



Actuator controls AUMATIC AC 01.2

Control
Parallel
→ Profibus DP
Modbus



Read operation instructions first.

- Observe safety instructions.

Purpose of the document:

This document contains information for the commissioning, operation and maintenance staff. It is intended to support local device operation and setting modifications.

Reference documents:

- Operation instructions (Assembly, operation, commissioning) for actuator.
- Manual (Device integration Fieldbus) AUMATIC AC 01.2/ACExC 01.2 Profibus DP

Reference documents can be downloaded from the Internet (www.auma.com) or ordered directly from AUMA (refer to <Addresses>).

Table of contents	Page
1. Safety instructions.....	7
1.1. Basic information on safety	7
1.2. Range of application	7
1.3. Warnings and notes	8
1.4. References and symbols	8
2. Identification.....	9
2.1. Name plate	9
2.2. Short description	10
3. Operation.....	11
3.1. Local actuator operation	11
3.2. Actuator operation from remote	12
3.3. Menu navigation via push buttons (for settings and indications)	12
3.3.1 Menu layout and navigation	13
3.4. User level, password	14
3.4.1 Password entry	14
3.4.2 Password change	15
3.5. Language in the display	15
3.5.1 Change language	15
4. Indications.....	17
4.1. Indications during commissioning	17
4.2. Indications in the display	17
4.2.1 Feedback indications from actuator and valve	18
4.2.2 Status indications according to AUMA classification	21
4.2.3 Status indications according to NAMUR recommendation	22
4.3. Indication lights	23
4.3.1 Indication lights: change colour	24
5. Signals.....	25
5.1. Signals via fieldbus	25
5.2. Status signals via output contacts (digital outputs)	25
5.2.1 Assignment of outputs	25
5.2.2 Encoding of outputs	25
5.3. Configurable status signals	26
5.4. Analogue signals	26
5.4.1 Assignment of analogue output 1	26

5.4.2	Signal range of analogue output 1	27
5.4.3	Adjustment of analogue output 1	27
5.4.4	Assignment of analogue output 2	28
5.4.5	Signal range of analogue output 2	28
5.4.6	Adjustment of analogue output 2	28
6.	Operation	29
6.1.	Operation mode Off	29
6.2.	Operation mode Local	29
6.2.1	Push-to-run operation or self-retaining Local	29
6.3.	Operation mode Remote	30
6.3.1	Push-to-run operation or self-retaining Remote	30
6.4.	Operation mode EMERGENCY	31
6.5.	Operation mode EMERGENCY stop	31
6.6.	Operation mode Disabled	31
6.7.	Operation mode Service	32
7.	Basic settings for commissioning.....	33
7.1.	Type of seating for end positions	33
7.1.1	Type of seating: set	33
7.2.	Torque switching	34
7.2.1	Torque switching: set	35
7.3.	Limit switching	36
7.3.1	Limit switching: set	36
7.4.	Date and time	38
7.5.	Display formats	38
7.5.1	Date format	38
7.5.2	Time format	39
7.5.3	Number format	39
7.5.4	Torque unit	39
7.5.5	Temperature unit	39
7.6.	Contrast	39
8.	Application functions.....	40
8.1.	Intermediate positions (pivot points)	40
8.1.1	Intermediate positions (pivot points): determine	40
8.1.2	Signal behaviour of intermediate positions: set	40
8.1.3	Hysteresis for intermediate positions: set	41
8.2.	Operation profile (operation behaviour) for intermediate positions	41
8.2.1	Operation profile: activate	42
8.2.2	Off times for intermediate positions (pivot points): set	42
8.2.3	Off times for intermediate positions (pivot points): set	43
8.3.	Two-wire control	43
8.4.	Positioner (operation mode Remote SETPOINT)	43
8.4.1	Positioner: activate	44
8.4.2	Adaptive behaviour: switch on or off	44
8.4.3	Overrun (inner dead band): set manually	45
8.4.4	Max. error variable (outer dead band): set manually	45
8.4.5	Dead time: set	46
8.4.6	Hysteresis for positioner: set	46
8.4.7	Closing fully/opening fully (end position tolerance for setpoint)	46
8.4.8	Limit setting range	46

8.4.9	Change-over between OPEN - CLOSE control and setpoint control	47
8.4.10	Input of setpoint position	48
8.4.11	Input range of setpoint position	48
8.5.	Process controller	49
8.5.1	Process controller activation	50
8.5.2	Process controller: set modulating behaviour	50
8.5.3	Setpoint source (input for process setpoint)	51
8.5.4	Behaviour on loss of process setpoint	52
8.5.5	Inverse operation	52
8.5.6	Internal process setpoint	52
8.5.7	Setting procedure	53
8.5.8	Proportional amplification Kp: set	53
8.5.9	Reset time Ti: set	53
8.5.10	Rate time Td: set	53
8.5.11	Actual value source (input for actual process value)	54
8.6.	Stepping mode	54
8.6.1	Stepping mode: activate	55
8.6.2	Operation mode for stepping mode	55
8.6.3	Start and end of stepping mode	55
8.6.4	On times and off times	55
8.7.	Profibus DP interface	56
8.7.1	Bus address (slave address)	56
8.7.2	Redundancy	56
8.7.3	Response telegrams for AUMA redundancy II	56
8.8.	Additional bus inputs	57
8.9.	Combination of fieldbus-parallel interface	57
8.10.	Auto change-over I/O (during bus failure)	58
8.11.	By-pass function	58
8.11.1	Bypass function: activate	60
8.11.2	By-pass application: configure	61
9.	Failure functions.....	62
9.1.	Reversing time	62
9.2.	Failure behaviour on loss of signal	62
9.2.1	Failure behaviour initiation on loss of signal	62
9.2.2	Failure source (failure reason) for a failure operation: set	63
9.2.3	Failure operation (reaction of the actuator) on loss of signal	63
9.2.4	Failure position: define	63
9.2.5	Delay time: set	64
9.3.	EMERGENCY behaviour	64
9.3.1	EMERGENCY behaviour: activate	65
9.3.2	EMERGENCY failure behaviour	65
9.3.3	Failure source (failure reason) for an EMERGENCY operation: set	66
9.3.4	Operation mode for EMERGENCY behaviour	66
9.3.5	EMERGENCY operation	66
9.3.6	EMERGENCY position	67
9.3.7	Torque switching: by-pass	67
9.3.8	Motor protection: by-pass	67
9.3.9	Stepping mode: by-pass	67
9.3.10	Operation profile: by-pass	68
9.3.11	Interlock: by-pass	68

9.3.12	Local stop: by-pass	68
9.3.13	Delay time for EMERGENCY operation	68
9.4.	Local controls: enable	69
9.4.1	Enabling function: activate	69
9.4.2	Enabling function behaviour	70
9.5.	Priority REMOTE	70
9.5.1	Priority REMOTE: activate	71
9.5.2	Priority REMOTE behaviour	71
9.5.3	Fieldbus auto enable	71
9.6.	Interlock (enable operation commands)	72
9.6.1	Interlock: activate	72
9.6.2	Operation mode Interlock	73
9.6.3	Interlock behaviour (running direction)	73
9.7.	Local Stop	73
9.7.1	Behaviour	73
9.8.	EMERGENCY stop function	74
9.9.	Partial Valve Stroke Test (PVST)	74
9.9.1	PVST: activate	75
9.9.2	Operation mode for PVST	76
9.9.3	Behaviour for PVST: define	76
9.9.4	Partial stroke for PVST: set	76
9.9.5	PVST monitoring time: set	76
9.9.6	PVST operating time: set	76
9.9.7	PVST reverse time: set	76
9.9.8	PVST reminder	77
10.	Monitoring functions.....	78
10.1.	Torque monitoring	78
10.2.	Motor protection monitoring (thermal monitoring)	79
10.3.	Type of duty monitoring (motor starts and running time)	80
10.4.	Operation time monitoring	81
10.5.	Reaction monitoring	82
10.6.	Motion detector	82
10.6.1	Motion detector: activate	82
10.6.2	Detection time dt	83
10.6.3	Travel difference dx	83
10.6.4	Delay time	83
10.7.	Monitoring of electronics power supply	83
10.8.	Temperature monitoring	83
10.9.	Verification of sub-assemblies	84
10.10.	Phase failure monitoring	84
10.11.	Phase sequence detection and correction of the direction of rotation	85
11.	Functions: activate and enable.....	86
11.1.	Activate functions	86
11.2.	Enable functions	86
12.	Service functions.....	87
12.1.	Direction of rotation	87
12.2.	Factory setting	87
12.3.	Languages: reload	88
12.4.	Data export	88

12.5.	Data import	88
12.6.	Actual configuration: accept	89
12.7.	Firmware update	89
12.8.	Service software AUMA ToolSuite (Bluetooth)	89
13.	Diagnostics.....	91
13.1.	Electronic device ID	91
13.2.	Operating data	91
13.3.	Event report	92
13.4.	Diagnostic interface	94
13.5.	Profibus interface: diagnostics	95
13.6.	Bluetooth connection: diagnostic	95
13.7.	Diagnostic position transmitter potentiometer	96
13.8.	Diagnostic position transmitter RWG	96
13.9.	Diagnostic position transmitter MWG	96
13.10.	Diagnostic positioner	97
13.11.	Torque-travel characteristic	97
13.12.	Motor running time-position (histogram)	98
13.13.	Motor running time-temperature (histogram)	99
13.14.	Motor running time-torque (histogram)	99
14.	Simulation (inspection and test function).....	101
14.1.	Actuator signals	101
14.2.	Interface signals	101
15.	Corrective action.....	102
15.1.	Primary fuses	102
15.2.	Fault indications and warning indications	102
16.	Appendix.....	109
16.1.	Selection overview for output contacts and indication lights (digital outputs DOUT)	109
16.2.	Selection overview of binary signals for digital inputs (DIN)	111
17.	Index.....	115
18.	Parameter index.....	119
	Addresses.....	121

1. Safety instructions

1.1 Basic information on safety

Standards/directives AUMA products are designed and manufactured in compliance with recognised standards and directives. This is certified in a Declaration of Incorporation and a EC Declaration of Conformity.

The end user or the contractor must ensure that all legal requirements, directives, guidelines, national regulations and recommendations with respect to assembly, electrical connection, commissioning and operation are met at the place of installation.

They include among others:

- Standards and directives such as: EN 60079 "Electrical apparatus for explosive gas atmospheres" –
 - Part 14: Electrical installations in hazardous areas (other than mines).
 - Part 17: Inspection and maintenance of electrical installations in hazardous areas (other than mines).

- Applicable configuration guidelines for fieldbus applications.

They include among others applicable configuration guidelines for fieldbus applications.

Safety instructions/warnings All personnel working with this device must be familiar with the safety and warning instructions in this manual and observe the instructions given. Safety instructions and warning signs on the device must be observed to avoid personal injury or property damage.

Qualification of staff Assembly, electrical connection, commissioning, operation, and maintenance must be carried out exclusively by suitably qualified personnel having been authorised by the end user or contractor of the plant only.

Prior to working on this product, the staff must have thoroughly read and understood these instructions and, furthermore, know and observe officially recognised rules regarding occupational health and safety.

Work performed in potentially explosive atmospheres is subject to special regulations which have to be observed. The end user or contractor of the plant are responsible for respect and control of these regulations, standards, and laws.

Commissioning Prior to commissioning, it is important to check that all settings meet the requirements of the application. Incorrect settings might present a danger to the application, e.g. cause damage to the valve or the installation. The manufacturer will not be held liable for any consequential damage. Such risk lies entirely with the user.

Operation Prerequisites for safe and smooth operation:

- Correct transport, proper storage, mounting and installation, as well as careful commissioning.
- Only operate the device if it is in perfect condition while observing these instructions.
- Immediately report any faults and damage and allow for corrective measures.
- Observe recognised rules for occupational health and safety.
- Observe the national regulations.

Protective measures The end user or the contractor are responsible for implementing required protective measures on site, such as enclosures, barriers, or personal protective equipment for the staff.

Maintenance Any device modification requires the consent of the manufacturer.

1.2 Range of application

AUMA actuator controls are exclusively designed for the operation of AUMA actuators.

Other applications require explicit (written) confirmation by the manufacturer. The following applications are not permitted, e.g.:

- motor control
- pump control

No liability can be assumed for inappropriate or unintended use.

Observance of these operation instructions is considered as part of the device's designated use.

1.3 Warnings and notes

The following warnings draw special attention to safety-relevant procedures in these operation instructions, each marked by the appropriate signal word (DANGER, WARNING, CAUTION, NOTICE).



Indicates an imminently hazardous situation with a high level of risk. Failure to observe this warning could result in death or serious injury.



Indicates a potentially hazardous situation with a medium level of risk. Failure to observe this warning could result in death or serious injury.



Indicates a potentially hazardous situation with a low level of risk. Failure to observe this warning may result in minor or moderate injury. May also be used with property damage.



Potentially hazardous situation. Failure to observe this warning may result in property damage. Is not used for personal injury.


Arrangement and typographic structure of the warnings



Type of hazard and respective source!

Potential consequence(s) in case of non-observance (option)

- Measures to avoid the danger
- Further measure(s)

Safety alert symbol  warns of a potential personal injury hazard.
The signal word (here: DANGER) indicates the level of hazard.

1.4 References and symbols

The following references and symbols are used in these instructions:

Information The term **Information** preceding the text indicates important notes and information.



Symbol for CLOSED (valve closed)



Symbol for OPEN (valve open)



Important information before the next step. This symbol indicates what is required for the next step or what has to be prepared or observed.



Via the menu to parameter

Describes the path within the menu to the parameter. By using the push buttons of the local controls you may quickly find the desired parameter in the display.



Reference to other sections


Terms in brackets shown above refer to other sections of the document which provide further information on this topic. These terms are either listed in the index, a heading or in the table of contents and may quickly be found.

2. Identification

2.1 Name plate


Each device is equipped with a name plate.

Figure 1: Arrangement of name plate



[1] Controls name plate

Data for identification Figure 2: Controls name plate



[1] Type and size of the controls
[2] Commission number
[3] Wiring diagram
[4] Control

Type and size

These instructions apply to the following devices:

Types: AC/ACExC = AUMATIC actuator controls

Size: 01.2

Versions: Intrusive and Non-Intrusive

Commission number

An order-specific commission number is assigned to each device. This commission number can be used to directly download the wiring diagram, inspection records and further information regarding the device from the Internet: <http://www.auma.com>.

Wiring diagram

9th position in the **TPA** wiring diagram: Position transmitter (actuator):

Control unit: electromechanical:

0 = Without position transmitter

A, B, J, K, L, N = Potentiometer

C, D, E, G, H, M = RWG (electronic position transmitter)

Control unit: electronic:

I = MWG (Magnetic limit and torque transmitter)

Control

Profibus DP = Control via Profibus DP interface

Profibus DP-V1 = Control via Profibus DP-V1 interface

Profibus DP-V2 = Control via Profibus DP-V1 interface

Profibus DP/24 V DC = Control via Profibus DP interface and parallel interface at 24 V DC

2.2 Short description

Actuator controls The AUMATIC actuator controls are used to operate AUMA actuators and are supplied ready for use. The controls may be mounted directly to the actuator or separately on a wall bracket.

The functions of the AUMATIC controls include standard valve control in OPEN - CLOSE duty, positioning, process control, logging of operating data, diagnostic functions right through control via fieldbus.

Local controls/AUMA ToolSuite Operation, setting, and display can be performed directly at the controls or alternatively from REMOTE via a fieldbus interface.

When set to local control, it is possible to

- operate the actuator via the local controls (push buttons and display) and perform settings (contents of these instructions).
- read in or out data or modify and save settings via the AUMA ToolSuite software (option), using a computer (laptop or PC). The connection between computer and AUMATIC is wireless via Bluetooth interface (not included in these instructions).

Intrusive - Non-Intrusive

- Intrusive version (control unit: electromechanical):
Limit and torque setting is performed via switches in the actuator.
- Non-Intrusive version (control unit: electronic):
Limit and torque setting is performed via the controls, actuator and controls housings do not have to be opened. For this purpose, the actuator is equipped with an MWG (magnetic limit and torque transmitter), also supplying analogue torque feedback signals/torque indication and analogue position feedback signals/position indication.

3. Operation

NOTICE

Valve damage due to incorrect basic setting!

→ Prior to electrical operation of the actuator, the basic settings i.e. type of seating, torque and limit switching have to be completed.

3.1 Local actuator operation

Local actuator operation is performed using the push buttons of the local controls of the AC.

Figure 3: Local controls



- [1] Push button for operation command in direction OPEN
- [2] Push button STOP
- [3] Push button for operation command in direction CLOSE
- [4] Push button RESET
- [5] Selector switch


CAUTION

Hot surfaces, e.g. possibly caused by high ambient temperatures or strong direct sunlight!



Danger of burns

→ Check surface temperature and wear protective gloves, if required.

→ Set selector switch [5] to position **Local control** (LOCAL).



➔ The actuator can now be operated using the push buttons [1 – 3].


- Run actuator in direction OPEN: Press push button [1] .
- Stop actuator: Press push button STOP [2].
- Run actuator in direction CLOSE: Press push button [3] .

Information

The OPEN - CLOSE operation commands can be given either in push-to-run operation mode or in self-retaining mode. For further information, please refer to <Push-to-run operation or self-retaining local> chapter.

3.2 Actuator operation from remote

→ Set selector switch to position **Remote control** (REMOTE).




→ Now, the actuator can be remote-controlled via fieldbus.

Information For actuators equipped with a positioner, it is possible to select between **open-close control** (Remote OPEN-CLOSE) and **setpoint control** (Remote SETPOINT). For further information, please refer to <Selection between open-close control and setpoint control>.

3.3 Menu navigation via push buttons (for settings and indications)


Menu navigation for display and setting is made via the push buttons [1 – 4] of the local controls.

Set the selector switch [5] to position **0** (OFF) when navigating through the menu.



The bottom row of the display [6] serves as navigation support and explains which push buttons [1 – 4] are used for menu navigation.

Figure 7:



[1–4] Push buttons or navigation support

[5] Selector switch

[6] Display

Table 1: Important push button functions for menu navigation

Push buttons	Navigation support on display	Functions
[1] ▲	Up ▲	Change screen/selection
		Change values
		Enter figures from 0 to 9
[2] ▼	Down ▼	Change screen/selection
		Change values
		Enter figures from 0 to 9

Push buttons	Navigation support on display	Functions
[3]	Ok	Confirm selection
	Save	Save
	Edit	Enter <Edit> menu
	Details	Display more details
[4] C	Setup	Enter Main menu
	Esc	Cancel process
		Return to previous display

- Backlight**
- The display is illuminated in white during normal operation. The backlight turns to red under fault conditions.
 - The screen illumination is brighter when operating a push button. If no push button is operated for 60 seconds, the display will become dim again.

3.3.1 Menu layout and navigation

Groups The indications on the display are divided into 3 groups:


Figure 8: Groups



- [1] Startup menu
- [2] Status menu
- [3] Main menu

ID Status menu and main menu are marked with an ID.

Figure 9: Marking with ID




- S ID starts with S = status menu
- M ID starts with M = main menu

Group selection It is possible to select between status menu **S** and main menu **M**:

For this, set selector switch to **0** (OFF), hold down push button **C** for approx. 2 seconds until a screen containing the ID **M...** appears.

Figure 10: Select menu groups




You return to the status menu if:

- the push buttons on the local controls have not been operated within 10 minutes
- or by briefly pressing **C**

Direct display via ID

When entering the ID within the main menu, screens can be displayed directly (without clicking through).

Figure 11: Direct display (example)



Display indicates in the bottom row: **Go to**


1. Press push button **▲ Go to**.
Display indicates: **Go to menu M0000**
2. Use push buttons **▲▼ Up ▲ Down ▼** to select figures 0 to 9.
3. Press push button **↵ Ok** to confirm first digit.
4. Repeat steps 2 and 3 for all further digits.
5. To cancel the process: Press **C Esc**.

3.4 User level, password

User level The user level defines which menu items or parameters can be displayed or modified by the active user.

There are 6 different user levels. The user level is indicated in the top row:

Figure 12: User level display (example)



Password A password must be entered to allow parameter modification. The display indicates: **Password 0*****

A specific password is assigned to each user level and permits different actions.

Table 2: User levels and authorisations

Designation (user level)	Authorisation/password
Observer (1)	Verify settings No password required
Operator (2)	Change settings Default factory password: 0000
Maintenance (3)	Reserved for future extensions
Specialist (4)	Change device configuration e.g. type of seating, assignment of output contacts Default factory password: 0000
Service (5)	Service staff Change configuration settings
AUMA (6)	AUMA administrator

3.4.1 Password entry

Display indicates: **Password 0*****

1. Select desired menu and hold down push button **↵** for approx. 3 seconds.
➡ Display indicates the set user level, e.g. **Observer (1)**
2. Press **▲ Up ▲** to select a higher user level and press **↵ Ok** to confirm.
➡ Display shows: **Password 0*****
3. Use push buttons **▲▼ Up ▲ Down ▼** to select figures 0 to 9.
4. Confirm first digit of password via push button **↵ Ok**.

5. Repeat steps 1 and 2 for all further digits.
- ➔ Having confirmed the last digit with **↵ Ok**, access to all parameters within one user level is possible if the password entry is correct.

3.4.2 Password change


Only the passwords of same or lower user level may be changed.

Example: The user is signed in as **Specialist (4)**. This authorises him or her to modify the passwords between user levels (1) to (4).

M ▶ **Device configuration M0053**
Service functions M0222
Change passwords M0229

Menu point **Service functions M0222** is only visible if user level has been set to **Specialist (4)** or higher.

- Select main menu**
1. Set selector switch to position **0** (OFF).



2. Press push button **C Setup** and hold it down for approx. 3 seconds.
- ➔ Display goes to main menu and indicates: **▶ Display...**

Change passwords

3. Select parameter **Change passwords** either:
 - click via the menu **M ▶** to parameter, or
 - via direct display: press **▲** and enter ID **M0229**
- Display indicates: **▶ Change passwords**
- The user level is indicated in the top row (1 – 6), e.g.:



- For user level 1 (view only), passwords cannot be changed. To change passwords, you must change to a higher user level. For this, enter a password via a parameter.
- 4. For a user level between 2 and 6: Press push button **↵ Ok**.
- ➔ The display indicates the highest user level, e.g.: **For user 4**
- 5. Select user level via push buttons **▲ ▼ Up ▲ Down ▼** and confirm with **↵ Ok**.
- ➔ Display indicates: **▶ Change passwords Password 0*****
- 6. Enter current password (→ enter password).
- ➔ Display indicates: **▶ Change passwords Password (new) 0*****
- 7. Enter new password (→ enter password).
- ➔ Display indicates: **▶ Change passwords For user 4 (example)**
- 8. Select next user level via push buttons **▲ ▼ Up ▲ Down ▼** or cancel the process via **Esc**.

3.5 Language in the display


The AUMATIC display is multilingual.

3.5.1 Change language

M ▶ **Display... M0009**
Language M0049

Select main menu

1. Set selector switch to position **0** (OFF).



2. Press push button **C Setup** and hold it down for approx. 3 seconds.
➔ Display goes to main menu and indicates: ▶ **Display...**

Change language

3. Press **↵ Ok**.
➔ Display indicates: ▶ **Language**
4. Press **↵ Ok**.
➔ Display indicates the selected language, e.g.: ▶ **Deutsch**
5. The bottom row of the display indicates:
 - **Save** → continue with step 10
 - **Edit** → continue with step 6
6. Press **↵ Edit**.
➔ Display indicates: ▶ **Observer (1)**
7. Select user level via **▲▼ Up ▲ Down ▼** resulting in the following significations:
 - black triangle: ▶ = current setting
 - white triangle: ▷ = selection (not saved yet)
8. Press **↵ Ok**.
➔ Display indicates: **Password 0*****
9. Enter password (→ enter password).
➔ Display indicates: ▶ **Language** and **Save** (bottom row)
10. Select new language via **▲▼ Up ▲ Down ▼** resulting in the following significations:
 - black triangle: ▶ = current setting
 - white triangle: ▷ = selection (not saved yet)
11. Confirm selection via **↵ Save**.
➔ The display changes to the new language. The new language selection is saved.

Language selection


4. Indications

4.1 Indications during commissioning

LED test

When switching on the power supply, all LEDs on the local controls illuminate for approx. 1 second. This optical feedback indicates that the voltage supply is connected to the controls and all LEDs are operable.

Figure 16: LED test




Language selection

During the self-test, the language selection can be activated so that the selected language is immediately indicated in the display. For this, set selector switch [5] to position 0 (OFF).

Activate language selection:

1. Display indicates in the bottom row: **Language selection menu? 'Reset'**
2. Press push button **RESET** and hold it down until the following text is displayed in the bottom line: **Language menu loading, please wait.**

Figure 17: Self-test




The language selection menu follows the startup menu.

Startup menu


The current firmware version is displayed during the startup procedure:

Figure 18: Startup menu with firmware version: 04.00.00–xxxx



If the language selection feature has been activated during the self-test, the menu for selecting the display language will now be indicated. For further information on language setting, please refer to chapter <Language in the display>.

Figure 19: Language selection




If no entry is made over a longer period of time (approx. 1 minute), the display automatically returns to the first status indication.

4.2 Indications in the display

Status bar

The status bar (first row in the display) indicates the operation mode [1], the presence of an error [2] and the ID number [3] of the current display indication.

Figure 20: Information in the status bar (top)




- [1] Operation mode
- [2] Error symbol (only for faults and warnings)
- [3] ID number: S = Status page

Navigation support

If further details or information are available with reference to the display, the following indications **Details** or **More** appear in the navigation support (bottom display row). Then, further information can be displayed via the push button.

Figure 21: Navigation support (bottom)



- [1] shows list with detailed indications
- [2] shows further available information

The navigation support (bottom row) is faded out after approx. 3 seconds. Press any push button (selector switch in position 0 (OFF)) to fade in the navigation support.

4.2.1 Feedback indications from actuator and valve


Display indications depend on the actuator version.

Valve position (S0001)

This indication is only available if a position transmitter (potentiometer, RWG or MWG) is installed in the actuator.


- **S0001** on the display indicates the valve position in % of the travel.
- The bargraph display appears after approx. 3 seconds.
- When issuing an operation command, an arrow indicates the direction (OPEN/CLOSE).

Figure 22: Valve position and direction of operation



Reaching the preset end positions is additionally indicated via symbols (CLOSED) and (OPEN).

Figure 23: End position CLOSED/OPEN reached




- 0% Actuator is in end position CLOSED
- 100% Actuator is in end position OPEN

Torque (S0002)

The indication is only available if the actuator is equipped with an MWG (magnetic limit and torque transmitter).

- **S0002** on the display indicates the torque applied at the actuator output.
- The bargraph display appears after approx. 3 seconds.

Figure 24: Torque



Select unit



The push button  allows to select the unit displayed (percent %, Newton metre Nm or pounds per foot Lbs/ft.).

Figure 25: Units of torque



Display in percent

100 % indication equals the max. torque indicated on the name plate of the actuator.
Example: SA 07.5 with 20 – 60 Nm.

- 100 % corresponds to 60 Nm of nominal torque.
- 50 % corresponds to 30 Nm of nominal torque.

Operation commands (S0003)

The display **S0003** indicates:


- active operation commands, like e.g.: Operation in direction CLOSE or in direction OPEN
- the actual value E2 as bargraph indication and as value between 0 and 100 %.
- for setpoint control (positioner): setpoint E1
- for stepping mode or for intermediate positions with operation profile: pivot points and operation behaviour of pivot points

The navigation support (bottom row) is faded out after approx. 3 seconds and the axis/axes for pivot point display are shown.

OPEN - CLOSE control

Active operation commands (OPEN, CLOSE, ...) are shown above the bargraph display. The figure below shows the operation command in direction CLOSE.

Figure 26: Display for OPEN - CLOSE control




E2 Actual position value

Setpoint control If the positioner is enabled and activated, the bargraph indication for E1 (position setpoint) is displayed.

The direction of the operation command is displayed by an arrow above the bargraph indication. The figure below shows the operation command in direction CLOSE.

Figure 27: Display for setpoint control (positioner)



E1 Position setpoint
E2 Actual position value

Pivot point axis The pivot points and their operation behaviour (operation profile) are shown on the pivot point axis by means of symbols.

The symbols are only displayed if at least one of the following functions is activated:

Operation profile M0294

Timer CLOSE M0156

Timer OPEN M0206

Figure 28: Examples: on the left pivot points (intermediate positions); on the right stepping mode




Table 3: Symbols along the pivot point axis

Symbol	Pivot point (intermediate position) with operation profile	Stepping mode
	Pivot point without reaction	End of stepping mode
◀	Stop during operation in direction CLOSE	Start of stepping mode in direction CLOSE
▶	Stop during operation in direction OPEN	Start of stepping mode in direction OPEN
◆	Stop during operation in directions OPEN and CLOSE	—
◁	Pause for operation in direction CLOSE	—
▷	Pause for operation in direction OPEN	—
◇	Pause for operation in directions OPEN and CLOSE	—

Multiport valve positions (S0017)

In case of active multiport valve function, the display S0017 indicates a second bargraph display with set positions (valve connections) above the actual position value E2. Positions (P1, P2, ...) are displayed with a black triangle ▼. Push buttons ▲▼ are used to select positions. Both positions and the actual position value E2 are displayed in degrees.

Figure 29: Status indication for multiport valve (example P4 = 180°)



4.2.2 Status indications according to AUMA classification


These indications are available, if the parameter **Diagnostic classific. M0539** is set to **AUMA**.

Warnings (S0005)

If a warning has occurred, the display shows **S0005**:

- the number of warnings occurred
- a blinking question mark after approx. 3 seconds

Figure 30: Warnings



For further information, please also refer to <Corrective action>.


Not ready REMOTE (S0006)

The **S0006** display shows indications of the Not ready REMOTE group.

If such an indication has occurred, the display shows **S0006**:

- the number of indications occurred
- a blinking crossbar after approx. 3 seconds

Figure 31: Not ready REMOTE indications




For further information, please also refer to <Corrective action>.

Fault (S0007)

If a fault has occurred, the display shows **S0007**:

- the number of faults occurred
- a blinking exclamation mark after approx. 3 seconds

Figure 32: Fault



For further information, please also refer to <Corrective action>.

4.2.3 Status indications according to NAMUR recommendation

These indications are available, if the parameter **Diagnostic classific. M0539** is set to **NAMUR**.


Out of Specification (S0008)

The **S0008** indication shows out of specification indications according to NAMUR recommendation NE 107.

If such an indication has occurred, the display shows **S0008**:

- the number of indications occurred
- a blinking triangle with question mark after approx. 3 seconds

Figure 33: Out of specification



For further information, please also refer to <Corrective action>.


Function check (S0009)

The **S0009** indication shows function check indications according to NAMUR recommendation NE 107.

If an indication has occurred via the function check, the display shows **S0009**:

- the number of indications occurred
- a blinking triangle with a spanner after approx. 3 seconds

Figure 34: Function check



For further information, please also refer to <Corrective action>.


Maintenance required (S0010)

The **S0010** indication shows maintenance indications according to NAMUR recommendation NE 107.

If such an indication has occurred, the display shows **S0010**:

- the number of indications occurred
- a blinking square with an oil can after approx. 3 seconds

Figure 35: Maintenance required



For further information, please also refer to <Corrective action>.


Failure (S0011)

The S0011 indication shows the causes of the failure indication according to NAMUR recommendation NE 107.

If such an indication has occurred, the display shows S0011:

- the number of indications occurred
- a blinking circle with a cross after approx. 3 seconds

Figure 36: Failure



For further information, please also refer to <Corrective action>.

4.3 Indication lights

Figure 37: Arrangement and signification of indication lights



- [1] Marking with symbols (standard)
 [2] Marking with figures 1 – 6 (option)
- 1 End position CLOSED reached (blinking: for operation in direction CLOSE)
 2 Tc Torque fault CLOSE
 3 Motor protection tripped
 4 To Torque fault OPEN
 5 End position OPEN reached (blinking: for operation in direction OPEN)
 6 Bluetooth connection

Modify indication light assignment (indications)

Different indications can be assigned to LEDs 1 – 5.

- M ► **Device configuration** M0053
 Local controls M0159
 Indication light 1 (left) M0093
 Indication light 2 M0094
 Indication light 3 M0095
 Indication light 4 M0096
 Indicat. light 5 (right) M0097
 Signal interm. pos. M0167

Default values (Europe):

Indication light 1 (left) = End p. CLOSED, blink

Indication light 2 = Torque fault CLOSE
 Indication light 3 = Thermal fault
 Indication light 4 = Torque fault OPEN
 Indicat. light 5 (right) = End p. OPEN, blink
 Signal interm. pos. = OPEN/CLOSED = Off

Further setting values:

Refer to <Appendix>/<Selection overview for output contacts and indication lights>

4.3.1 Indication lights: change colour

— Option —

User level required to make changes: AUMA (6)

M ▷ Device configuration M0053
 Local controls M0159

Parameters	Menu	Default values for version		Setting values
		Europe	USA	
Colour ind.light 1	M0838	Yellow	Green	Yellow Green Yellow/green
Colour ind.light 2	M0839	Red	Blue	Red Blue Purple
Colour ind.light 3	M0840	Red	Yellow	Red Yellow Orange
Colour ind.light 4	M0841	Red	Blue	Red Blue Purple
Colour ind.light 5	M0842	Green	Red	Green Red Orange

5. Signals

5.1 Signals via fieldbus

Feedback signals via fieldbus can be configured. Configuration is possible for both data structure and data contents.

Configuration is defined via the GSD file only.

Information If required, download the GSD file (General Station Description) from the Internet: www.auma.com

For information on the feedback signals via fieldbus and the configuration of the parameters via fieldbus interface, refer to Manual (Device integration fieldbus) Profibus DP.

5.2 Status signals via output contacts (digital outputs)

— (Option) —

Output contacts are only available if a parallel interface is provided in addition to the fieldbus interface.

Characteristics Output contacts are used to send status signals (e.g. reaching the end positions, selector switch position, faults...) as binary signals to the control room.

Status signals only have two states: active or inactive. Active means that the conditions for the signal are fulfilled.

5.2.1 Assignment of outputs

The output contacts (outputs DOUT 1 – 6) can be assigned to various signals.

Required user level: **Specialist (4)** or higher.

M ▶ **Device configuration** M0053
 I/O interface M0139
 Digital outputs M0110
 Signal DOUT 1 M0109

Default values:

Signal DOUT 1 = Fault
Signal DOUT 2 = End position CLOSED
Signal DOUT 3 = End position OPEN
Signal DOUT 4 = Selector sw. REMOTE
Signal DOUT 5 = Torque fault CLOSE
Signal DOUT 6 = Torque fault OPEN

Further setting values:

Refer to <Appendix>/<Selection overview for output contacts and indication lights>

5.2.2 Encoding of outputs

The output signals DOUT 1 – 6 can be set either to high active or low active.

- High active = output contact closed = signal active
- Low active = output contact open = signal active

Required user level: **Specialist (4)** or higher.

M ▶ **Device configuration** M0053
 I/O interface M0139
 Digital outputs M0110
 Coding DOUT 1 M0102

Default values for DOUT 1 – 6: High active

5.3 Configurable status signals

Requirements <Additional inputs> or additional <Parallel interface>.

Failure (Cfg) signal can be configured as user-specific fault signal. The signal may both be sent to a digital output (output contact) and assigned to an indication light (LED).

Required user level: **Specialist (4)** or higher.

M ▶ **Device configuration** M0053
Config. of signals M0860
Failure (Cfg) M0879

Default values:

- ☒ **Warning (Cfg)** (activated)
- ☒ **Fault (Cfg)** (activated)
- ☒ **Not ready REMOTE (Cfg)** (activated)

Each signal contains further signals which can be activated or deactivated.

5.4 Analogue signals

— (Option) —

Conditions The actuator is equipped with a position transmitter.

Characteristics Depending on the actuator equipment, different signals, such as travel, torque or output speed can be recorded and issued as continuous values, e.g. 4 to 20 mA. The AC is equipped with up to two analogue outputs AOUT1 and AOUT2.

5.4.1 Assignment of analogue output 1

Designation in the wiring diagram: AOUT 1.

Required user level: **AUMA (6)**.

M ▶ **Device configuration** M0053
I/O interface M0139
Analogue outputs M0335
Signal AOUT 1 M0131

Default value: **Actual position**

Information The signal range of the output (e.g. 0/4 – 20 mA) is set via a separate parameter (**Signal range AOUT 1** M0129).

Setting values:

Not used Analogue output 1 is not assigned.

Actual position Position feedback of the valve position (actual position value E2)

Condition: Position transmitter installed in the actuator.

An adjustment to the end positions or the defined travel is not required. An automatic adjustment is done via the end positions (LSC (WSR) and LSO (WOEL)).


For torque seating, the end positions OPEN and CLOSED of the limit switching should be set as close as possible to the end positions of the valve to minimise the deviation of the feedback.

Torque Torque feedback E6

Condition: Position transmitter MWG installed in the actuator.

The zero point is in the centre of the selected output range (10 mA or 12 mA). The torque in direction CLOSE is indicated with 0 – 10 mA or 4 – 12 mA, the torque in direction OPEN with 10 – 20 mA or 12 – 20 mA. For 100 % of the nominal output torque, 0 or 4 mA are indicated in direction CLOSE, and 20 mA are indicated in direction OPEN.

Figure 38: Actual torque value



-100%= maximum nominal torque in end position CLOSED reached

+100%= maximum nominal torque in end position OPEN reached

Input AIN 1 Analogue value transmitted via AIN1 (refer to wiring diagram) to the actuator.

Condition: An analogue signal (e.g. 0 – 20 mA) is connected to the analogue input AIN 1.

Input AIN 2 Analogue value transmitted via AIN 2 (refer to wiring diagram) to the actuator.

Condition: An analogue signal (e.g. 0 – 20 mA) is connected to the analogue input AIN 2.

Fieldbus AOUT 1 Analogue value transmitted from the fieldbus to the actuator.

The value is transmitted via fieldbus in per mil (value: 0 – 1000) and can be sent as continuous value. e.g 4 to 20 mA, via output **Signal AOUT 1**.

Fieldbus AOUT 2 If another analogue value is transmitted via fieldbus to the actuator, it can be sent as continuous value. e.g 4 to 20 mA, via output **Signal AOUT 2**.

5.4.2 Signal range of analogue output 1

Required user level: **Specialist (4)** or higher.

M ▶ **Device configuration** M0053
I/O interface M0139
Analogue outputs M0335
Signal range AOUT 1 M0129

Default value: 0 - 20 mA

Setting values:

0 - 20 mA Analogue output 1 generates a 0 – 20 mA signal.

4 - 20 mA Analogue output 1 generates a 4 – 20 mA signal.

20 - 0 mA Analogue output 1 generates a 20 – 0 mA signal.

20 - 4 mA Analogue output 1 generates a 20 – 4 mA signal.

5.4.3 Adjustment of analogue output 1

The initial values and end values of the signal range can be corrected by ± 1 mA.

Example: Parameter **Signal range AOUT 1** = 4 - 20 mA

The initial value (4 mA) can be adapted within a range of 3 mA to 5 mA.

The end value (20 mA) can be adapted within a range of 19 mA to 21 mA.

Required user level: **Specialist (4)** or higher.

M ▶ **Device configuration** M0053
I/O interface M0139
Analogue outputs M0335
Adjustment AOUT 1 M0544
0/4 mA (initial value) M0140
20 mA (final value) M0210

Default value: 0

Setting ranges: -100 ... 100 (- 1.00 to + 1.00 mA)

5.4.4 Assignment of analogue output 2

Designation in the wiring diagram: AOUT2.

Required user level: AUMA (6).

- M ▶ Device configuration M0053
 I/O interface M0139
 Analogue outputs M0335
 Signal AOUT 2 M0132

Default value: Torque

Setting values:

Description see <Assignment of analogue output 1>.

5.4.5 Signal range of analogue output 2

Required user level: Specialist (4) or higher.

- M ▶ Device configuration M0053
 I/O interface M0139
 Analogue outputs M0335
 Signal range AOUT 2 M0130

Default value: 0 - 20 mA

Setting values:

- 0 - 20 mA Analogue output 2 generates a 0 – 20 mA signal.
 4 - 20 mA Analogue output 2 generates a 4 – 20 mA signal.
 20 - 0 mA Analogue output 2 generates a 20 – 0 mA signal.
 20 - 4 mA Analogue output 2 generates a 20 – 4 mA signal.

5.4.6 Adjustment of analogue output 2

Initial values and end values of the signal range can be corrected by ± 1 mA

Example: Parameter Signal range AOUT 1 = 4 - 20 mA

The initial value (4 mA) can be adapted within a range of 3 mA to 5 mA.

The end value (20 mA) can be adapted within a range of 19 mA to 21 mA.

Required user level: Specialist (4) or higher.

- M ▶ Device configuration M0053
 I/O interface M0139
 Analogue outputs M0335
 Adjustment AOUT 2 M0545
 0/4 mA (initial value) M0141
 20 mA (final value) M0211

Default values: 0

Setting ranges: -100 ... 100 (-1.00 to +1.00 mA)

6. Operation

Different operation modes (states) are available. The current operation mode is indicated in the first line of the display:


Figure 39: Example: Operation mode Off



This chapter describes the characteristics of the different operation modes; the respective functions are described in separate chapters.

6.1 Operation mode Off

The selector switch is in position **0** (OFF).




Characteristics

- The indication in the top row of the display shows: **Off**
- Electric operation is not possible (not even EMERGENCY operation).
- The controls remain fully operative as far as signalling is concerned (controls' power supply is maintained).
- Push buttons ▲ ▼ ◀ ▶ can be used for menu navigation via the display.

6.2 Operation mode Local

Selector switch is in position **Local control** (LOCAL).



Characteristics

- The indication in the top row of the display shows: **Local**
- In motor operation, the actuator can be controlled locally via the push buttons **I** (OPEN), **STOP**, **II** (CLOSE).
- Faults and warnings without automatic reset can be confirmed with the push button RESET.

6.2.1 Push-to-run operation or self-retaining Local

The parameter **Self-retaining LOCAL M0076** determines the operation behaviour of the actuator to operation commands via the push buttons of the local controls.

M ▶ **Customer settings M0041**
Local controls M0075
Self-retaining LOCAL M0076

Default value: OPEN and CLOSE

Setting values:

Off (push-to-run op.) Push-to-run operation activated, self-retaining off:

Actuator only runs in direction OPEN or CLOSE while an operation command is being received. The actuator stops if the operation command is cancelled.

OPEN In direction OPEN = self-retaining (in direction CLOSE push-to-run operation):

After an operation command in direction OPEN, the actuator continues to run, even if the operation command is cancelled (self-retaining). The actuator is either stopped by the STOP command or if end position OPEN or an intermediate position OPEN has been reached.

CLOSE In direction CLOSE = self-retaining (in direction OPEN push-to-run operation):



After an operation command in direction CLOSE, the actuator continues to run, even if the operation command is cancelled (self-retaining). The actuator is either stopped by the STOP command or if end position CLOSED or an intermediate position CLOSED has been reached.

OPEN and CLOSE In directions OPEN and CLOSE = self-retaining:

After an operation command, the actuator continues to run in directions OPEN or CLOSE, even if the operation command is cancelled (self-retaining). The actuator is either stopped by the STOP command or if an end position or intermediate position has been reached.


OPEN & CL w/o STOP In directions OPEN and CLOSE = self-retaining without stop:

Direct reversal of operation direction without STOP command is possible.

Information Hold down push buttons  (OPEN) or  (CLOSE) for more than 2 seconds to activate self-retaining, press STOP to reset the operation mode to push-to-run operation.

6.3 Operation mode Remote

Selector switch is in position **Remote control** (REMOTE).



Characteristics The indication in the top row of the display shows the set source of the operation commands:

- **Remote** (parallel interface)
- **Remote II** (parallel interface, operation box)
- **Fieldbus** (channel 1 or channel 2)

Depending on the control, a distinction is made between:

- OPEN - CLOSE control (operation mode Remote OPEN - CLOSE):
Control is made via binary operation commands OPEN, STOP, CLOSE.
- Setpoint control (operation mode Remote SETPOINT):
Control via analogue operation commands, e.g. 4 – 20 mA.

Information

- Binary signals (e. g. +24 V DC) via digital inputs are only recognised as valid operation commands if the signal is present for at least 100 ms.
- If a positioner or process controller is available, change-over between OPEN - CLOSE control (operation mode Remote OPEN - CLOSE) and setpoint control (operation mode Remote SETPOINT) is possible. Refer to chapter <Change-over between OPEN - CLOSE control and setpoint control>.

6.3.1 Push-to-run operation or self-retaining Remote

Parameters **Self-retaining Remote M0100** and **Self-retaining Remote II M0101** determine the operation behaviour of the actuator to binary operation commands (OPEN, STOP, CLOSE) from Remote.

The two parameters have no influence on the operation commands transmitted via fieldbus. Setting will only be required if, in addition to the fieldbus interface, digital inputs (OPEN, STOP, CLOSE) are available for control.

M ▶ **Customer settings M0041**
I/O interface M0015
Self-retaining Remote M0100
Self-retaining Remote II M0101

Default value: Off (push-to-run op.)

Setting values:

Off (push-to-run op.) Push-to-run operation activated, self-retaining off:

Actuator only runs in direction OPEN or CLOSE while an operation command is being received. The actuator stops if the operation command is cancelled.

OPEN In direction OPEN = self-retaining (in direction CLOSE push-to-run operation):
After an operation command in direction OPEN, the actuator continues to run, even if the operation command is cancelled (self-retaining). The actuator is either stopped by the STOP command or if end position OPEN or an intermediate position OPEN has been reached.

CLOSE In direction CLOSE = self-retaining (in direction OPEN push-to-run operation):
After an operation command in direction CLOSE, the actuator continues to run, even if the operation command is cancelled (self-retaining). The actuator is either stopped by the STOP command or if end position CLOSED or an intermediate position CLOSED has been reached.


OPEN and CLOSE In directions OPEN and CLOSE = self-retaining:
After an operation command, the actuator continues to run in directions OPEN or CLOSE, even if the operation command is cancelled (self-retaining). The actuator is either stopped by the STOP command or if an end position or intermediate position has been reached.

OPEN & CL w/o STOP In directions OPEN and CLOSE = self-retaining without stop:
Direct reversal of the operation direction without STOP command is possible.

6.4 Operation mode EMERGENCY

See also: Failure function <EMERGENCY behaviour>

- Characteristics**
- The indication in the top row of the display shows: **EMERGENCY**
 - The operation mode EMERGENCY is initiated by the EMERGENCY signal.
 - The actuator performs an EMERGENCY operation. For example, the actuator moves to a predefined EMERGENCY position (i.e. end position OPEN or end position CLOSED).
 - As long as the EMERGENCY signal is present, the actuator does not respond to any other operation commands (EMERGENCY signal has top priority).



The actuator can start immediately when switching on!

Risk of personal injuries or damage to the valve.

- Ensure that the EMERGENCY signal is present when switching on.
- Should the actuator start unexpectedly: Immediately set selector switch to position **0** (OFF).

6.5 Operation mode EMERGENCY stop

— Option —

See also: Failure function <EMERGENCY stop function>

Condition EMERGENCY Stop switch (via AUMA electrical connection)

- Characteristics**
- The indication in the top row of the display shows: **EMCY stop**
 - In an emergency, the EMERGENCY stop button can be used to interrupt the power supply of the motor controls (contactors or thyristors).
 - Operation mode EMERGENCY stop supersedes all other operation modes.
 - A new operation command can only be executed once the pressed EMERGENCY stop button is released and the operation mode EMERGENCY stop is cleared using a Reset command.
 - Analogue operation commands (e.g. 0/4 – 20 mA) or operation commands via fieldbus are immediately executed again.

6.6 Operation mode Disabled

See also: Application function <Local controls:enable>

- Characteristics**
- The indication in the top row of the display shows: **Disabled**
 - The operation via the push buttons on the local controls is disabled.
 - Operation mode **Disabled** is possible in selector switch positions LOCAL and OFF.

Table 4: Functions depending on the selector switch position:

Selector switch is in position	Function during indication = Disabled
Local control (LOCAL)	Actuator cannot be operated locally
0 (OFF)	Local menu operation not possible

- For control via fieldbus interface, the fieldbus disables or enables the operation.

6.7 Operation mode Service

Conditions: Set selector switch = position **Local control** (LOCAL) or **Remote control** (REMOTE).
Display indicates in the first row: **Service**

- Characteristics**
- The indication in the top row of the display shows: **Service**
 - For operation mode service, a PC or laptop with the ToolSuite service software is required. AUMA service uses this software (e.g. during commissioning or maintenance) to perform settings at the AUMATIC.

Information In selector position **Local control** (LOCAL), press any push button to exit the service operation mode and to activate operation mode local.

7. Basic settings for commissioning

Definition Basic settings such as type of seating, torque and limit switching are required for safe commissioning of the AUMATIC together with the actuator. Basic settings for display, such as date and time or display formats, can be changed, if required.

7.1 Type of seating for end positions


- Function**
- Selection of the type of seating (according to valve manufacturer's specifications)
 - Limit seating in end position
 - Torque seating in end position
 - For end positions OPEN and CLOSE, the following can be set individually:

Limit seating

The controls switch off the actuator in the end positions (OPEN/CLOSED) set via limit switching.

For end position seating via limit switching, you have to account for the overrun of the actuator. Overrun [1] is the travel from switching off until complete standstill. The overrun depends on the inertia of both the actuator and the valve and the delay time of the controls.

Figure 43: Limit seating



P Tripping position
[1] Overrun

Torque seating

The controls switch off the actuator in the end positions via torque switching.

For this the torque switching has to be set to the tripping torque specified by the valve manufacturer. When reaching the end position, the torque increases within the valve seat. As soon as the set tripping torque is reached, the controls automatically switch off the actuator.

In this context, the limit seating is used to signal that the limit switching will trip shortly **before** reaching the end position.

7.1.1 Type of seating: set

NOTICE

Valve damage due to incorrect setting!

- The type of seating must suit the valve.
- Only change the setting with prior consent of the valve manufacturer.

M ▷

Customer settings M0041

Type of seating M0012

End position CLOSED M0086


End position OPEN M0087

Default value: Limit

Setting values:

Limit Seating in end positions via limit switching.

Torque Seating in end positions via torque switching.

- Select main menu** 1. Set selector switch to position **0** (OFF).
- 
2. Press push button **C Setup** and hold it down for approx. 3 seconds.
 ➔ Display goes to main menu and indicates: ▶ **Display...**
- Select parameter** 3. Select parameter either:
 → click via the menu **M ▶** to parameter, or
 → via direct display: press **▲** and enter ID **M0086** or **M0087**
 ➔ Display indicates: **End position CLOSED**
- CLOSE or OPEN** 4. Use **▲▼ Up ▲ Down ▼** to select:
 → ▶ **End position CLOSED**
 → ▶ **End position OPEN**
 ➔ The black triangle ▶ indicates the current selection.
 5. Press **↵ Ok**.
 ➔ Display indicates the current setting: **Limit** or **Torque**
 ➔ The bottom row of the display indicates either:
 - **Edit** → continue with step 6
 - **Save** → continue with step 10
 6. Press **↵ Edit**.
 ➔ Display indicates: ▶ **Specialist (4)**
- Log on user** 7. Use **▲▼ Up ▲ Down ▼** to select user:
Information: Required user level: **Specialist (4)** or higher
 ➔ The symbols have the following meaning:
 - black triangle: ▶ = current setting
 - white triangle: ▷ = selection (not saved yet)
 8. Press **↵ Ok**.
 ➔ Display indicates: **Password 0*****
 9. Enter password (→ enter password).
 ➔ The screen indicates the pre-set type of seating (▶ **Limit** or ▶ **Torque**) by means of a black triangle ▶.
- Change settings** 10. Select new setting **▲▼ Up ▲ Down ▼** resulting in the following significations:
 ➔ The symbols have the following meaning:
 - black triangle: ▶ = current setting
 - white triangle: ▷ = selection (not saved yet)
 11. Confirm selection via **↵ Save**.
 ➔ The setting for the type of seating is complete.
 12. Back to step 4 (CLOSED or OPEN): Press **↵ Esc**.

7.2 Torque switching

- Conditions** MWG in actuator (Non-intrusive version).
 For torque switches in the actuator (Intrusive version), the torque switching is set as described in the operation instructions.
- Function**
- Overload protection across full travel
 - Tripping in end positions (for torque seating)
 - Tripping in during manual operation also possible

- Indication or setting either in percent %, Newton metre Nm or in pounds per foot Lbs/ft.

Read more: <Torque monitoring> chapter

7.2.1 Torque switching: set

Once the set torque is reached, the torque switches will be tripped (overload protection of the valve).

Information The torque switches may also trip during manual operation.

NOTICE

Valve damage due to excessive tripping torque limit setting!


- The tripping torque must suit the valve.
- Only change the setting with the consent of the valve manufacturer.

M ▶ Customer settings M0041
Torque switching M0013
Trip torque CLOSE M0088
Trip torque OPEN M0089

Default value: According to order data

Setting range: Torque range according to actuator name plate

Select main menu 1. Set selector switch to position 0 (OFF).



2. Press push button **C Setup** and hold it down for approx. 3 seconds.
→ Display goes to main menu and indicates: ▶ Display...

Select parameter 3. Select parameter either:

- click via the menu **M ▶** to parameter, or
- via direct display: press ▲ and enter ID M0088.

→ Display indicates: Trip torque CLOSE

CLOSE or OPEN

4. Select via ▲▼ Up ▲ Down ▼:

- ▶ Trip torque CLOSE
- ▶ Trip torque OPEN

→ The black triangle ▶ indicates the current selection.

5. Press ↵ Ok.

→ Display shows the set value.

→ The bottom row indicates: Edit Esc

6. Press ↵ Edit.

→ Display indicates:

- Specialist (4) → continue with step 7
- in bottom row Up ▲ Down ▼ Esc → continue with step 11

Log on user 7. Use ▲▼ Up ▲ Down ▼ to select user:

Information: Required user level: Specialist (4) or higher

→ The symbols have the following meanings:

- black triangle: ▶ = current setting
- white triangle: ▷ = selection (not saved yet)

8. Press ↵ Ok.

→ Display indicates: Password 0***

9. Enter password (→ enter password).
 ➔ Display shows the set value.
 ➔ The bottom row indicates: **Edit Esc**
- Change value** 10. Press **↵ Edit**.
 11. Enter new value for tripping torque via **▲ ▼ Up ▲ Down ▼**.
Information: The adjustable torque range is shown in round brackets
 12. Save new value via **↵ Save**.
 ➔ The tripping torque is set.
 13. Back to step 4 (CLOSED or OPEN): Press **↵ Esc**.
- Information** The following fault signals are sent if the set torque is reached **in mid-travel**:
- Status indication **S0007 Fault = Torque fault OPEN** or **Torque fault CLOSE**
- The fault has to be acknowledged before the operation can be resumed. The acknowledgement is made:
1. either by an operation command in the opposite direction.
 - For **Torque fault OPEN**: Operation command in direction OPEN
 - For **Torque fault CLOSE**: Operation command in direction CLOSE
 2. or, in case the torque applied is lower than the preset tripping torque:
 - via the push button **RESET** in selector switch position **Local control** (LOCAL).
 - or via the Profibus, command reset (process representation output: byte 1, bit 3).

7.3 Limit switching

- Conditions** MWG in actuator (Non-intrusive version).
 For torque switches in the actuator (Intrusive version), the limit switching is set as described in the operation instructions.
- Functions**
- Tripping in end positions (limit seating)
 - Signalling the end positions (torque seating)

7.3.1 Limit switching: set


NOTICE

Valve damage at valve/gearbox due to incorrect setting!

- When setting with motor operation: Stop actuator **before** reaching end of travel (press push button **STOP**).
- Allow for overrun when selecting limit seating.


M ▶ Customer settings **M0041**
 Limit switching **M0010**
 Set end pos. CLOSED? **M0084**
 Set end pos. OPEN? **M0085**

- Select main menu** 1. Set selector switch to position **0** (OFF).





2. Press push button **C** and hold it down for approx. 3 seconds.
 ➔ Display goes to main menu and indicates: ▶ **Display...**

- | | |
|--|--|
| Select parameter | <p>3. Select parameter either:</p> <ul style="list-style-type: none"> → click via the menu M ▶ to parameter, or → via direct display: press ▲ and enter ID M0084. <p>➔ Display indicates: Set end pos.CLOSED?</p> |
| CLOSED or OPEN | <p>4. Use ▲ ▼ Up ▲ Down ▼ to select:</p> <ul style="list-style-type: none"> → ▶ Set end pos.CLOSED? M0084 → ▶ Set end pos. OPEN? M0085 <p>➔ The black triangle ▶ indicates the current selection.</p> <p>5. Press ↵ Ok.</p> <p>➔ The display indicates either:</p> <ul style="list-style-type: none"> - Set end pos.CLOSED? CMD0009 → continue with step 9 - Set end pos. OPEN? CMD0010 → continue with step 14 - Specialist (4) → continue with step 6 |
| Log on user | <p>6. Use ▲ ▼ Up ▲ Down ▼ to select a user:</p> <p>Information: Required user level: Specialist (4) or higher</p> <p>➔ The symbols have the following meaning:</p> <ul style="list-style-type: none"> - black triangle: ▶ = current setting - white triangle: ▷ = selection (not saved yet) <p>7. Press ↵ Ok to confirm selected user level.</p> <p>➔ Display indicates: Password 0***</p> <p>8. Enter password (→ enter password).</p> <p>➔ The display indicates either:</p> <ul style="list-style-type: none"> - Set end pos.CLOSED? CMD0009 → continue with step 9 - Set end pos. OPEN? CMD0010 → continue with step 14 |
| Set end position CLOSED CMD0009 | <p>9. Re-set end position CLOSED:</p> <p>9.1 For large strokes: Set selector switch in position Local control (LOCAL) and operate actuator in motor operation via push button I (CLOSED) in direction of the end position.</p> <p>Information: Stop actuator before reaching end of travel (press push button STOP) to avoid damage.</p> <p>9.2 Engage manual operation.</p> <p>9.3 Turn handwheel until valve is closed.</p> <p>9.4 Turn back the handwheel by an amount equal to the overrun.</p> <p>9.5 Set selector switch to position 0 (OFF).</p> <p>➔ Display indicates: Set end pos.CLOSED? Yes No</p> <p>10. Press ↵ Yes to accept new end position setting.</p> <p>➔ Display indicates: End pos. CLOSED set!</p> <p>➔ The left LED is illuminated (standard version) and thus indicates that the end position CLOSED setting is complete.</p> |



Set end position OPEN
CMD0010

11. Make selection:
 - **Edit** → back to step 9: Set end position CLOSED "once again"
 - **Esc** → back to step 4; either set end position OPEN or exit the menu.
12. Re-set end position OPEN:
 - 12.1 For large strokes: Set selector switch in position **Local control** (LOCAL) and operate actuator in motor operation via push button  (OPEN) in direction of the end position.
Information: Stop actuator **before** reaching end of travel (press push button **STOP**) to avoid damage.
 - 12.2 Engage manual operation.
 - 12.3 Turn handwheel until valve is open.
 - 12.4 Turn back the handwheel by an amount equal to the overrun.
 - 12.5 Set selector switch to position **0** (OFF).
 - ➔ Display indicates: **Set end pos. OPEN? Yes No**
13. Press **Yes** to accept new end position setting.
 - ➔ Display indicates: **End pos. OPEN set!**
 - ➔ The right LED is illuminated (standard version) and thus indicates that the end position setting is complete.



14. Make selection:
 - **Edit** → back to step 9: Set end position OPEN "once again"
 - **Esc** → back to step 4; either set end position CLOSED or exit the menu.

Information If an end position cannot be set: Check the type of control unit in actuator.

7.4 Date and time

After commissioning, we recommend checking and setting date and time. Date and time are required for the event report function.

In case of a mains failure, date and time are stored. This data will only have to be checked after a longer downtime.

M ▶ **Display...** M0009
Date and time M0221

- Information**
- The date format, e.g. day/month/year, can be changed via the parameter **Date format** M0310.
 - The time format, e.g. 12/24h can be changed via the parameter **Time format** M0050.
 - For Profibus DP-V2 control, data and time can be synchronised using the fieldbus.

7.5 Display formats

The indications on the display can be represented in different formats: Country-specific spellings, for example, can be accounted for.

7.5.1 Date format

The data can be represented in day/month/year or in year/month/day.

M ▶ **Display...** M0009
Date format M0310
Default value: DD.MM.YYYY

Setting values:

MM/DD/YYYY	Indication in: Month/day/year, example: 01/21/2009
DD.MM.YYYY	Indication in: Day/month/year, example: 21.01.2009
YYYY-MM-DD	Indication in: Year/month/day, example: 2009-01-21

7.5.2 Time format

The time can be indicated in 12 or 24 hour format.

M ▷ Display... M0009
Time format M0050

Default value: 24h

Setting values:

12h	Indication of hour/minute/second in 12-hour format, example: 02:25:09 PM
24h	Indication of hour/minute/second in 24-hour format, example: 14:25:09

7.5.3 Number format

The number format determines the sign for indicating the decimal places. Either a decimal point or a decimal comma can be used to separate integral numbers and decimal places.

M ▷ Display... M0009
Number format M0231

Default values:

- For English as display language = xx.x
- For all other display languages = xx,x

Setting values:

xx.x	Indication of the decimal places using a decimal point, example: 20.0 mA
xx,x	Indication of the decimal places using a decimal comma, example: 20,0 mA

7.5.4 Torque unit

The torque can be indicated in different units.

M ▷ Display... M0009
Torque unit M0051

Default value: Nm

Setting values:

Nm	Indication in Nm
Lbs/ft.	Indication in pounds per foot
%	Indication in percent

7.5.5 Temperature unit

The temperature unit can either be displayed in Celsius [C°] or Fahrenheit [°F].

M ▷ Display... M0009
Temperature unit M0052

Default value: °C

Setting range: °C or °F

7.6 Contrast

The contrast can be used to adapt the display backlight (light or dark background).

M ▷ Display... M0009
Contrast M0230

8. Application functions

Definition Application functions are functions used to adapt the AC to special applications. This includes device functions, communication functions and device information.

If they are enabled, these functions can be programmed by the user for his/her specific task using parameters.

8.1 Intermediate positions (pivot points)

— Option —

Conditions The actuator is equipped with a position transmitter.

- Characteristics**
- With the AC, up to 8 intermediate positions (pivot points) can be set to any value between 0 % and 100 % of the travel.
 - Each intermediate position can be activated or deactivated individually.
 - When reaching an intermediate position, a signal can be generated.
 - A hysteresis can be defined for each pivot point.

8.1.1 Intermediate positions (pivot points): determine

Each intermediate position can be set to a value between 0 and 100 % of the travel.

M ▷ **Customer settings** M0041
Intermediate positions M0143
Pivot points M0160
Pivot point 1 M0249

Default values: 0.0 % for all 8 intermediate positions

Setting range: 0.0 % to 100.0 % of the travel (from OPEN to CLOSED)

Information The pivot points are also valid for the functions <Operation profile> and <Operation to position>.

8.1.2 Signal behaviour of intermediate positions: set

Reaching a pivot point (intermediate position) can be signalled:

- via bus (see separate instructions)
- via indication lights (LEDs) of the local controls or
- via output contacts

The signal behaviour of the different pivot points may be set individually.

M ▷ **Customer settings** M041
Intermediate positions M0143
Signal behaviour M0266
Signal behaviour 1 M0269

Default value: No signal

Setting values:

No signal

A: Signal behaviour Off. Intermediate position is not signalled.

C ☐ ☐ O

B: Signal is active from reaching the intermediate position to end position OPEN.


C ☐ ☐ O

C: Signal active from end position CLOSED to reaching the intermediate position.

C ☐ ☐ O

D: When passing the intermediate position, a pulse signal is sent. The pulse range (range +/- around the pivot point) depends on the set hysteresis.

Figure 49: Signal behaviour of intermediate positions




8.1.3 Hysteresis for intermediate positions: set

The hysteresis determines the tripping point.

Example Parameter **Pivot point 6 M0253** is set to 50.0 % of the travel.
Parameter **Hysteresis 6 M0253** is set to 1.0 % of the travel.

Figure 50: Switching behaviour for signalling behaviours B, C, D and hysteresis 1 %



P1 Switch-on point (●)

P2 Tripping point (○)

Required user level: AUMA (6).

M ▶ **Customer settings M041**
Intermediate positions M0143
Hysteresis M0267
Hysteresis 1 M0277

Default values: 0.5 % for all 8 positions

Setting range: 0.0 % to 5.0 % of the travel (from OPEN to CLOSED)

8.2 Operation profile (operation behaviour) for intermediate positions

— Option —

Conditions Function <Positioner>, parameter **Positioner M0158** = **Function active** (Required user level: **Specialist (4)** or higher)

- Characteristics** The function <Operation profile> can be used to define the operation behaviour of the actuator when reaching an end position. Example: The actuator stops and only continues its operation after another operation command.
- This function is required in special applications to avoid water hammer, possibly also in combination with the timer.

8.2.1 Operation profile: activate

Required user level: **Specialist (4)** or higher.

- M ▶** **Device configuration** **M0053**
Application functions **M0178**
Activation **M0212**
Operation profile **M0294**

Default value: Function not active

Setting values:

- Function not active** Function <Operation profile> deactivated.
Function active Function <Operation profile> activated.

8.2.2 Off times for intermediate positions (pivot points): set

When reaching an intermediate position, the operation behaviour of the actuator may be set.

- M ▶** **Customer settings** **M0041**
Intermediate positions **M0143**
Operation behaviour **M0257**
Operation behaviour 1 **M0258**

Default value: Off

Setting values:

- Off** No intermediate stop, actuator continues the operation.

- Stop in OPEN**
- Actuator stops at pivot point during operation in direction OPEN.
 - The operation command has to be cleared by means of the STOP command and a new operation command has to be sent to resume operation.
 - This function is not active in the operation mode Remote SETPOINT.
- Stop in CLOSED**
- Actuator stops at pivot point during operation in direction CLOSE.
 - The operation command has to be cleared by means of the STOP command and a new operation command has to be sent to resume operation.
 - This function is not active in the operation mode Remote SETPOINT.
- Stop in OPEN & CL.**
- Actuator stops automatically upon reaching the pivot point.
 - The operation command has to be cleared by means of the STOP command and a new operation command has to be sent to resume operation.
 - This function is not active in the operation mode Remote SETPOINT.

- Off time in OPEN** Actuator stops at pivot point during operation in direction OPEN. If an operation command in direction OPEN is present at the end of the pause time, the actuator resumes operation into direction OPEN. If an operation command in direction CLOSE is present during the pause time, the pause is interrupted and operation into direction CLOSE resumed.

- Off time in CLOSED** When reaching the pivot point, the actuator stops during operation in direction CLOSE. If an operation command in direction CLOSE is present at the end of the pause time, the actuator resumes operation into direction CLOSE. If an operation command in direction OPEN is present during the pause time, the pause is interrupted and operation into direction OPEN resumed.

- Off time in OPEN & CL.** Actuator stops automatically upon reaching the pivot point. If an operation command in direction OPEN or CLOSE is present at the end of the pause time, the actuator resumes operation depending on the operation command.

Information The actuator stops for each activated intermediate position, for which operation behaviour **Stop in OPEN**, **Stop in CLOSED** or **Stop in OPEN & CL** is assigned.

8.2.3 Off times for intermediate positions (pivot points): set

An off time can be defined for each pivot point.

Once a pivot point with the operation behaviour **Off time in OPEN**, **Off time in CLOSED** or **Off time in OPEN & CL** is reached, the AC generates the **Operation pause active** indication during the off time.

Required user level: **Specialist (4)** or higher.

M ▶ **Customer settings M041**
Intermediate positions M0143
Off times M0268
Off time 1 M0285

Default values: 1 s

Setting ranges: 1 to 1,800 seconds

8.3 Two-wire control

— Option —

Conditions • <Additional inputs> or additional <parallel interface>
 • Operation mode **Remote** (Selector switch = position **Remote control**).

Characteristics With the function <Two-wire control>, the actuator can be operated to end position OPEN or CLOSED via a digital input.

Information In this function, the actuator only reacts to commands via the input **OPEN/CLOSE**. Other inputs to which operation commands OPEN, STOP, CLOSE were assigned do not have any function.

Execute operation commands via digital input:

Designation of digital input **OPEN/CLOSE**

(wiring diagram designation: OPEN/CLOSE)

Default setting • Input **OPEN/CLOSE** = **low level** (0 V DC or input open):
 Actuator runs in direction CLOSE.
 • Input **OPEN/CLOSE** = **high level** (Standard: +24 V DC):
 Actuator runs in direction OPEN.

Configuration of digital input

For two-wire control, a digital input for the signal **OPEN/CLOSE** has to be available and configured.

Required user level: **AUMA (6)**

M ▶ **Device configuration M0053**
I/O interface M0139
Digital inputs M0116

Example Use input DIN 5 for signal **OPEN/CLOSE**:

Parameter: Signal DIN 5 M0122 = OPEN/CLOSE

Information The logic for the digital inputs may be inverted. Depending on the parameter setting (e.g. **Coding DIN 6 M0128**), the input is either **High active** or **Low active**. Default setting is **High active**.

8.4 Positioner (operation mode Remote SETPOINT)

Conditions This function requires one of the following equipments within the actuator:

	<ul style="list-style-type: none"> Electronic control unit with MWG (Non-Intrusive version) Potentiometer Electronic position transmitter RWG <p>Further conditions for the positioner operation mode:</p> <ul style="list-style-type: none"> Positioner enabled and activated. Operation mode Remote (selector switch = position Remote control).
Characteristics	The positioner records setpoint position E1 and actual position value E2 for comparison. Depending on the detected deviation, the actuator motor then runs in direction OPEN or CLOSE.
Information	<ul style="list-style-type: none"> If the actuator is controlled via a setpoint (e.g. 0 – 20 mA), the status indication S0003 on the display shows both the setpoint position E1 and the actual position value E2. If the status indication S0003 only shows the actual position value E2, OPEN - CLOSE control is active: there is no setpoint control via the positioner. In this case, you have to change-over to setpoint control first, refer to <Change-over between OPEN - CLOSE control and setpoint control> chapter.

8.4.1 Positioner: activate

Required user level: **Specialist (4)** or higher.

M ▶ **Device configuration** M0053
Application functions M0178
Activation M0212
Positioner M0158

Default value: Function not active

Setting values:

Function not active Function <Positioner> deactivated.
Function active Function <Positioner> activated.

8.4.2 Adaptive behaviour: switch on or off

Adaptive positioning may reduce the number of starts and compensate for the overrun of the actuator.

M ▶ **Customer settings** M0041
Positioner M0145
Adaptive behaviour M0147

Default value: Adaptive I

Setting values:


Off Adaptive behaviour switched off.
Adaptive I Adaptive behaviour for precise positioning (high positioning accuracy).

Due to the inertia of actuator and valve, the valve position changes only slightly after switching off the actuator (overrun). The positioner determines the resulting error between setpoint and actual value for both directions and automatically adapts the inner dead bands X_i and therefore switching point P2.

On the basis of the determined inner dead bands X_i and the set hysteresis (parameters **Positioner hyst. OPEN** M0598 or **Positioner hyst. CLOSE** M0599), the outer dead bands X_T are automatically determined.

This reduces the error caused by the overrun after only a few operations and a high positioning accuracy is achieved.

Figure 51: Positioner positioning behaviour



- E1 Setpoint
- E2 Actual value
- P1 Switch-on point
- P2 Switch-off point in OPEN direction
- P3 Setpoint reached
- X_T Max. error (outer dead band)
- X_{i1} Overrun in direction OPEN (inner dead band OPEN)
- X_{i2} Overrun in direction CLOSE (inner dead band CLOSE)

8.4.3 Overrun (inner dead band): set manually

The inner dead band determines the switch-off point of the actuator and therefore influences the overrun.

The inner dead band may be set individually for the directions OPEN and CLOSE.

Manual setting is only possible if the adaptive behaviour, parameter **Adaptive behaviour M0147** is switched off.

- M ▷ **Customer settings M0041**
 - Positioner M0145
 - Dead band OPEN M0234
 - Dead band CLOSE M0235

Default values: 0.5 % for dead band OPEN and CLOSED

Setting ranges: 0.0 – 10.0 % for dead band OPEN and CLOSED

- Information**
- Inner dead bands may not be set wider than outer dead bands.
 - Inner dead bands may not be set too narrow as this may cause unnecessary switching procedures (premature wear) or oscillation of the actuator.

8.4.4 Max. error variable (outer dead band): set manually

The outer dead band determines the switching-on point of the actuator.

The motor starts if the actual value (input signal E2) or a change in nominal value is higher than the max. error variable determined by the outer dead band.

Manual setting is only possible if the adaptive behaviour, parameter **Adaptive behaviour M0147** switched off.

- M ▷ **Customer settings M0041**
 - Positioner M0145
 - Outer dead band M0148

Default value: 1.0 %**Setting range:** 0.1 – 10.0 %**8.4.5 Dead time: set**

The dead time prevents the operation to a new setpoint position within a pre-determined time.

M ▷ Customer settings M0041
 Positioner M0145
 Dead time M0149

Default value: 0.5 s**Setting range:** 0.2 – 60.0 s (seconds)

Information It must be ensured via the controls that the max. permissible number of starts of the actuator is not exceeded. This can be achieved by setting the dead time to a sufficiently high value.

8.4.6 Hysteresis for positioner: set

The hysteresis determines the switching accuracy. It can be used to reduce the number of starts for example.

This setting can only be made if the adaptive behaviour, parameter Adaptive behaviour M0147 is set to Adaptive I.

M ▷ Customer settings M041
 Positioner M0145
 Positioner hyst. OPEN M0598
 Positioner hyst. CLOSE M0599

Default values: 0.5 % for OPEN and CLOSED**Setting range:** 0.0 % to 5.0 % of the travel (from OPEN to CLOSED)**8.4.7 Closing fully/opening fully (end position tolerance for setpoint)**

If the end positions cannot be reached due to inaccurate analogue setpoint signals (0/4 mA or 20 mA), a tolerance for the setpoint within the end position range can be set. If the tolerance is exceeded or not reached, the actuator continues the operation until the full end position has been reached. This ensures that the actuator opens and closes fully.

Information The tolerance ranges are not effective if the operation commands are transferred to the actuator as fieldbus telegrams. In this case the actuator runs completely CLOSED as soon as it receives the nominal value 0.0 % and completely OPEN as soon as it receives the nominal value 100.0 %.

M ▷ Customer settings M0041
 Positioner M0145
 Tolerance CLOSE M0150
 Tolerance OPEN M0151

Default values:

Tolerance CLOSE = 0.0 %

Tolerance OPEN = 100.0 %

Setting ranges: (in percent of the travel)

Tolerance CLOSE = 0.0 – 5.0 %

Tolerance OPEN = 95 – 100.0 %


8.4.8 Limit setting range

Travel can be limited in directions OPEN and/or CLOSE.

This prevents end position(s) OPEN and/or CLOSED from being approached in modulating duty. The actuator stops when reaching the set limit value.

For OPEN - CLOSE control (LOCAL or REMOTE OPEN-CLOSE operation mode), this limitation is not active. The valve can then be run into the end positions either via the local controls or from remote.

Figure 52: Limitation of setting range



[1] Permissible actuator travel for setpoint control

[2] Permissible actuator travel for OPEN - CLOSE control

Activate limitation

M ▷ Customer settings M0041
Positioner M0145
Limit positioner range M0845

Default value: Function not active

Setting values:

Function not active Limitation deactivated.

Function active Limitation activated.

Set limits

M ▷ Customer settings M0041
Positioner M0145
Limit OPEN M0162
Limit CLOSE M0161

Default values:

Limit OPEN = 100.0 %

Limit CLOSE = 0.0 %

Setting ranges: 0.0 ... 100.0 % of travel

8.4.9 Change-over between OPEN - CLOSE control and setpoint control

For actuators equipped with a positioner, it is possible to select between **open-close control** (Remote OPEN-CLOSE) and **setpoint control** (Remote SETPOINT).

Change-over via fieldbus command:

For control via fieldbus interface, the change-over is done via fieldbus command **Fieldbus SETPOINT**.

Switching behaviour:

- **Fieldbus SETPOINT** = 0 = Remote OPEN-CLOSE:
The actuator reacts to operation commands OPEN, STOP, CLOSE
- **Fieldbus SETPOINT** = 1 = Remote SETPOINT:
The actuator reacts to a setpoint signal (e.g. 0.0 ... 100.0 %)

If the operation commands are not transmitted via fieldbus commands, but via <Additional inputs> or additional <Parallel interface>, a digital input for the signal MODE has to be available and configured for change-over.

Configuration of digital input

Required user level: AUMA (6).

M ▶ Device configuration M0053
I/O interface M0139
Digital inputs M0116

Example Use input DIN 1 for change-over:

Parameter: Signal DIN 1 M0118

Setting value: MODE (wiring diagram designation: MODE)

Information The logic for the digital inputs may be inverted. Depending on the parameter setting (e.g. Coding DIN 4 M0126), the input is either High active or Low active. Default setting of input MODE is Low active.

Change-over via digital input MODE

Switching behaviour for coding Low active:

(Default factory setting)

- Input MODE = **low level** (0 V DC or input open) = Remote SETPOINT:
The actuator reacts to a setpoint signal (e.g. 0/4 – 20 mA)
- Input MODE = **high level** (Standard: +24 V DC) = Remote OPEN-CLOSE:
The actuator reacts to operation commands OPEN, STOP, CLOSE.

8.4.10 Input of setpoint position

In Profibus DP version, the setpoint position is transmitted via the fieldbus interface, channel 1 or channel 2.

Configuration (process representation) is defined via the GSD file only.

Information If required, download the GSD file (General Station Description) from the Internet: www.auma.com

AC with two additional inputs

— Option —

The setpoint position can also be fed via an analogue input. In this case, one of the inputs AIN 1 or AIN 2 has to be configured as setpoint position.

Required user level: AUMA (6).

M ▶ Device configuration M0053
I/O interface M0139
Analogue inputs M0389
Signal AIN 1 M0135
Signal AIN 2 M0138

Setting value: Setpoint position

Information The AC will only react to the additional analogue input, if high level (standard: +24 V DC) is available at the I / O INTERFACE input(refer to wiring diagram).

8.4.11 Input range of setpoint position

The input range defines the signal range, i.e the initial and the end value of the setpoint signal. For example: 0 – 20 mA, 4 – 20 mA or another value.

In Profibus DP version, the input range for setpoint position is set to 0.0 % ... 100.0 %.

AC with two additional inputs

— Option —

If the setpoint position is fed via an analogue input, the signal range of the respective input (AIN1 or AIN2) has to be correctly set. The configuration is then made via parameters.

Required user level: **Specialist (4)** or higher.

M ▶ **Device configuration** M0053
I/O interface M0139
Analogue inputs M0389
Low limit AIN 1 M0
High limit AIN 1 M0

Default values:

Low limit AIN 1 = 0 mA

High limit AIN 1 = 20 mA

Setting values: 0 ... 20 mA

8.5 Process controller

— Option —

Requirements This function requires one of the following equipments within the actuator:

- Electronic control unit with MWG (non-intrusive version)
- Potentiometer
- Electronic position transmitter RWG


Further conditions for the process controller operation mode:

- Process controller enabled and activated.
- Operation mode **Remote** (Selector switch = position **Remote control**).

Characteristics The following figure illustrates the function of the process controller:

The process controller [2] receives the process setpoint E1 and the actual process value E4 (e.g. from a sensor). On the basis of both values, the process controller calculates the position setpoint E7 for positioner [3]. In turn, the positioner [3] compares this target setpoint with the position feedback E2 of the valve and issues the operation commands (OPEN - CLOSE) for the actuator.

Figure 53: Process controller function



- [1] Actuator controls AUMATIC
- [2] Process controller
- [3] Positioner
- [4] Actuator
- [5] Positioner e.g. RWG/MWG
- [6] Sensor
- [7] Valve
- E1 Process setpoint
- E2 Actual position value
- E4 Actual process value
- E7 Position setpoint (internal)

Application The process controller can be used to control pressure, flow or flow rates, flow levels and temperature.

8.5.1 Process controller activation

Required user level: **Specialist (4)** or higher.

M ▶ **Device configuration** M0053
Application functions M0178
Activation M0212
Process controller M0741

Default value: Function not active

Setting values:

Function not active <Process controller> function deactivated.

Function active <Process controller> function activated.

8.5.2 Process controller: set modulating behaviour

Three controller types are available to ideally adapt the modulating behaviour of the process controller to the respective application.


M ▶ Customer settings M0041
Process controller M0742
Modulating behaviour M0887

Default value: PI controller

Setting values:

P controller P controller immediately reacts to a control deviation (i.e. actively) and amplifies the input signal (error variable) proportionally to the set amplification. Setting parameter: Proport. gain K_p M0744


Figure 54: Step response of P controller



P controller application For uncritical closed-loop applications allowing to accept continuous error variables in the event of failures, e.g. pressure, flow, filling level and temperature control.

PI controller PI controllers consist of a P fraction immediately reacting to a control deviation and an I fraction for chronological integration of the input signal (error variable). Due to the additional time constant of the I fraction, the output value takes more time to reach the target status (i.e. inertia of control loop response) whereas positioning accuracy increases at the same time (lower control deviation). Parameters for setting the time constant: Reset time T_i M0745


Figure 55: Step response of PI controller



PI controller application Quick control circuits not allowing continuous error variables, e.g. pressure, temperature and ratio control.

PID controller Compared to the PI controller, the PID controller has an additional D fraction accounting for changes in the error variable (change rate). The D fraction quickly reacts to changes, even to minor control deviations with large output values. Parameter for setting the D fraction: Rate time T_d M0746

Figure 56: Step response of PID controller



PID controller use For precise and highly dynamic control not allowing a continuous error variable.

8.5.3 Setpoint source (input for process setpoint)

M ▶ Customer settings M0041
Process controller M0742

Setpoint source M0743**Default value:** I/O interface**Setting values:****I/O interface** The process setpoint is defined via an analogue input (AIN 1 or AIN 2) of the I/O interface.**Fieldbus interface** The process setpoint is defined via fieldbus.**Internal setpoint** The process setpoint is generated internally via actuator controls: parameters **Internal setpoint 1** M0749 / **Internal setpoint 2** M0750**Information** To use internal setpoint 2, a digital input must be configured accordingly.**8.5.4 Behaviour on loss of process setpoint****M ▷** **Customer settings** M0041
Process controller M0742
Beh. setpoint failure M0747**Default value:** Internal setpoint 1**Setting values:****Internal setpoint 1** In case of process setpoint signal loss, controls switch to the internal setpoint 1. Parameter **Internal setpoint 1** M0749**Internal setpoint 2** In case of process setpoint signal loss, controls switch to the internal setpoint 2. Parameter **Internal setpoint 2** M0750**Failure behaviour** In case of process setpoint signal loss, failure behaviour procedure is activated. Parameter **Failure behaviour** M0378**8.5.5 Inverse operation**

As standard, the valve is opened by the modulating actuator as soon as the actual process value falls below the process setpoint. Depending on the process, it may, however, be necessary that the valve closes as soon as the actual process value falls below the process setpoint. In this case, the respective parameters are used to set the process controller to inverse operation.

M ▷ **Customer settings** M0041
Process controller M0742
Inverse operation M0748**Default value:** Function not active**Setting values:****Function not active** Inverse operation is deactivated.**Function active** Inverse operation is activated.**8.5.6 Internal process setpoint**

An internal process setpoint may be set with this parameter. The internal process setpoint is used if:

- Parameter **Setpoint source** M0743 is set to **Internal setpoint** or
- Parameter **Beh. setpoint failure** M0747 is set to **Internal setpoint 1** or **Internal setpoint 2**.

M ▷ **Customer settings** M0041
Process controller M0742
Internal setpoint 1 M0749
Internal setpoint 2 M0750**Default value:** 50.0 %**Setting range:** 0.0 ... 100.0 %

8.5.7 Setting procedure

The setting of the process controller largely depends on the area of controller application. A PI controller suffices for most applications.

- Procedure**
1. Operate the controller as P controller, i.e. set the parameters as follows:
 - Proportional gain $K_p = 1$
 - Reset time $T_i = 1,000$ s
 - Rate time $T_d = 0$
 - Derivative gain $K_d = 0$
 2. Double proportional gain K_p until the control loop starts to oscillate.
 3. Reduce proportional gain K_p to 60 % of the set value.
 4. Decrease rate time T_d until the error variable equals zero.

8.5.8 Proportional amplification K_p : set

In the event of an error variable, the P portion immediately (i.e. actively) changes the position value proportionally to the error variable.

If a small error variable already requires a major valve position adjustment, the proportional gain K_p must be increased.

Information If the reaction is too extreme (overshoot), the value must be reduced. If the reaction is too weak, the value must be increased.

M ▶ Customer settings M0041
Process controller M0742
Proport. gain K_p M0744

Default value: 1.0

Setting range: 0.1 ... 10.0

8.5.9 Reset time T_i : set

The reset time determines the I portion of the controller. The more inert a system, the higher this value should be set.

- Information**
- Increase T_i in case of propensity for oscillation.
 - Decrease T_i if the reactions are excessively delayed.
 - Starting value for fast processes (e.g. pressure): 10
 - Starting value for slow processes (e.g. temperature): 1,000

M ▶ Customer settings M0041
Process controller M0742
Reset time T_i M0745

Default value: 1,000 s (seconds)

Setting range: 1 ... 1,000 s

8.5.10 Rate time T_d : set

The rate time determines the D portion of the controller. Typically, no setting is required here ($= 0$), since actuator and valve – due to the operating time – cannot react abruptly to a sudden occurrence of an error variable.

- Information**
- Increase T_d in case of propensity for oscillation.
 - Initial value for actuators: 0

M ▶ Customer settings M0041
Process controller M0742
Rate time T_d M0746

Default value: 0 s (seconds)

Setting range: 1 ... 100 s

8.5.11 Actual value source (input for actual process value)

M▷ Customer settings M0041
Process controller M0742
Actual value source M0756

Default value: I/O interface

Setting values:

I/O interface The actual process value is defined via an analogue input (AIN 1 or AIN 2) of the I/O Interface.

Fieldbus interface The actual process value is defined via fieldbus.

8.6 Stepping mode

— Option —


Conditions This function requires one of the following equipments within the actuator:

- MWG (Non-Intrusive version)
- Potentiometer
- Electronic position transmitter RWG

Characteristics

- With stepping mode, the operating time can be increased for the entire or any portion of the valve travel.
- Stepping mode can be individually activated for the directions OPEN and CLOSE.

Figure 57: Stepping mode



- | | |
|-----|-------------------------------------|
| [1] | Stepping range OPEN |
| [2] | Stepping range CLOSE |
| P1 | Start of stepping mode |
| P2 | End of stepping mode |
| t1 | Operating time for normal operation |
| t2 | Operating time for stepping mode |
| t3 | Running time |
| t4 | Off time |

8.6.1 Stepping mode: activate

Stepping mode can be individually activated for the directions OPEN and CLOSE.
Required user level: **Specialist (4)** or higher.

M ▶ **Device configuration** M0053
 Application functions M0178
 Activation M0212
 Timer CLOSE M0156
 Timer OPEN M0206

Default value: Function not active

Setting values:

Function not active Function <Stepping mode> deactivated.
Function active Function <Stepping mode> activated.

8.6.2 Operation mode for stepping mode

Stepping mode can be activated via operation modes Local and/or Remote.

M ▶ **Customer settings** M0041
 Timer M0142
 Step mode CLOSE M0157
 Step mode OPEN M0207

Default value: Off both directions

Setting values:

Off Stepping mode is switched off.
Remote Stepping mode is active in the operation modes: **Remote**, **Remote II**, **Fieldbus**
Local Stepping mode is active in the operation modes: **Local**, **Service**
Remote and local Stepping mode is active in the operation modes: **Remote**, **Remote II**, **Fieldbus**, **Local**, **Service**

Information The timer cannot be by-passed in <operation mode EMERGENCY>.

8.6.3 Start and end of stepping mode

Start and end of stepping mode can be individually set for both directions.

M ▶ **Customer settings** M0041
 Timer M0142
 End stepping CLOSE M0152
 Start stepping CLOSE M0153
 Start stepping OPEN M0154
 End stepping OPEN M0155

Default values:

End stepping CLOSE = 0.0 %
Start stepping CLOSE = 100.0 %
Start stepping OPEN = 0.0 %
End stepping OPEN = 100.0 %

Setting ranges:

End stepping CLOSE = 0.0 – 99.9 %
Start stepping CLOSE = 0.1 – 100.0 %
Start stepping OPEN = 0.0 – 99.9 %
End stepping OPEN = 0.1 – 100.0 %

8.6.4 On times and off times

On or off times can be set individually for directions OPEN and CLOSE.

- M ▷ **Customer settings** M0041
 Timer M0142
 On time CLOSE M0163
 Off time CLOSE M0164
 On time OPEN M0165
 Off time OPEN M0166

Default values: 5.0 s (for all on and off times)

Setting ranges: 1 ... 1,800 s (for all on and off times)

8.7 Profibus DP interface

8.7.1 Bus address (slave address)

The bus address can be entered manually via push buttons at the local controls according to the description below. For information on how to set the bus address via fieldbus, refer to Manual Device integration Profibus DP.

- M ▷ **Customer settings** M0041
 Profibus DP M0016
 DP1 slave address M0098
 DP2 slave address M0295

Default value: 126

Setting range: 0 ... 126

Information Parameter **DP2 slave address** is only available for some redundancy options.

8.7.2 Redundancy

Redundancy can be entered manually via the push buttons at the local controls according to the description below.

- M ▷ **Device configuration** M0054
 Profibus M0799
 Redundancy M0601

Default value: None

Setting values:

None No redundancy

DP-V2 (SR) DP-V2 (system redundancy)

DP-V2 (FR) DP-V2 (flying redundancy)

AUMA redundancy I Redundant line topology with universal redundancy behaviour according to AUMA redundancy type I

AUMA redundancy II Redundant line topology with universal redundancy behaviour according to AUMA redundancy type II

Information For detailed information on redundancy types, refer to Manual Device integration Profibus.

8.7.3 Response telegrams for AUMA redundancy II

When using AUMA redundancy II, response telegrams can be sent on both channels.

- M ▷ **Device configuration** M0054
 Modbus M0799
 Behaviour Tx M0801

Default value: Tx active channel

Setting values:

Tx active channel Response telegrams are only sent via the active channel.

Tx both channels Response telegrams are sent via both channels, the active and the passive channel.

8.8 Additional bus inputs

— Option —

AC controls with fieldbus interface can be equipped with additional digital and analogue inputs. Depending on the version, up to 6 digital inputs (standard: 24 V DC) and two analogue 0/4 – 20 mA inputs are available.

If additional inputs are available, operation commands can be sent both via fieldbus and the additional inputs.

For manual change-over, a digital input has to be available and configured between fieldbus and parallel interface.

The <Auto change-over I/O (during bus failure)> function is required for automatic change-over (bus failure).

Configuration of additional inputs

Required user level: AUMA (6).

M ▶ **Device configuration M0053**
I/O interface M0139
Digital inputs M0116
Analogue inputs M0389

- Example**
- Use digital inputs DIN 2 to 4 for operation commands:
Signal DIN 2 M0120 = CLOSE
Signal DIN 3 M0119 = OPEN
Signal DIN 4 M0118 = STOP
 - Use digital input DIN 6 for manual change-over:
Signal DIN 6 M0121 = I/O interface (wiring diagram designation: I/O interface)

Information The logic for the digital inputs may be inverted. Depending on the parameter setting (e.g. Coding DIN 6 M0128), the input is either **High active** or **Low active**. Default setting is **High active**.

Manual change-over via I/O interface input

Switching behaviour for coding **High active**

(Default factory setting)

- Input **I/O interface** = **low level** (0 V DC or input open):
The AC only reacts to operation commands via fieldbus.
- Input **I/O interface** = **high level** (standard: +24 V DC):
The AC reacts to additional input signals only.
Irrespective of the signal assignment of the additional inputs, the fieldbus communication with the DCS will remain intact.

8.9 Combination of fieldbus-parallel interface

— Option —

An AC with fieldbus interface may be additionally equipped with a parallel interface. Depending on the version, up to 6 digital inputs (standard: 24 V DC) and up to two analogue 0/4 – 20 mA inputs are available.

For this combined version, operation commands can be executed both via fieldbus and the inputs of the parallel interface (I/O interface).

For manual change-over, a digital input has to be available and configured between fieldbus and parallel interface.

The <Auto change-over I/O (during bus failure)> function is required for automatic change-over (bus failure).

Configuration of I/O interface inputs

A digital input for the I/O interface signal has to be configured for change-over.

Required access level: AUMA (6).

M ▷ Device configuration M0053
I/O interface M0139
Digital inputs M0116
Analogue inputs M0389

- Example**
- Use digital inputs DIN 2 to 4 for operation commands:
Signal DIN 2 M0120 = CLOSE
Signal DIN 3 M0119 = OPEN
Signal DIN 4 M0118 = STOP
 - Use digital input DIN 6 for manual change-over:
Signal DIN 6 (wiring diagram designation: I/O interface)

Information The logic for the digital inputs may be inverted. Depending on the parameter setting (e.g. Coding DIN 6 M0128), the input is either High active or Low active. Default setting is High active.

Manual change-over via I/O interface input**Switching behaviour for coding High active**

(Default factory setting)

- Input I/O interface = **low level** (0 V DC or input open):
The AC only reacts to operation commands via fieldbus.
- Input I/O interface = **high level**
AC reacts to parallel interface signals only:
Irrespective of the signal assignment of the inputs of the parallel interface, the fieldbus communication with the DCS will remain intact.

8.10 Auto change-over I/O (during bus failure)**— Option —**

Requirements The function is only available for a combination of additional bus inputs or parallel interface (I/O) and a fieldbus interface.

Characteristics If this function is activated, automatic change-over to the parallel interface (I/O) will be performed on loss of fieldbus communication.

Change-over is performed before activation of <Failure behaviour> or <EMERGENCY behaviour>.

Auto change-over I/O: activate

Required user level: Specialist (4) or higher.

M ▷ Device configuration M0053
Application functions M0178
Activation M0212
Auto change-over I/O M0790

Default value: Function not active

Setting values:

Function not active <Auto change-over I/O (during bus failure)> function deactivated.

Function active <Auto change-over I/O (during bus failure)> function activated.

8.11 By-pass function**— Option —**

- Application** The by-pass function is used, e.g. for district heating pipelines. Under high pipeline pressure, the gate valve of the main valve cannot be used, pressure compensation via by-pass valve is therefore required.
- Requirements**
- <EMERGENCY behaviour> function is enabled and activated.
 - <Additional inputs> or additional <Parallel interface>.
- Function** Two MOVs – one main valve and a by-pass valve – are linked via release signals **By-pass Sync In** and **By-pass Sync Out**. Operation commands can only be executed if one of the two actuators sends the release signal to the other. Release depends on the end position. This ensures that only the following operation commands may be executed:
- The main valve can only be operated in directions OPEN or CLOSE if the by-pass valve is in end position OPEN.
 - The by-pass valve can only be operated in direction CLOSE if the main valve is in end position CLOSED. However, it can always be operated in direction OPEN.

Figure 58: Function




Table 5: Main valve reaction to by-pass valve position.

By-pass valve		Main valve
Position	Sends enable signal Bypass Sync OUT	Release (available operation commands)
End position OPEN	High level (Default: +24 V DC)	in directions OPEN and CLOSE
other position than end position OPEN	Low level (0 V DC or input open-circuit):	No operation possible ¹⁾

1) In case of an operation command, the "Interlock by-pass" signal is sent (no release).

Table 6: By-pass valve reactions to main valve position

Main valve		By-pass valve
Position	Sends enable signal Bypass Sync OUT	Release (available operation commands)
End position CLOSED	High level (Standard: +24 V DC)	in directions OPEN or CLOSE
Other position than end position CLOSED	Low level (0 V DC or input open-circuit):	in direction OPEN only ¹⁾

- 1) In case of an operation command in direction CLOSE, the "Interlock by-pass" signal is sent (no release).

EMERGENCY behaviour The emergency behaviour of the by-pass function has the same characteristics as the <EMERGENCY behaviour> function with the following differences:

In an EMERGENCY situation, both controls receive the EMERGENCY signal at the same time. This signal starts the EMERGENCY operation specially defined for the by-pass function. (Parameter **EMCY operation M0204** is therefore not available in the <EMERGENCY behaviour> function).

EMERGENCY operation procedure

1. By-pass valve is opened first.
2. Once the by-pass valve is fully opened, the main valve is closed.
3. Once the main valve is fully closed, the by-pass valve is fully opened.

Configuration of digital inputs

Required user level: **AUMA (6)** or higher.

M ▶ **Device configuration M0053**
I/O interface M0139
Digital inputs M0116

Example Use input DIN4 for signal **By-pass Sync In**:
 Use input DIN6 for signal **EMERGENCY**:

Setting values:

- **Signal DIN 5 M0122 = By-pass Sync In**
 (wiring diagram designation: **BYPASS SYNC IN**)
- **Signal DIN 6 M0121 = EMERGENCY**
 (wiring diagram designation: **NOT / EMERGENCY**)

Information The logic for the digital inputs may be inverted. Depending on the parameter setting (e.g. **Coding DIN 6 M0128**), the input is either **High active** or **Low active**. Default setting is **High active**.

Configuration of digital input

Required user level: **Specialist (4)** or higher.

M ▶ **Device configuration M0053**
I/O interface M0139
Digital outputs M0110

Example Use output DOUT6 for signal **By-pass Sync Out**:

Parameter: **Signal DOUT 6 M0111**

Setting value: **By-pass Sync Out** (wiring diagram designation: **BYPASS SYNC OUT**)

8.11.1 Bypass function: activate

Required user level: **Specialist (4)** or higher.

M ▶ **Device configuration M0053**
Application functions M0178
Activation M0212
By-pass function M0941

Default value: **Function not active**

Setting values:

Function not active Bypass function deactivated.

Function active Bypass function activated.

8.11.2 By-pass application: configure

The actuators for the two MOVs (valves) have to be configured according to their application (main or by-pass valve).

M ▶ Customer settings M0041
By-pass function M0942
By-pass application M0943

Default value: Main valve

Setting values:

Main valve	Actuator for main valve.
By-pass valve	Actuator for by-pass valve.

9. Failure functions

Definition Failure functions are started by certain events and lead to a defined action of the controls or the actuator. A failure operation can be started by a manual action (e.g. pressing an EMERGENCY stop button). In general, a failure operation is automatically started by a fault signal from a monitoring function (e.g. loss of signal).

9.1 Reversing time

Application Prevention of impermissible operation states such as: Operation command in direction OPEN, actuator still runs in direction CLOSE due to the delay time.

Characteristics The reversing time (off-time between two operation commands in opposite direction) prevents a restart for a defined interval once the motor has switched off.

Parameters and instructions for setting

Required user level: AUMA (6).

M ▷ **Device configuration** M0053
Switchgear M0173
Revers. prevent. time M0174

Default value: 0.3 s seconds

Setting range: 0.1 ... 30.0 s seconds

9.2 Failure behaviour on loss of signal

Characteristics The failure behaviour can be used to define AC reaction to loss of signal or a defective signal.

Information The failure function can only be set off when the watchdog function is activated within the master.

As soon as the cause for initiating the failure function is eliminated (connection restored, master in Operate state), the operation commands from the master can be executed again at once.

9.2.1 Failure behaviour initiation on loss of signal

Required user level: Specialist (4) or higher.

M ▷ **Customer settings** M0041
Failure behaviour M0378
Failure behaviour M0379

Default value: Good signal first

Setting values:

Good signal first The <Failure behaviour> is only initiated if the monitored signal fails (falling edge).

This setting ensures that if the signal is missing, the actuator will not start when switching on (Good signal first).

Immediately active The <Failure behaviour> is immediately initiated if the monitored signal is missing (is not present).

For the setting Immediately active:



The actuator can start immediately when switching on!

Risk of personal injuries or damage to the valve.

→ Ensure that the signal set under parameter **Failure source** M0385 is present when switching on.

→ Should the actuator start unexpectedly: Immediately set selector switch to position **Local control** (LOCAL) or **0** (OFF).

9.2.2 Failure source (failure reason) for a failure operation: set

M ▷ Customer settings M0041
Failure behaviour M0378
Failure source M0385

Default value: Active interface

Setting values:

Fieldbus interface The failure behaviour is initiated in case of bus communication loss.

I/O interface The failure behaviour is initiated in case of loss of setpoints.

The monitoring depends on the preset setpoint range, e.g.:

- Setpoint = 4 – 20 mA, E1 lower than 3.7 mA = loss of signal
- Setpoint = 10 – 20 mA, E1 lower than 9.7 mA = loss of signal

For a setpoint range of 0 – 20 mA, monitoring is not possible.

Active interface The failure behaviour is initiated in case of bus communication loss and/or loss of setpoints/actual values.

Possible failure reasons in case of bus communication loss

- The connection to the master is interrupted.
- The master goes into Clear state and sends:
 - either global control telegrams with the content Clear
 - or data telegrams of the length 0 (FailSafe mode).

9.2.3 Failure operation (reaction of the actuator) on loss of signal

The failure operation determines which action is executed by the actuator once the failure behaviour is initiated.

M ▷ Customer settings M0041
Failure behaviour M0378
Failure operation M0384

Default value: STOP

Setting values:

STOP The actuator stops in the current position.

CLOSE The actuator runs to end position CLOSED.

OPEN The actuator runs to end position OPEN.

Approach position The actuator runs to the predetermined position. Conditions:

- The function <Positioner> is activated.
- Parameter **Failure source** M0385 is set to **I/O interface** (for fieldbus control: **Active interface**)

Execute last CMD The actuator executes the last operation command before it is stopped.

Behaviour depending on the selector switch position:

Once the failure operation is triggered, the defined position is approached. If the actuator is then moved to another position (e.g. by manual operation), it will try to perform the set failure operation while the selector switch is in position **Remote control** (REMOTE).

Information To prevent a new approach to the failure position during handwheel operation, the selector switch must be set to position **Local control** (LOCAL) or **0** (OFF) before operating the handwheel.

9.2.4 Failure position: define

If the failure operation **Approach position** is set, the actuator moves to the failure position indicated here.

Required access level: **Specialist (4)** or higher.

- M ▷ **Customer settings** M0041
Failure behaviour M0378
Failure position M0387

Default value: 50.0 %

Setting range: 0.0 ... 100.0 % (from end position OPEN to CLOSED)

9.2.5 Delay time: set

A failure operation is only performed once the delay time has expired. This prevents a short-term loss of signal, which does not have an effect on the process, from directly starting a failure operation

Required user level: **Specialist (4)** or higher.

- M ▷ **Customer settings** M0041
Failure behaviour M0378
Delay time M0386

Default value: 3.0 s

Setting range: 0.0 ... 1,800.0 s seconds

9.3 EMERGENCY behaviour

Application The EMERGENCY behaviour can be used to determine the actuator behaviour in an emergency.

- Characteristics**
- The function <EMERGENCY behaviour> is initiated by the EMERGENCY signal.
 - The actuator performs a defined EMERGENCY operation. For example, the actuator moves to a predefined EMERGENCY position (i.e. end position OPEN or end position CLOSED).
 - As long as the EMERGENCY signal is present, the actuator does not respond to any other operation commands (EMERGENCY signal has top priority).
 - After initiating the EMERGENCY behaviour, binary operation commands (via digital inputs) may have to be sent again.
 - Analogue operation commands (e.g. 0/4 – 20 mA) or operation commands via fieldbus are immediately executed again.

Perform EMERGENCY operation via fieldbus command

For control via fieldbus interface, the EMERGENCY command is done via fieldbus command **Fieldbus EMCY**.

Switching behaviour:

- **Fieldbus EMCY** = 1 = EMERGENCY behaviour is initiated.
- **Fieldbus EMCY** = 0 = No EMERGENCY operation

If the EMERGENCY command is not to be transmitted via a fieldbus command but using a binary signal, (e.g. + 24 V DC) via <Additional inputs> or via an additional <Parallel interface>, a digital input has to be available and configured.

Configuration of digital input

Required access level: **AUMA (6)**.

- M ▷ **Device configuration** M0053
I/O interface M0139
Digital inputs M0116

Example Use input DIN 4 for signal **EMERGENCY**:

Parameter: Signal DIN 4 M0118

Setting value: **EMERGENCY** (wiring diagram designation: EMERGENCY)

Information The logic for the digital inputs may be inverted. Depending on the parameter setting (e.g. Coding DIN 4 M0126), the input is either **High active** or **Low active**. For safety reasons, the **EMERGENCY** signal input is generally set to **Low active**.

Perform EMERGENCY operation via digital input

Switching behaviour for coding Low active:

- Input **EMERGENCY** = **low level** (0 V DC or input open-circuit)
EMERGENCY operation is initiated.
- Input **EMERGENCY** = **high level** (standard: +24 V DC)
No EMERGENCY operation

9.3.1 EMERGENCY behaviour: activate

Required user level: **Specialist (4)** or higher.

M ▷ **Device configuration** M0053
Application functions M0178
Activation M0212
EMERGENCY behaviour M0589

Default value: **Function not active**

Setting values:

Function not active Function <EMERGENCY behaviour> deactivated.

Function active Function <EMERGENCY behaviour> activated.

For activated EMERGENCY behaviour:



The actuator can start its operation due to an EMERGENCY signal.

Risk of personal injuries or damage to the valve.

- For commissioning and maintenance work: Set selector switch to position **0** (OFF). The motor operation can only be interrupted in this selector switch position.
- Should the actuator start unexpectedly: Immediately set selector switch to position **0** (OFF).

9.3.2 EMERGENCY failure behaviour

Required user level: **Specialist (4)** or higher.

M ▷ **Customer settings** M0041
EMCY behaviour M0198
Failure reaction EMCY M0203

Default value: **Good signal first**

Setting values:

Good signal first The <EMERGENCY behaviour> is initiated as soon as the EMERGENCY signal changes from high to low. Example: In case of a binary EMERGENCY input from +24 V DC to 0 V. This prevents the <EMERGENCY behaviour> from being initiated immediately once the AC is switched on and no EMERGENCY signal is present.

Immediately active The <EMERGENCY behaviour> is initiated by a low level at the EMERGENCY signal. For this setting, the EMERGENCY has to have a high level before switching on the AC; otherwise <EMERGENCY behaviour> is initiated immediately after switching on.

For the setting **Immediately active**:



The actuator can start immediately when switching on!

Risk of personal injuries or damage to the valve.

- Ensure that the EMERGENCY signal is present when switching on.
- Should the actuator start unexpectedly: Immediately set selector switch to position **0** (OFF).

9.3.3 Failure source (failure reason) for an EMERGENCY operation: set

- M ▷ Customer settings M0041
EMCY behaviour M0198
EMCY failure source M0591

Default value: I/O interface

Setting values:

- I/O interface** The EMERGENCY signal is present as binary signal (standard: +24 V DC) at a digital input. If this voltage (i. e. the signal) is no longer present, the EMERGENCY behaviour is initiated.
- Fieldbus interface** The EMERGENCY signal is sent as fieldbus command. If the command is no longer present, the EMERGENCY behaviour is initiated.
- I/O or fieldbus** If the fieldbus command or the binary signal is no longer present, the EMERGENCY behaviour is initiated.
- Active interface** If active interface fails, the EMERGENCY behaviour is initiated; e.g. when changing the command source the failure source for the EMERGENCY signal also fails.

9.3.4 Operation mode for EMERGENCY behaviour

The EMERGENCY behaviour can be activated for the operation modes Remote and/or Local

- M ▷ Customer settings M0041
EMCY behaviour M0198
EMCY operation mode M0202

Default value: Remote only

Setting values:

- Remote only** EMERGENCY behaviour is active in the operation modes: Remote Remote II Fieldbus
- Remote and local** EMERGENCY behaviour is active in the operation modes: Remote, Remote II, Fieldbus, Local, Service

Information In the operation mode Off (selector switch position 0), no emergency operation is performed.

9.3.5 EMERGENCY operation

The EMERGENCY operation determines which action is executed by the actuator once the EMERGENCY behaviour is initiated.

- M ▷ Customer settings
EMCY behaviour
EMCY operation

Default value: STOP

Setting values:

- STOP** The actuator stops in the current position.
- CLOSE** The actuator runs to end position CLOSED.
- OPEN** The actuator runs to end position OPEN.

Approach EMCY pos. The actuator runs to the predetermined position.

9.3.6 EMERGENCY position

If the EMERGENCY operation **Approach EMCY pos.** is set, the actuator moves to the EMERGENCY position entered here.

Required user level: **Specialist (4)** or higher.

M ▶ **Customer settings** M0041
EMCY behaviour M0198
EMCY position M0232

Default value: 0.0 %

Setting range: 0.0 ... 100.0 % (from end position OPEN to CLOSED)

9.3.7 Torque switching: by-pass

If the EMERGENCY signal initiates an EMERGENCY operation, the torque switching can be by-passed during this operation.

Required access level: **Specialist (4)** or higher.

M ▶ **Customer settings** M0041
EMCY behaviour M0198
By-pass torque M0199

Default value: Off

Setting values:

Off No by-pass of the torque switching.

On The signals of the torque switching in the actuator are by-passed

9.3.8 Motor protection: by-pass

If the EMERGENCY signal initiates an EMERGENCY operation, the motor protection can be by-passed during this operation.

Required user level: **Specialist (4)** or higher.

M ▶ **Customer settings** M0041
EMCY behaviour M0198
Thermal by-pass M0200

Default value: Off

Setting values:

Off No by-pass of motor protection.

On The signals of the thermoswitches or the PTC thermistors of the motor winding are by-passed.

Information It is not possible to by-pass the motor protection for actuators with explosion protection.

9.3.9 Stepping mode: by-pass

If the EMERGENCY signal initiates an EMERGENCY operation, the stepping mode can be by-passed during this operation.

Required user level: **Specialist (4)** or higher.

M ▶ **Customer settings** M0041
EMCY behaviour M0198
By-pass timer M0201

Default value: Off

Setting values:

- Off** No by-pass of stepping mode.
- On** Stepping mode is by-passed.

9.3.10 Operation profile: by-pass

If the EMERGENCY signal initiates an EMERGENCY operation, the set operation profile (operation behaviour) can be by-passed during this operation.

Required user level: **Specialist (4)** or higher.

- M ▷** **Customer settings** M0041
 - EMCY behaviour** M0198
 - By-pass operat.profile** M0596

Default value: Off

Setting values:

- Off** No by-pass of operation profile.
- On** The operation profile is by-passed.

9.3.11 Interlock: by-pass

If the Interlock function is activated, you may by-pass this function during EMERGENCY operation to prevent that an enable command must be issued to perform EMERGENCY operation.

Required user level: **Specialist (4)** or higher.

- M ▷** **Customer settings** M0041
 - EMCY behaviour** M0198
 - By-pass Interlock** M0668

Default value: Off

Setting values:

- Off** By-pass mode is deactivated. Interlock function is even active during EMERGENCY operation.
- On** By-pass mode is activated. Interlock function is deactivated during EMERGENCY operation.

9.3.12 Local stop: by-pass

If activated, you may by-pass Local Stop function during an EMERGENCY operation to prevent interruption of EMERGENCY operation by pressing the push button STOP.

Required user level: **Specialist (4)** or higher.

- M ▷** **Customer settings** M0041
 - EMCY behaviour** M0198
 - By-pass Local STOP** M0668

Default value: Off

Setting values:

- Off** By-pass mode is deactivated. Local Stop function is even active during EMERGENCY operation.
- On** By-pass mode is activated. Local Stop function is deactivated during EMERGENCY operation.

9.3.13 Delay time for EMERGENCY operation

An EMERGENCY operation is only performed once the delay time has expired. Consequently, a short-term signal failure will not have an impact on the process and will not immediately initiate an EMERGENCY operation.

Required user level: **Specialist (4)** or higher.

- M ▷** **Customer settings** M0041
 - EMCY behaviour** M0198

Delay time M0804

Default value: 00:01.00 min : s

Setting range: 00:00.0 ... 30:00.0 min : s

9.4 Local controls: enable

— Option —

- Application**
- Protection against unauthorised operation via local controls
 - Protection against unauthorised parameter setting via local controls
- Characteristics** The selector switch functions LOCAL and/or OFF may be enabled or disabled.

Enable/disable local controls via fieldbus command

For control via fieldbus interface, the command for enabling the local controls is done via fieldbus command **Fieldb. enable LOCAL**.

Switching behaviour:

- **Fieldb. enable LOCAL** = 1 = enable:
Operation via local controls enabled
- **Fieldb. enable LOCAL** = 0 = enable:
Operation via local controls disabled

If the operation commands are not transmitted via fieldbus commands, but via <Additional inputs> or additional <Parallel interface>, a digital input has to be available and configured to enable/disable the local controls.

Assignment of digital input

Required user level: AUMA (6).

M ▷ **Device configuration** M0053
I/O interface M0139
Digital inputs M0116

Example Use input DIN 5 for signal **Enable LOCAL**:

Parameter: Signal DIN 5 M0122

Setting value: **Enable LOCAL** (wiring diagram designation: **Enable LOCAL**)

Information The logic for the digital inputs may be inverted. Depending on the parameter setting (e.g. **Coding DIN 5 M0127**), the input is either **High active** or **Low active**. Default setting is **High active**.

Enable/disable local controls via digital input

Switching behaviour for coding High active:

- Input **Enable LOCAL** = **high level** (Standard: +24 V DC):
Operation via local controls enabled
- Input **Enable LOCAL** = **low level** (0 V DC or input open):
Operation via local controls disabled

9.4.1 Enabling function: activate

Required user level: **Specialist (4)** or higher.

M ▷ **Device configuration** M0053
Application functions M0178
Activation M0212
Enable LOCAL M0631

Default value: Function not active

Setting values:

Function not active	Function <Local controls: enable from REMOTE> deactivated.
Function active	Function <Local controls: enable from REMOTE> activated.

9.4.2 Enabling function behaviour

The enable behaviour determines which selector switch functions (LOCAL, OFF) require an additional enable signal.

Required user level: **Specialist (4)** or higher.

M ▶ **Customer settings** M0041
Local controls M0075
Enable LOCAL M0628

Default value: Sel. sw. Local

Setting values:

Sel. sw. Local Disabling or enabling is only effective in operation mode LOCAL (selector switch is in position **Local control**). If there is no enable signal present, local operation via push buttons is disabled and the controls generates the indication: **Disabled**.

Sel. sw. Local + Off Disabling or enabling is effective in operation modes LOCAL and OFF (selector switch positions **Local control** and **0**). If there is no enable signal present, local operation via push buttons is disabled and the controls generates the indication: **Disabled**.

In case the bus fails, the local controls allow no actuator operation via the push buttons, because there is no enable signal present.

9.5 Priority REMOTE**— Option —**

Characteristics A control signal can provide REMOTE control with priority over actuator operation via local controls (irrespective of the selector switch position)
This function uses the same input signal as the <Enabling local controls> function.

Application No changing possibility via selector switch from LOCAL

Priority REMOTE via fieldbus command

For control via fieldbus interface, the Priority REMOTE command is done via fieldbus command **Fieldb. enable LOCAL**.

Switching behaviour:

- **Fieldb. enable LOCAL** = 1 = enable:
Operation via local controls enabled
- **Fieldb. enable LOCAL** = 0 = Priority REMOTE:
Operation via local controls disabled

If the operation commands are not transmitted via fieldbus commands, but via <Additional inputs> or additional <Parallel interface>, a digital input has to be available and configured for the <Priority REMOTE> function.

Assignment of digital input

Required user level: **AUMA (6)**.

M ▶ **Device configuration** M0053
I/O interface M0139
Digital inputs M0116

Example Use input DIN 5 for signal **Enable LOCAL**:

Parameter: Signal DIN 5 M0122

Setting value: **Enable LOCAL** (wiring diagram designation: Enable LOCAL)

Information The logic for the digital inputs may be inverted. Depending on the parameter setting (e.g. Coding DIN 5 M0127), the input is either **High active** or **Low active**. Default setting is **High active**.

Priority REMOTE via digital input

Switching behaviour for coding High active:

- Input **Enable LOCAL** = **high level** (standard: +24 V DC):
Operation via local controls enabled
- Input **Enable LOCAL** = **low level** (0 V DC or input open)
Priority REMOTE: Operation via local controls disabled

9.5.1 Priority REMOTE: activate

Required user level: **Specialist (4)** or higher.

M ▶ **Device configuration** M0053
Application functions M0178
Activation M0212
Priority REMOTE M0770

Default value: Function not active

Setting values:

Function not active <Priority REMOTE> function is deactivated.

Function active <Priority REMOTE> function is activated.

9.5.2 Priority REMOTE behaviour


This function determines which selector switch functions (LOCAL, OFF) require an additional enable signal.


Required user level: **Specialist (4)** or higher.

M ▶ **Customer settings** M0041
Local controls M0075
Priority REMOTE M0773

Default value: Sel. sw. Local

Setting values:

Sel. sw. Local Priority of control from REMOTE is only effective in operation mode LOCAL (selector switch is in position **Local control**). If no enable signal is present, operation via push buttons on the local controls is disabled, the actuator can be controlled from REMOTE and the controls indicate the  symbol in the status line of the display (menu **S0001**).

Sel. sw. Local + Off Priority of control from REMOTE is effective in operation modes LOCAL and OFF (selector switch positions **Local control** and **0**). If no enable signal is present, operation via push buttons on the local controls is disabled, the actuator can be controlled from REMOTE and the controls indicate the  symbol in the status line of the display (menu **S0001**).

9.5.3 Fieldbus auto enable

— Option —

Characteristics Generating an enable signal for the <Priority REMOTE> function in case of fieldbus communication failure

Condition <Priority REMOTE> function.

M ▶ **Customer settings** M0041
Local controls M0075
Fieldbus auto enable M0774

Default value: Sel. sw. Local

Setting values:

- Off** <Fieldbus auto enable> function is deactivated. In case of bus failure, NO enable signal is generated via fieldbus (command **Fieldb. enable LOCAL** = 0). <Priority REMOTE> function is active and operation via local controls disabled.
- On** In case of bus failure, the actuator controls generate the enable signal themselves to be able to operate the actuator locally.

9.6 Interlock (enable operation commands)**— Option —**

- Characteristics**
- An operation command will only be executed if an additional release signal for the operation command is present.
 - Enabling may be activated or deactivated individually for operation commands OPEN and CLOSE.
 - Enabling can be set for the different operation modes.

Enable/disable operation commands via fieldbus command:

For control via fieldbus interface, the command for enabling the local controls is done via fieldbus command **Fieldb. enable OPEN**.

Switching behaviour:

- **Fieldb. enable OPEN** or **Fieldb. enable CLOSE** = 1 = enabled:
Operation command enabled.
- **Fieldb. enable OPEN** or **Fieldb. enable CLOSE** = 0 = disabled:
Operation command disabled.

If the operation commands are not transmitted via fieldbus commands, but via <Additional inputs> or additional <Parallel interface>, a digital input has to be available and configured to enable/disable the local controls.

Configuration of digital input

Required user level: AUMA (6).

- M ▶** **Device configuration** M0053
I/O interface M0139
Digital inputs M0116

Example Use input DIN 5 to enable operation commands in direction CLOSE:

Parameter: Signal DIN 5 M0122

Setting value: Enable CLOSE (wiring diagram designation: Interlock CLOSE)

Information The logic for the digital inputs may be inverted. Depending on the parameter setting (e.g. Coding DIN 5 M0127), the input is either **High active** or **Low active**. Default setting is **High active**.

Enable/disable operation commands via digital input:**Switching- behaviour for coding High active:**

- Input **Enable OPEN** or **Enable CLOSE** = **low level** (0 V DC or input open):
Operation command enabled.
- Input **Enable OPEN** or **Enable CLOSE** = **high level** (standard: +24 V DC):
Operation command disabled,

9.6.1 Interlock: activate

Required user level: Specialist (4) or higher.

- M ▶** **Device configuration** M0053
Application functions M0178
Activation M0212

Interlock M0663

Default value: Function not active

Setting values:

Function not active	Function <Interlock (enable operation commands)> deactivated.
Function active	Function <Interlock (enable operation commands)> activated.

9.6.2 Operation mode Interlock

The additional release signal can be activated for different operation modes.

M ▶ Customer settings M0041

Interlock M0664

Oper. mode Interlock M0665

Default value: Off both directions

Setting values:

Off Interlock ist aus.

Remote Interlock is active in operation modes: Remote Remote II Fieldbus

Local Interlock is active in operation modes: Local, Service

Remote and local Interlock is active in operation modes: Remote, Remote II, Fieldbus, Local, Service

9.6.3 Interlock behaviour (running direction)

The Interlock behaviour determines which selector switch functions (LOCAL, OFF) require an additional enable signal.

Required user level: Specialist (4) or higher.

M ▶ Customer settings M0041

Interlock M0664

Running dir. Interlock M0666

Default value: OPEN and CLOSE

Setting values:

OPEN The release signal is only required for operation commands in direction OPEN.

CLOSE The release signal is only required for operation commands in direction CLOSE.

OPEN and CLOSE The release signal is required for operation commands in directions OPEN and CLOSE.

9.7 Local Stop

— Option —

- Characteristics**
- The function Local Stop can be used to stop an operation from Remote locally with the push button STOP.
 - All operation commands are interrupted.

Information After releasing push button STOP, and operation command which might still be present will become active immediately.

9.7.1 Behaviour

Required user level: Specialist (4) or higher.

M ▶ Customer settings M0041

Local controls M0075

Local STOP M0627

Default value: Off

Setting values:

Off Push button STOP can only interrupt an operation in operation mode **Local** (selector switch = position **Local control**).

Sel.sw.Local + Remote In the operation modes **Local**, **Remote**, **Remote II**, **EMERGENCY** and **Service**, push button STOP interrupts an operation.

Information In operation mode **Disabled**, an interruption is NOT possible.

9.8 EMERGENCY stop function

— Option —

Conditions An EMERGENCY stop button is located on the electrical connection

- Characteristics**
- In an emergency, the EMERGENCY stop button can be used to interrupt the power supply of the motor control (contactors or thyristors). Possibly present operation commands with self-retaining will be reset
 - The indication in the top row of the display shows: **EMCY stop**
- Figure 59: EMERGENCY stop button on the electrical connection



- Information**
- The EMERGENCY stop button is intended for operation in an emergency. For maintenance work, the mains supply of the AC has to be switched off and protected against accidental switching on.
 - The EMERGENCY stop button is not available for the ACExC, but only for the weatherproof versions of the AC.

Operation commands

After having unlocked the EMERGENCY stop button, a possibly active operation command will **NOT** immediately be re-activated, but only respective acknowledgement by the operator. This resets the EMERGENCY stop status.

The acknowledgement is made:

- via the **RESET** push button in selector switch position **Local control** (LOCAL).
- or via fieldbus reset byte 1 bit 3 of output data (for this, the selector switch must be set to **Remote control**).
- via a digital input from Remote. Assignment: **RESET**

9.9 Partial Valve Stroke Test (PVST)

— Option —

Characteristics The Partial Valve Stroke Test (PVST) is used to check the function of both actuator and controls. During this test, the function of the valve is tested by means of partial opening or closing within a defined period of time without interrupting the process. After successful test, controls operate the actuator to its initial position.

- Requirements**
- Position transmitter in the actuator
 - Function <Positioner> activated.

- If the actuator is in safe state (caused by the failure behaviour), the test will not be performed.
- The test can only be performed during OPEN - CLOSE control. It cannot be performed for setpoint control (modulating duty).

Perform PVST via fieldbus command

For control via fieldbus interface, the tests are initiated via the **PVST** command.

Switching behaviour:

- **PVST** = 0 (low active) = no test
- **PVST** = 1 = test is initiated

If the test is not to be transmitted via a fieldbus command but using a binary signal, (e.g. + 24 V DC) via <Additional inputs> or via an additional <Parallel interface>, a digital input has to be available and configured.

Assignment of digital input

Required user level: **AUMA (6)**.

M ▷ **Device configuration** **M0053**
I/O interface **M0139**
Digital inputs **M0116**

Example Use input DIN 5 for **Execute PVST** signal :

Parameter: Signal DIN 4 **M0118**

Setting value: **Execute PVST** (wiring diagram designation: ESD)

Information The logic for the digital inputs may be inverted. Depending on the parameter setting (e.g. **Coding DIN 4 M0126**), the input is either **High active** or **Low active**. For safety reasons, the **Execute PVST** signal input is generally set to **Low active**.

Execute PVST via digital input

Switching behaviour for coding **Low active**:

- Input **Execute PVST** = **low level** (0 V DC or input open)
No test
- Input **Execute PVST** = **high level** (standard: +24 V DC)
Test is initiated

Execute PVST manually via push buttons of local controls

Required user level: **Specialist (4)** or higher.

M ▷ **Device configuration** **M0053**
Service functions **M0222**
Execute PVST **M0850**

The actuator is within the set stepping range. The initial position depends on the settings of the following parameters: **PVST behaviour** **M0853**, **PVST stroke** **M0854**

9.9.1 PVST: activate

Required user level: **Specialist (4)** or higher.

M ▷ **Device configuration** **M0053**
Application functions **M0178**
Activation **M0212**
PVST **M0851**

Default value: Function not active

Setting values:

Function not active <PVST> function deactivated.

Function active <PVST> function activated.

9.9.2 Operation mode for PVST

Required user level: **Specialist (4)** or higher.

M ▷ **Customer settings** **M0041**
PVST **M0852**
PVST operation mode **M0889**

Default value: **Stroke**

Setting values:

Stroke Stroke controlled PVST, based on operation via defined stroke (PVST stroke).

Operating time Operating time controlled PVST, based on operation via defined stroke (PVST stroke).

9.9.3 Behaviour for PVST: define

The test can be performed in direction OPEN or direction CLOSE.

M ▷ **Customer settings** **M0041**
PVST **M0852**
PVST behaviour **M0853**

Default value: **OPEN**

Setting values:

OPEN Testing by operation in direction OPEN.

CLOSE Testing by operation in direction CLOSE.

9.9.4 Partial stroke for PVST: set

Usually, the valve stroke amounts to 10 to 15 %. The amount of the partial stroke depends on process requirements and the required diagnostic coverage rate.

M ▷ **Customer settings** **M0041**
PVST **M0852**
PVST stroke **M0854**

Default value: **10.0 %**

Setting range: **0.0 ... 100.0 %**

9.9.5 PVST monitoring time: set

The actuator remains in the current position, if the test could not be completed within the pre-set time.

M ▷ **Customer settings** **M0041**
PVST **M0852**
PVST monitoring **M0855**

Default value: **01:00.0 min:s** (1 minute)

Setting range: **00:01.0 ... 05:00.0 min:s** (minutes:seconds)

9.9.6 PVST operating time: set

M ▷ **Customer settings** **M0041**
PVST **M0852**
PVST operating time **M0890**

Default value: **20.0 s**

Setting range: **1.0 ... 60.0 s** (seconds)

9.9.7 PVST reverse time: set

Waiting time during PVST prior to returning to initial position.

- M ▷ Customer settings M0041
 - PVST M0852
 - PVST reverse time M0891
- Default value: 20.0 s
- Setting range: 1.0 ... 60.0 s (seconds)

9.9.8 PVST reminder

If this function is active, a signal is generated if no PVST was executed during the reminder period.

Activate reminder

Required user level: Specialist (4) or higher.

- M ▷ Customer settings M0041
 - PVST M0852
 - PVST reminder M0892

Default value: OPEN

Setting values:

- Function not active Reminder not activated.
- Function active Reminder activated.

Set reminder period

- M ▷ Customer settings M0041
 - PVST M0852
 - PVST reminder period M0893

Default value: 0 d

Setting range: 0 ... 65535 d (days)

10. Monitoring functions

Definition The monitoring functions signal a warning or a fault as soon as a certain value is outside the permissible range. Faults generally cause an actuator shutdown.

10.1 Torque monitoring

Torque monitoring has the following functions:

- Valve overload protection against excessive torques (leads to switching off)
- Torque warning before overload protection tripping (only in combination with electronic control unit in the actuator)

Overload protection

Once the overload protection trips (torque exceeds set tripping torque), the actuator is stopped.

The controls generate a fault indication if:

- the excessive torque occurs **between** end positions
- the excessive torque occurs **in** the end positions **and** limit seating is set.

The fault indication is shown in the display

- Status indications: **S0007 Fault** or **S0011 Failure**
 - Details: **Torque fault CLOSE** or **Torque fault OPEN**

The fault has to be acknowledged before the operation can be resumed:

1. either by an operation command in the opposite direction.
 - For **Torque fault CLOSE**: Operation command in direction OPEN
 - For **Torque fault OPEN**: Operation command in direction CLOSE
2. or, in case the torque applied is lower than the preset tripping torque after tripping:
 - via the **RESET** push button in selector switch position **Local control** (LOCAL).
 - or via Profibus command **Fieldbus RESET** (process representation output: byte 1, bit 3).

Depending on the version, tripping torques for overload protection are either set via switches in the actuator or via software parameters in the controls. For the settings, refer to <Torque switching> chapter.

Torque warning

Requirements Actuator with electronic control unit (MWG) .

The torque warning can be used e.g. for self-monitoring or for anticipating maintenance requirements.

M ▶ **Customer settings** **M0041**
Torque switching **M0013**
Wrn torque CLOSE **M0769**
Wrn torque OPEN **M0768**

Default value: 80 %

Setting range: 20 ... 100 % of the set nominal torque

When exceeding the set limit values, the actuator is not stopped, however, the controls generate a warning signal:

- Status indications: **S0005 Warnings** or **S0008 Out of specification**
 - Details: **Torque wrn CLOSE** or **Torque wrn OPEN**

Torque by-pass

By means of the torque by-pass, the torque monitoring is deactivated for a defined (short) time. During this interval, the full actuator torque may be used, for example, to release the actuator from a jammed end position or any other jammed position.

NOTICE

Valve damage due to excessive torque!

→ Only apply torque by-pass with the consent of the valve manufacturer.

M ▷ **Customer settings** M0041
Torque switching M0013
Torque by-pass M0092

Default value: Function not active

Setting values:

Function active The torque by-pass is activated.

Function not active The torque by-pass is deactivated.

Time interval for torque by-pass

During the time interval set here, the torque monitoring is deactivated.

M ▷ **Customer settings** M0041
Torque switching M0013
Torque by-pass [s] M0205

Default value: 0.0 s

Setting range: 0.0 ... 5.0 s seconds

10.2 Motor protection monitoring (thermal monitoring)

In order to protect against overheating and impermissibly high temperatures at the actuator, PTC thermistors or thermoswitches are embedded in the motor winding. The thermoswitch is tripped as soon as the max. permissible winding temperature has been reached.

The actuator is switched off and the following signals are given:

- LED 3 (motor protection tripped) on the local controls is illuminated.
- Status indication: S0007 **Fault** or S0011 **Failure**
- Details: Thermal fault

The motor has to cool down before the operation can be resumed.

Depending on the parameter setting, the fault signal is either automatically reset or the fault signal has to be acknowledged.

The acknowledgement is made:

- via the **RESET** push button in selector switch position **Local control** (LOCAL).
- or via fieldbus, reset command, byte 1 bit 3 of output data (for this, the selector switch must be set to REMOTE).

In addition, the AC cyclically (once per day) checks the motor protection monitoring for its proper function. If this check fails, the controls generate the fault indication:

IE mot. prot. monitor

Motor protection behaviour

Required user level: AUMA (6).

M ▷ **Device configuration** M0053
Actuator M0168
Motor prot. mode M0169

Default values:

Non-explosion-proof actuators = **Auto**

Explosion-proof actuators = **Reset**

Setting values:

Auto Automatic reset after the motor has cooled down.

Not possible for explosion-proof version ACExC 01.2

Reset Manual reset.

The acknowledgement is made:

- via the push button **RESET** in selector switch position LOCAL.
- or via the fieldbus, command reset.

If required the thermal overload relay has to be reset manually. To this end, remove the cover on the back of the AC and operate the Reset button on the thermal overload relay.

10.3 Type of duty monitoring (motor starts and running time)

This function monitors the permissible type of duty (e.g. S2 - 15 min) of the actuator. For this, controls monitor possible excess of

- permissible motor starts (cycles) per hour
- permissible running time (on-time) per hour

If any of these values has been exceeded, the actuator will however not be stopped, but the following warning signals are issued.

- Status indications: **S0005** or **S0008**
- Details: **Wrn on time starts**
- Status indications: **S0005** or **S0008**
- Details: **Wrn on time running**

The warning signals will automatically be cleared if the permissible motor starts per second or the permissible running time per hour are no longer reached.

The operational info logger records the number of excesses (warnings) as well as the number of motor starts and motor running times.

M ▶ Diagnostic **M0022**
Operational info **M0177**
Operational info **M0188**

On time warning 1 M0325 contains total number of all on time warnings.


On time warning 2 M0326 contains maximum duration of on time warning

Example: Due to excess of defined starts/h or defined running time/h, the AC issues in total 4 on time warnings: two for 5 min, once for 10 min, once for 17 min.. Afterwards the operating data counters contain the following values:

On time warning 1 M0325 = 37 min = total of all periods (5+5+10+17 min)

On time warning 2 M0326 = 17 min = longest period

Figure 60: Example



- [1] Running time/h
- [2] Starts/h
- [3] On-time warning

Activate on-time monitoring

Required user level: **Specialist (4)** or higher.

M ▶ Customer settings **M0041**
On time monitoring **M0355**
On time monitoring **M0358**

Default value: Function not active

Function not active	Setting values: Function <On-time monitoring> deactivated.
Function active	Function <On-time monitoring> activated.

Set permissible starts/h

M ▷ Customer settings M0041
On time monitoring M0355
Permissible starts/h M0357

Default value: 1,200

Setting range: 1 ... 1,800 starts/h

Set permissible running time/h

M ▷ Customer settings M0041
Positioner M0145
Perm. running time/h M0356

Default value: 15

Setting range: 10 ... 60 minutes

10.4 Operation time monitoring

This function allows the monitoring of the operating time of the actuator. If the actuator needs longer than the set time to move from end position OPEN to end position CLOSED, a warning is signalled (the actuator is not stopped):

- Status indication S0005 Warnings
- Details: Op. time warning
- Via fieldbus: Bit: Op. time warning

The warning indication is automatically cleared once a new operation command is executed.

When the actuator moves from an intermediate position to an end position, the set monitoring time for the whole stroke is assigned in relation to the remaining stroke/travel.

Activate operation mode

Required access level: Specialist (4) or higher.

M ▷ Customer settings M0041
Oper. time monitoring M0568
Operation mode M0569

Default value: Off

Setting values:

Off	The operating time monitoring is switched off
Manual	The operating time monitoring is switched on. The permissible operation time is set via parameter Perm.op. time, manual M0570.

Set permissible operation time manually

Required user level: Specialist (4) or higher.

M ▷ Customer settings M0041
Oper. time monitoring M0568
Perm.op. time, manual M0570

Default value: 10

Setting range: 0 ... 3,600 seconds (0 seconds to 1 hour)

10.5 Reaction monitoring

The AUMATIC monitors whether the actuator moves after an operation command.

If no reaction is recorded at the output drive of the actuator within a set time, either a warning or a fault signal is generated depending on the setting:

- Status indications: **S0005 Warnings** or **S0008 Out of specification**
- Details: **Wrn no reaction**
- Status indications: **S0007 Fault** or **S0011 Failure**
- Details: **Fault no reaction**

In the event of a fault signal, the fault has to be acknowledged to be able to resume the operation. The acknowledgement is made:

- via the **RESET** push button in selector switch position **Local control (LOCAL)**.
- or via the Profibus command **Fieldbus RESET** (process representation output: byte 1, bit 3).

In case of operation from an intermediate position, reaction monitoring will only be performed if the actuator is equipped with a position feedback.

Activate switching off for reaction time error

Required user level: **Specialist (4)** or higher.

- M ▶** **Customer settings M0041**
 Reaction monitoring M0632
 Wrn controls temp. M0633

Default value: **No cut-off**

Setting values:

No cut-off The reaction monitoring only issues a warning.

Cut-off The reaction monitoring issues a fault signal, the actuator is stopped.

Set reaction time

- M ▶** **Customer settings M0041**
 Reaction monitoring M0632
 Reaction time M0634

Default value: **15**

Setting range: **15 ... 300** seconds (0 seconds to 30 minutes)

10.6 Motion detector**— Option —**

Requirements Position transmitter in the actuator.

Characteristics The motion detector checks whether the actuator moves even without operation command (e.g. in manual operation or if there is no self-retaining).

Controls identify motion if the actuator moves more than the pre-set travel difference within the predefined recording time. Controls signal: **Output drive rotates**

Information Parameters for motion detection have a direct impact on reaction monitoring.

10.6.1 Motion detector: activate

Required user level: **Specialist (4)** or higher.

- M ▶** **Customer settings M0041**
 Motion detector M0676
 Motion detector M0675

Default value: **Function active**

Setting values:

Function not active	Monitoring is deactivated.
Function active	Monitoring is activated.

10.6.2 Detection time dt

Required user level: Specialist (4) or higher.

M ▷	Customer settings	M0041
	Motion detector	M0676
	Detect. time dt	M0677
	Detect. time dt (MWG)	M0681

Setting range:

Detect. time dt for potentiometer/RWG in actuator, setting in %

Detect. time dt (MWG) for MWG in actuator, setting in ms

10.6.3 Travel difference dx

Required user level: Specialist (4) or higher.

M ▷	Customer settings	M0041
	Motion detector	M0676
	Travel diff. dx	M0678
	Travel diff. dx (MWG)	M0679

Setting range:

Travel diff. dx for potentiometer/RWG in actuator

Travel diff. dx (MWG) for MWG in actuator

10.6.4 Delay time

Delay time of the signal: Handwheel oper.

Required user level: Specialist (4) or higher.

M ▷	Customer settings	M0041
	Motion detector	M0676
	Delay time	M0764

Default value: 1.000 s (seconds)

Setting range: 0.001 ... 65.535 s

10.7 Monitoring of electronics power supply

The AUMATIC monitors the following voltages and signals a warning (refer to <Fault signals and warnings> chapter):

- Auxiliary voltage 24 V DC, e.g for supplying the control inputs
- Voltage 24 V AC for controlling the reversing contactors, for thermostats and heater within the actuator and for generating the 115 V AC auxiliary voltage for the customer (option)
- Internal 24 V DC power supply of the electronics components (within the controls and in the actuator)
- External 24 V DC supply of the electronics (option)

10.8 Temperature monitoring

Characteristics If the respective sensors are installed in the devices, the AUMATIC monitors different temperatures.

If certain temperature limits are exceeded or fallen short of, the controls either send a warning or a fault signal.

Conditions:

- For temperature in the control unit of the actuator: additionally MWG (magnetic limit and torque transmitter)

- For motor temperature: additionally temperature sensor (PT 100) in the motor
- For gear housing temperature: additionally temperature sensor (PT 100) in the gearing

Display current device temperatures

Required access level: **Specialist (4)** or higher.

M ▶ **Diagnostic** M0022
Device status M0592
Device temperatures M0524

Indications:

Temp. controls	Indication of current temperature in controls housing
Temp. control unit	Indication of current temperature in control unit of the actuator (actuator housing)
Temp. motor	Indication of current temperature in motor winding For further information refer to <Motor protection monitoring (thermal monitoring)>
Temp. gearbox	Indication of current temperature in actuator gear housing

10.9 Verification of sub-assemblies

Conditions	<ul style="list-style-type: none"> • Actuators of the type range SA 07.2 – SA 16.2/SAR 07.2 – SAR 16.2 • MWG position transmitter in actuator
Characteristics	<p>The controls verify whether sub-assemblies mounted in actuators and controls correspond to the desired version.</p> <p>In case incorrect sub-assemblies are mounted or if sub-assemblies are missing the controls either send a warning or a fault signal.</p> <p>For detailed information on this indication refer to <Fault signals and warnings> chapter.</p>

10.10 Phase failure monitoring

Conditions:	The phase failure monitoring is only valid for connections to 3-phase AC power supplies. For versions with 1-phase AC or DC, phase failure monitoring is not possible.
Characteristics	<p>The AUMATIC monitors phase L2. If phase L2 is missing for a certain time interval, the AUMATIC still can send and receive signals and generates a fault indication. Since the AUMATIC is supplied via phases L1 and L3, the two phases cannot be monitored. In case L1 or L3 fails, the AUMATIC is inoperable and the actuator stops.</p>
Information	<p>In case of phase L2 loss during motor operation, this does not necessarily lead to an immediate standstill of the actuator. The reason is that the rotating motor generates the missing phase itself. This leads, however, to a reduction of the motor output torque. If the torque is sufficient for valve operation, the missing phase L2 is only detected when switching off (e.g. in an end position) and the fault signal Phase fault is generated.</p>

Configuration of the tripping time

Required user level: **Specialist (4)** or higher.

M ▶ **Device configuration** M0053
Phase monitoring M0170
Tripping time M0172

Default value: 10.0 s

Setting range: 1.0 – 300.0 s

Information	Faults in supply voltage (e.g. voltage drops) do not generate a fault signal during the adjustable tripping time.
--------------------	---

10.11 Phase sequence detection and correction of the direction of rotation

- Conditions:** The phase sequence detection is only valid for connections to 3-phase AC power supplies. For versions with 1-phase AC or DC, phase sequence detection is not possible.
- Characteristics** Exchanging any two phase conductors in the 3-phase mains changes the direction of phase rotation. Should the phases L1, L2 and L3 be connected in the wrong sequence, this is detected and corrected by the AUMATIC, preventing the actuator from turning into the wrong direction.

Activate phase sequence detection and correction of direction of rotation

- M ▶ **Device configuration** M0053
Phase monitoring M0170
Adapt rotary dir. M0171
- Default value:** Function active
- Setting values:**
- Function active Function <Phase sequence detection and correction of direction of rotation> is activated.
- Function not active Phase sequence detection and correction of direction of rotation is deactivated.

11. Functions: activate and enable

11.1 Activate functions

Via menu **Activation M0212**, functions can be switched on (activated) or off (deactivated).

Required user level for enabling/disabling: **Specialist (4)** or higher.

- M ▶ **Device configuration M0053**
Application functions M0178
Activation M0212

Information Some functions require enabling. Only enabled functions are visible and can be activated or deactivated.

Function	Menu	Enabling required
EMERGENCY behaviour	M0589	No
Timer CLOSE	M0156	No
Timer OPEN	M0206	No
Positioner	M0158	Yes
Operation profile	M0294	No
Process controller	M0741	Yes
Profibus DP-V2	M0857	No
Bluetooth	M0573	No
Enable LOCAL	M0631	Yes
Priority REMOTE	M0770	Yes
Auto change-over I/O	M0790	Yes
Interlock	M0663	Yes
Torque Wrn	M0796	Yes
PVST	M0851	Yes
By-pass function	M0941	Yes

11.2 Enable functions

Via menu **Enabling M0179**, optional functions can be enabled or disabled.

This menu is visible in the display from user level **Specialist (4)**.

- M ▶ **Device configuration M0053**
Application functions M0178
Enabling M0179

Function	Menu for user level	
	Specialist (4)	AUMA (6)
Positioner	M0217	M0209
Process controller	M0219	M0338
Profibus DP-V1	M0340	M0339
Enable LOCAL	M0629	M0630
Priority REMOTE	M0772	M0771
Auto change-over I/O	M0791	M0789
Interlock	M0662	M0661
Torque wrn	M0798	M0797
PVST	M0857	M0856
By-pass function	M0939	M0940

Information In user level **Specialist (4)**, an additional activation password (works number specific) is required for enabling the function. The activation password can only be assigned and generated by the AUMA service.

12. Service functions

The functions described here may only be changed by the AUMA service or by authorised and trained personnel.

Menu item **Service functions** is only visible, if user level **Specialist (4)** or higher is selected.

12.1 Direction of rotation

Characteristics This function allows changing the direction of rotation for actuator with 3-phase AC motors.

The direction of rotation indicates the direction into which the drive shaft rotates around its own axis. The view is on the top of the actuator. Distinction is made between clockwise and counterclockwise rotation.

- Information**
- When changing from clockwise closing to counterclockwise closing or vice versa, only the direction of rotation of the motor is changed. The change-over requires further action:
 - The wiring diagram designation is marked on the AUMATIC name plate. In case of a change, a new name plate with the new wiring diagram number has to be requested from AUMA.
 - The wiring diagram number is stored in the electronic device ID (parameter **Wiring diagram actuator M0060**). The ID has to be adapted to the new designation once the conversion is complete.
 - The actuator mounted to the controls must be configured for the set direction of rotation. Subsequent conversion from clockwise closing to counterclockwise closing is possible using an AUMA conversion kit.

Parameters and instructions for setting

Setting the direction of rotation using parameters is only possible for actuators with electronic control unit/MWG (Non-intrusive version).

NOTICE

Valve damage due to incorrect direction of rotation!

→ For 3-phase AC motors, the rotation direction of the actuator must match the rotation direction of the valve.

Required user level: **AUMA (6)**.

M ▶ **Device configuration M0053**
Actuator M0168
Closing rotation M0176

Default value: **Clockwise rotation**

Setting values:

Clockwise rotation The motor is controlled with a clockwise rotating field with the following sequence: L1-U1, L2-U2, L3-U3 (clockwise closing).

Counterclockwise rot. The motor is controlled with a counterclockwise rotating field with the following sequence: L1-U3, L2-U2, L3-U1 (counterclockwise closing).

12.2 Factory setting

The factory setting corresponds to the delivery state of the AUMATIC.

When converting the controls e.g. by the AUMA service, a new factory setting can be generated to adapt the modified configuration.

Former factory settings can be restored.

Generate new factory setting

Required user level: **Service (5)** or higher.

M ▶ **Device configuration M0053**

Service functions M0222
Create factory settings M0225

Generates new factory settings by accepting the current settings.

Restore factory setting

Required user level: Specialist (4) or higher.

M ▷ Device configuration M0053
Service functions M0222
Reset factory settings M0226

Resets the current settings to factory settings.

12.3 Languages: reload

If texts are changed or if a new display language is available, the language file can be updated from the external data carrier (SD card).

Required user level: Specialist (4) or higher.

M ▷ Device configuration M0053
Service functions M0222
Reload languages M0227

12.4 Data export

During data export the data is saved from the device to an external data carrier (SD card).

Export data

Comprehensive export of all data (parameters, operation data and event protocol).
Operation data is device-specific data.

Required user level: Service (5) or higher.

M ▷ Device configuration M0053
Service functions M0222
Export all data M0223

Export parameters

Export of all parameters. No operation data is transmitted.

Required user level: Specialist (4) or higher.

M ▷ Device configuration M0053
Service functions M0222
Export all parameters M0297

Export event report

Required user level: Specialist (4) or higher.

M ▷ Device configuration M0053
Service functions M0222
Export event report M0298

12.5 Data import

During data import, the data is transmitted to the controls from an external data carrier (SD card).

Import parameters

Import of all parameters. Operating data is not overwritten.

Required user level: Specialist (4) or higher.

- M ▶ **Device configuration** M0053
Service functions M0222
Import all parameters M0311

12.6 Actual configuration: accept

When retrofitting controls, sub-assemblies are replaced by new sub-assemblies with different functions.

Example: Replacing the PSU (different voltage).

If the controls detect a modified sub-assembly during start up, the following fault signal is generated: **Configuration error**

Accept current actual configuration

Accept new actual configuration as target configuration.

Required user level: **AUMA (6)**.

- M ▶ **Device configuration** M0053
Service functions M0222
Accept actual config. M0590

12.7 Firmware update

A firmware update is required in the following cases:

- Upgrade with new functions
- Corrective actions

A firmware update can be performed in the following ways:

1. via Bluetooth connection using AUMA ToolSuite software on a laptop computer or PDA
2. via an SD card (card slot in local controls)
3. via Profibus DP (using AUMA ToolSuite)

Firmware version

The firmware version can be displayed via the following menu:

- M ▶ **Device ID** M0021
Version M0062
Firmware M0077

Firmware update via SD card

The menu **Update firmware** is only displayed if an SD card has engaged in the card slot of the local controls.

Required access level: **Service (5)** or higher.

- M ▶ **Device configuration** M0053
Service functions M0222
Update firmware M0564

12.8 Service software AUMA ToolSuite (Bluetooth)

AUMA ToolSuite is a user-friendly setting and operation program for AUMA actuator controls AC 01.2.

The connection between computer (PC, laptop, PDA) and local controls is established wireless via Bluetooth interface.

Activate Bluetooth

Required user level: **Specialist (4)** or higher.

- M ▶ **Device configuration** M0053
Application functions M0178
Activation M0212

Bluetooth M0573**Default value:** Function active**Setting values:**

Function not active

Function deactivated.

Function active

Function activated. If the connection is active, the blue LED on the local controls is illuminated.

Addresses and device tag

Required user level: Specialist (4) or higher.

M ▷

Diagnostic M0022

Bluetooth M0244

Device tag M0423

Bluetooth address M0422

Bluetooth add.partner M0576

13. Diagnostics

Diagnostics comprise information (indications, signals, reports and characteristic curves) for support during commissioning, maintenance or corrective action.

13.1 Electronic device ID

The electronic device ID provides information about the order data (important for enquiries with the factory).

M ► **Device ID** M0021
Identification M0026
Version M0062

Information on device identifications can be modified with the appropriate rights (user level).

Table 7: Information on device identifications

Identification M0026		
Indication on display	Description	User level required for modification
Device designation M0072	AUMATIC device designation	Service (5)
Device tag M0070	Device ID for identification within the plant marking (e.g. KKS (Power Plant Classification System))	Specialist (4)
Project name M0068	Project name of the plant	Specialist (4)
Controls M0028	Information on the identification of the AUMATIC	Menu
Com. no. controls M0055	Commission number (order number) of AUMATIC	Service (5)
Works no. controls M0056	Works number of AUMATIC	Service (5)
Wiring diagram M0059	Wiring diagram number of AUMATIC	Service (5)
Date of manufacture M0063	Date of manufacture of controls	Service (5)
Actuator M0029	Information on the identification of actuator	Menu
Com. no. actuator M0057	Commission number of actuator	Service (5)
Works no. actuator M0220	Works number of actuator	Service (5)
Wiring diagram actuator M0060	Wiring diagram number of actuator	Service (5)

Table 8: Information on device version

Version M0062	
Indication on display	Description
Firmware M0077	Firmware version
Language M0565	Language version
Firmware details M0515	Menu with further items for requesting the current Image File versions of current sub-assemblies (only visible for user level AUMA (6))
Hardware art. no. M0684	Menu with further items for requesting the hardware article number of the actual sub-assemblies (only visible for user level AUMA (6))

13.2 Operating data

Operating data provides details e.g. about the running time, the number of starts, number of torque faults etc.

The analysis of this data provides valuable information regarding the optimization of both actuator and valve. When using this information purposefully, actuator and valve will be carefully operated, e.g. through appropriate parameter setting. In case of faults, the logging of operating data allows for quick fault diagnostic.

View operating data

Two counters are available, a lifetime counter and a resettable counter.

- M ► Diagnostic M0022
 Operational info M0177
 Operational info total M0183
 Operational info M0188

Description of the indications:

Operational info total = Lifetime counter

Operational info = Counter can be reset to 0

Table 9: Operating data

Indication on display	Description
Motor running time	Motor running time
Motor starts	Number of motor starts (starts)
Thermal fault	Number of thermal faults (motor protection)
Torque fault CLOSE	Number of torque faults in direction CLOSE
Torque fault OPEN	Number of torque faults in direction OPEN
Limit trip CLOSED	Number of limit switch trippings in direction CLOSE
Limit trip OPEN	Number of limit switch trippings in direction OPEN
Torque trip CLOSE	Number of torque switch trippings in direction CLOSE
Torque trip OPEN	Number of torque switch trippings in direction OPEN
On time warning 1	Total of all time intervals during which a start/run warning was signalled.
On time warning 2	Max. time interval during which a start/run warning was signalled.
System starts	Total of AUMATIC system starts

Reset operating data

Required user level: Specialist (4) or higher.

- M ► Diagnostic M0022
 Operational info M0177
 Reset operation. info M0197

The entries in the operating data logging can be reset (deleted) via this menu.

13.3 Event report

The event report records system events and status signals. The event record can be exported to the external SD card or read via the AUMA ToolSuite software. This allows conclusions on previous operation of actuator and valve.

- Information** Since the events are recorded with a time-stamp, date and time (parameter Date and time M0221) should be properly set.

Event filter for system events

The AUMATIC records system events such as operation commands or modifications on the parameter settings. A filter is used to define the system events to be recorded in the event report.

Required user level: AUMA (6).

- M ► Diagnostic M0022
 Event report M0195
 System event filter M0334

An event is recorded (i.e. filter is active) if a black dot is placed behind the value displayed.

Events which can be recorded:

Commands	All operation commands recognised as valid and executed are recorded. The command source of the operation command is also recorded.
Parameterization	All modifications of parameter settings are also recorded. Both former and new value are recorded.
Enable processes	The enabling of a function is recorded.
System events	All important system events are recorded. These include: System start, change of date, downloads, modifications of the event filter, resetting of operating data and switching on the mains voltage.

Event filter for status indications

The AUMATIC records status indications such as faults, errors, warnings or Actuator is in end position CLOSED/OPEN. A filter is used to define the status indications to be recorded in the event report.

Required user level: AUMA (6).

M ▷ **Diagnostic M0022**
Event report M0195
Event filter for Events M0333

An event is recorded (i.e. filter is active) if a black dot is placed behind the value displayed.

Events which can be recorded:

The events which can be selected here are described in the <Faults and warnings> chapter.

File size of event report

The file size of the event report can be modified to record more or less events as desired. If the file is full, the oldest events will be overwritten so that the latest and current events are recorded.

Required user level: AUMA (6).

M ▷ **Diagnostic M0022**
Event report M0195
File size M0330

Default value: 64 [k]

Setting range: 1 ... 1,024 [k]

With the maximum setting range of 1,024 k, at least 10,000 events can be stored.

Information Some events are stored in a sector which cannot be overwritten. This includes, for example, modifications of the parameter setting, enabling of functions and certain special functions.

Number of events in the buffer

The events are first stored into an internal RAM. From this buffer, they are written to the event report after the set report cycle. The number of events in the buffer can be set here.

Information In case of power failure, the events in the buffer will be lost.

Required user level: AUMA (6).

M ▷ **Diagnostic M0022**
Event report M0195
Buffer size M0332

Default value: 50

Setting range: 10 ... 100**Save interval**

The event report is updated and saved at a defined cycle. This cycle (save interval) can be reduced or extended

Required user level: AUMA (6).

M ► **Diagnostic** M0022
 Event report M0195
 Save interval M0331

Default value: 50,000**Setting range:** 1,000 ... 65 535 [ms]**13.4 Diagnostic interface**

Required user level: Specialist (4) or higher.

M ► **Diagnostic** M0022
 Interface M0239

The following states can be checked via the menu:

Parameters	Menu ID	Signification
States DIN	M0245	Shows configuration, coding and state of the input signals.
States AIN 1	M0246	Shows configuration and current value at analogue input 1.
States AIN 2	M0583	Shows configuration and current value at analogue input 2.
States DOUT	M0247	Shows configuration, coding and state of the output signals.
States AOUT 1	M0248	Shows configuration and current value at analogue output 1.
States AOUT 2	M0584	Shows configuration and current value at analogue output 2.
Interface status	M0730	Status of the interface


Diagnostics of digital inputs

For the digital inputs (DIN), both coding and signal states are indicated at the input by means of symbols.

Table 10: Symbol explanation

Symbol	Code	Signal (command)	Input state
△	High active	Not active	Low level = 0 V or input open
▲	High active	Active	High level = Default: +24 V DC
▽	Low active	Not active	High level = Default: +24 V DC
▼	Low active	Active	Low level = 0 V or input open

Figure 61: Example of DIN 4 and DIN 5



- Configuration:
 - DIN 4: Operation command OPEN
 - DIN 5: Operation command for EMERGENCY behaviour

- Coding:
 - DIN 4: **High active** (Triangle pointing in upward direction)
 - DIN 5: **Low active** (Triangle pointing in downward direction)
- Signal state at input:
 - DIN 4: Not active (triangle not filled in)
Low level = 0 V = No operation command in direction OPEN
 - DIN 5: Active (triangle is black)
Low level = 0 V = EMERGENCY operation command is available


Diagnostic of digital outputs

For the digital outputs (DOUT), both coding and signal states are indicated at the output by means of symbols.

Table 11: Symbol explanation

Symbol	Code	Signal (indication)	State output (output contact)
△	High active	Not active	Low = 0 (output contact not operated)
▲	High active	Active	High = 1 (output contact operated)
▽	Low active	Active	High = 1 (output contact operated)
▼	Low active	Not active	Low = 0 (output contact not operated)

Figure 62: Example of DOUT 1 and DOUT 2



- Configuration:
 - DOUT 1: Indication: Fault has occurred.
 - DOUT 2: Indication: End position CLOSED reached
- Coding:
 - DOUT 1: **Low active** (Triangle pointing in downward direction)
 - DOUT 2: **High active** (Triangle pointing in upward direction)
- Signal state at output:
 - DOUT 1: Not active (triangle not filled in)
Low level = 0 V = No indication (not fault available)
 - DOUT 2: Active (triangle is black)
Low level = 0 V = indication (end position CLOSED reached)

13.5 Profibus interface: diagnostics

This diagnostics provides information on the current status of the Profibus sub-assemblies.

Required access level: **Specialist (4)** or higher.

M ► **Diagnostic M0022**
Profibus DP1 M0240
Profibus DP2 M0549
Profibus details M0602

For a detailed description of the indications included these menus refer to Manual (Device integration fieldbus) Profibus DP.

13.6 Bluetooth connection: diagnostic

Menu is only visible if function **Bluetooth M0573** is activated.

Required user level: **Specialist (4)** or higher.

M ▶ Diagnostic M0022
Bluetooth M0244

The following states can be checked via diagnostic:

Parameters	Menu ID	Signification
Device tag	M0223	Information for actuator identification within the plant (e.g. KKS designation - Power Plant Classification system) (Can be changed for user level Specialist (4) and higher)
Bluetooth address	M0222	Bluetooth address (BD_ADDR) of controls
Bluetooth add.partner	M0576	Bluetooth address (BD_ADDR) of the Bluetooth partner

13.7 Diagnostic position transmitter potentiometer

Menu is only visible if the actuator is equipped with potentiometer.

Required user level: **Observer (1)** or higher.

M ▶ Diagnostic M0022
Position transm. potent. M0831

The following states can be checked via diagnostic:

Parameters	Menu ID	Signification
Low limit Uspan	M0832	Low limit setting of potentiometer signal range (monitoring the potentiometer span)
Volt.level diff. potent.	M0833	Current voltage level difference of the potentiometer.
Raw val. pos. OPEN	M0999	Raw value end position OPEN
Raw val. pos. CLOSED	M1001	Raw value end position CLOSED
Potent. raw value /mV	M1005	Potentiometer raw value /mV

13.8 Diagnostic position transmitter RWG

Menu is only visible if the actuator is equipped with electronic position transmitter (RWG).

Required user level: **Observer (1)** or higher.

M ▶ Diagnostic M0022
Position transm. RWG M0996

The following states can be checked via diagnostic:

Parameters	Menu ID	Signification
Low limit RWG	M1010	Low limit setting of RWG signal for wire break monitoring
Raw val. pos. OPEN	M0997	Raw value end position OPEN
Raw val. pos. CLOSED	M0998	Raw value end position CLOSED
RWG raw value /mA	M1000	RWG raw value /mA

13.9 Diagnostic position transmitter MWG

Menu is only visible if the actuator is equipped with magnetic limit and torque transmitter (MWG).

Required user level: **Observer (1)** or higher.

M ▶ Diagnostic M0022
Position transm. MWG M1006

The following states can be checked via diagnostic:

Parameters	Menu ID	Signification
Minimum stroke	M1007	Minimum stroke of MWG
Maximum stroke	M1012	Maximum stroke of MWG
Abs. end pos. OPEN	M1011	Absolute value in end position OPEN
Abs. end pos. CLOSED	M1008	Absolute value in end position CLOSED
Absolute value	M1009	Absolute value of MWG

13.10 Diagnostic positioner

Required user level: **Specialist (4)** or higher.

M ▶ Diagnostic M0022
Position transm. RWG M0996

Menu **M0996** is only visible if function **Positioner M0158** is activated.

The following states can be checked via diagnostic:

Parameters	Menu ID	Bedeutung
Adaptive behaviour	M0626	Setting the adaptive behaviour of the positioner
Setpoint position	M0622	Setpoint position
Actual position	M0623	Actual position
Outer dead band	M0624	Outer dead band
Outer dead b. OPEN	M0625	Outer dead band OPEN
Outer dead b. CLOSE	M1002	Outer dead band CLOSE
Inner dead b. OPEN	M1003	Inner dead band OPEN
Inner dead b. CLOSE	M1004	Inner dead band CLOSE

13.11 Torque-travel characteristic

- Conditions**
- Actuators with electronic control unit
 - Actuator controls AC 01.2 (non-intrusive version) from firmware version 02.03.01

Characteristics Representation of the torque requirement over the entire travel (resolution of 0.1 %)
During each travel, the controls continuously record the torques applied.

Application When comparing two characteristics (current characteristic with archived characteristic), the wear within the valve or the actuator can be assessed.

The following additional information is saved with the characteristic:

- Commission number
- Works number
- Save date
- Nominal torque in direction OPEN/CLOSE
- Set tripping torque in direction OPEN/CLOSE
- Device tag (20 characters)

Display torque-travel characteristic


M ▶ Diagnostic M0022
Characteristics M0313
Torque-position M0546

3 characteristics with two charts each (direction OPEN and direction CLOSE) are shown in the display.

Each characteristic has a designation (e.g. _REF 1_), an arrow indicates the chart for the running direction.

Use push buttons **▲ ▼ Up ▲ Down ▼** to browse the charts.

Figure 63: Example of torque-time characteristic



The displayed characteristics are records which were previously saved.

Characteristics recording procedure

1. Reset characteristics (clear buffer)
2. Change characteristic designation
3. Record characteristic: Perform operation (e.g. CLOSE-OPEN-CLOSE)
4. Save characteristic

Reset characteristic

This parameter is used to reset the data in the buffer (RAM).

Required user level: **Specialist (4)** or higher.

- M ▶ Diagnostic M0022
 Characteristics M0313
 Reset characteristic M0656

After resetting the buffer, new characteristics can be recorded and saved.

Change characteristic designation

Each of the three characteristics can be named with an additional 20 characters.

Required user level: **Specialist (4)** or higher.

- M ▶ Diagnostic M0022
 Characteristics M0313
 Tag torque-position 1 M0658
 Tag torque-position 2 M0659
 Tag torque-position 3 M0660

Record characteristic: Perform operation (e.g. CLOSE-OPEN-CLOSE)

Set selector switch to position **Local control** (LOCAL) or **Remote control** (REMOTE) to record the characteristic.

Save characteristics

3 characteristics can be saved.

Each characteristic consists of two charts (direction OPEN and direction CLOSE).

When saving, data is transferred from the buffer (RAM) to the read-only memory (ROM).

Required user level: **Specialist (4)** or higher.

- M ▶ Diagnostic M0022
 Characteristics M0313
 Save characteristic 2 M0653
 Save characteristic 3 M0654
 Reset characteristic M0656

13.12 Motor running time-position (histogram)


- Conditions** • Actuators of the type range SA 07.2 – SA 16.2/SAR 07.2 – SAR 16.2

- Characteristics** The entire travel (from 0 – 100 %) is divided into 20 segments for recording the motor running time. When passing a segment, the counter, shown as bar graph, increments. The histogram is cyclically saved once a minute, in case a change has occurred.
- Application** The motor running time position histogram shows the travel range within which the actuator is predominantly operated. This allows to draw conclusions for the sizing of the valve.

Indicate motor running time position

- M ▶ **Diagnostic** M0022
Histograms M0712
Motor run.time-position M0713

Figure 64: Example of a motor running time position histogram



The following detailed information is saved with the histogram (may be called up via push buttons **Details**)

- **Starting date:**
- **Saving date:**
- **Scaling:**


13.13 Motor running time-temperature (histogram)

- Conditions**
- MWG position transmitter in actuator
 - Temperature sensor in the motor (option)
- Characteristics** The motor temperature is divided into the following segments: < –20°C to –10°C, > –10°C to 0°C, > 0°C to 10°C, ..., 120°C to 130°C, > 130°C to 140°C, > 140°C. When passing a segment, the counter, shown as bar graph, increments. The histogram is cyclically saved once a minute, in case a change has occurred.
- Application** The histogram indicates the ambient conditions (temperatures) at which the actuator motor was predominantly operated.

Indicate motor running time-temperature

- M ▶ **Diagnostic** M0022
Histograms M0712
Motor run.time-temp. M0715

Figure 65: Example of motor running time-motor temperature histogram



The following further information is saved with the histogram (can be requested via push button **Details**)

- **Starting date:**
- **Saving date:**
- **Scaling:**

13.14 Motor running time-torque (histogram)

- Conditions** MWG position transmitter in actuator

- Characteristics** The torque scale is divided into the following segments for both directions (OPEN/CLOSE):
- from 0 – 30 %
 - from 30 – 110 % (8 segments with a width of 10 % each)
 - more than 110 %


When passing a segment, the counter, shown as bar graph, increments. The histogram is cyclically saved once a minute, in case a change has occurred.

- Application** The motor running time-torque histogram indicates the actuator load during service life.

Display motor running time-torque

- M ► Diagnostic M0022
Histograms M0712
Motor run.time-torque M0830

Figure 66: Example of motor running time-torque histogram



The following further information is saved with the histogram (can be requested via push button **Details**)

- Starting date:.
- Saving date:.
- Scaling:.

14. Simulation (inspection and test function)

The service personnel or the commissioning engineer can use this simulation function to simulate the operation and failure behaviour of the actuator or the AUMATIC to check the interface to the DCS and the correct behaviour of the DCS.

14.1 Actuator signals

By simulating the actuator signals, the signal behaviour of the AUMATIC to the DCS can be tested, for example, without having to connect the actuator.

Required user level: **Service (5)** or higher.

M ▶ **Diagnostic** M0022
Simulation M0023
Actuator signals M0024

Simulation values:

End position OPEN End position OPEN reached.
End position CLOSED End position CLOSED reached.
Torque fault OPEN Torque in direction OPEN reached.
Torque fault CLOSE Torque in direction CLOSE reached.
Thermal fault Motor protection tripped (thermal fault)

The simulation is activated and deactivated by push button **Ok**.

A loop on the display indicates that the simulation is active.

14.2 Interface signals

By simulating the interface signals, the signal behaviour of the AUMATIC to the DCS can be tested, for example, without having to connect the actuator.

Required access level: **Specialist (4)** or higher.

M ▶ **Diagnostic** M0022
Simulation M0023
Signals DOUT M0025
Signals AOUT 1 M0413
Signals AOUT 2 M0585

Signals for simulating digital outputs:

Only the assigned outputs are displayed.

Numbers **1, 2, 3, ...** indicate the digital output.

Example: **1 Fault**

Indication **Fault** is assigned to digital output 1 (parameter **Signal DOUT 1** M0109).

Simulation is activated and deactivated by push button **Ok**.

Triangles indicate the activation:

Triangle pointing in upward direction: Output is coded high active.	
▲	High active (voltage is present, e.g. + 24 V DC)
△	High active (voltage is not present)
Triangle pointing in downward direction: Output is coded low active.	
▼	Low active (voltage is not present)
▽	Low active (voltage is present, e.g. + 24 V DC)

Signals for simulating analogue outputs:

Signals AOUT 1 Simulation of output signal **Actual position**, setting range: **0 ... 20 mA**
Signals AOUT 2 Simulation of output signal **Torque**, setting range: **0 ... 20 mA**

15. Corrective action

15.1 Primary fuses

The AUMATIC has to be opened to replace the primary fuses. For detailed information, refer to operation instructions for actuator.

15.2 Fault indications and warning indications

Faults interrupt or prevent the electrical actuator operation. In the event of a fault, the display backlight is red.

Warnings have no influence on the electrical actuator operation. They only serve for information purposes.


Collective signals include further indications which can be displayed via the  **Details** push button.

Table 12: Faults and warnings via status indications in the display













Indication on display	Description/cause	For indicated value > 0:
Warnings S0005	Collective signal 02: Indicates the number of active warnings.	Press push button  Details . For details, refer to <Warnings and Out of specification> table.
Not ready REMOTE S0006	Collective signal 04: Indicates the number of active signals.	Press push button  Details . For details, refer to <Not ready REMOTE and Function check> table.
Fault S0007	Collective signal 03: Indicates the number of active faults. The actuator cannot be operated.	Press push button  Details to display a list of detailed indications. For details, refer to <Faults and Failure> table.
Out of specification S0008	Collective signal 07: Indication according to NAMUR recommendation NE 107 Actuator is operated outside the normal operation conditions.	Press push button  Details . For details refer to <Warnings and Out of specification> table.
Function check S0009	Collective signal 08: Indication according to NAMUR recommendation NE 107 The actuator is being worked on; output signals are temporarily invalid.	Press push button  Details . For details, refer to <Not ready REMOTE and Function check> table.
Maintenance required S0010	Collective signal 09: Indication according to NAMUR recommendation NE 107 Recommendation to perform maintenance.	Press push button  Details to display a list of detailed indications.
Failure S0011	Collective signal 10: Indication according to NAMUR recommendation NE 107 Actuator function failure, output signals are invalid	Press push button  Details to display a list of detailed indications. For details, refer to <Faults and Failure> table.

Table 13: Warnings and Out of specification

Indication on display	Description/cause	Remedy
Config. warning	Collective signal 06: Possible cause: Configuration setting is incorrect. The device can still be operated with restrictions.	Press push button  Details to display a list of individual indications. For a description of the individual signals refer to <Individual signals> table/ Config. warning (collective signal 06).
Internal warning	Collective signal 15: Device warnings The device can still be operated with restrictions.	Press push button  Details to display a list of individual indications. For a description of the individual signals refer to <Individual signals> table/ Internal warning (collective signal 15).
24 V DC external	The external 24 V DC voltage supply of the controls has exceeded the power supply limits.	Check 24 V DC voltage supply.
Wrn on time running	Warning on time max. running time/h exceeded	<ul style="list-style-type: none"> Check modulating behaviour of actuator. Check parameter Perm. running time/h M0356, re-set if required.
Wrn on time starts	Warning on time max. number of motor starts (starts) exceeded	<ul style="list-style-type: none"> Check modulating behaviour of actuator. Check parameter Permissible starts/h M0357, re-set if required.
Failure behav. active	The failure behaviour is active since all required setpoints and actual values are incorrect.	Verify signals: <ul style="list-style-type: none"> Setpoint E1 Actual value E2 Actual process value E4 Check connection to master. Check (clear) status of master.
Wrn input AIN 1	Warning: Loss of signal analogue input 1	Check wiring.
Wrn input AIN 2	Warning: Loss of signal analogue input 2	Check wiring.
Wrn setpoint position	Warning: Loss of signal of actuator setpoint position Possible causes: Input signal for setpoint = 0 (signal loss)	Check setpoint signal.
Op. time warning	The set time (parameter Perm.op. time, manual M0570) has been exceeded. The preset operating time is exceeded for a complete travel from end position OPEN to end position CLOSED.	The warning indications are automatically cleared once a new operation command is executed. <ul style="list-style-type: none"> Check valve. Check parameter Perm.op. time, manual M0570.
Wrn controls temp.	Temperature within controls housing too high	Measure/reduce ambient temperature.
Wrn motor temp.	Temperature within motor winding too high	Check actuator sizing, correct accordingly.
Wrn gearbox temp.	Temperature within actuator gear housing too high	Check actuator sizing, correct accordingly.
RTC not set	Real time clock has not yet been set.	Set time.
RTC button cell	Voltage of the RTC button cell is too low.	Replace button cell.
PVST fault	Partial Valve Stroke Test (PVST) could not be successfully completed.	Check actuator (PVST settings).
PVST abort	Partial Valve Stroke Test (PVST) was aborted or could not be started.	Perform RESET or restart PVST.
Wrn no reaction	No actuator reaction to operation commands within the set reaction time.	<ul style="list-style-type: none"> Check movement at actuator. Check parameter Reaction time M0634.
Wrn FOC	Optical receiving signal (channel 1) incorrect (no or insufficient Rx receive level) or RS-485 format error (incorrect bit(s))	Check/repair FO cables.
Wrn FO cable budget	Warning: FO cable system reserve reached (critical or permissible Rx receive level)	Check/repair FO cables.

Indication on display	Description/cause	Remedy
Wrn FOC connection	Warning FO cable connection is not available.	Fit FO cable connection.
Torque wrn OPEN	Limit value for torque warning in direction OPEN exceeded.	Check parameter Wrn torque OPEN M0768, re-set if required.
Torque wrn CLOSE	Limit value for torque warning in direction CLOSE exceeded.	Check parameter Wrn torque CLOSE M0769, re-set if required.

Table 14: Faults and Failure

Indication on display	Description/cause	Remedy
Configuration error	Collective signal 11: Configuration error has occurred.	Press push button  Details to display a list of individual indications. For a description of the individual signals refer to <Individual signals> table/ Configuration error (collective signal 11).
Config. error REMOTE	Collective signal 22: Configuration error has occurred.	Press push button  Details to display a list of individual indications. For a description of the individual signals refer to <Individual signals> table/ Config. error REMOTE (collective signal 22).
Internal error	Collective signal 14: Internal error has occurred.	AUMA service Press push button  Details to display a list of individual indications. For a description of the individual signals refer to <Individual signals> table/ Internal error (collective signal 14).
Torque fault CLOSE	Torque fault in direction CLOSE	Perform one of the following measures: <ul style="list-style-type: none"> • Issue operation command in direction OPEN. • Set selector switch to position Local control (LOCAL) and reset fault indication via push button RESET. • Execute reset command via fieldbus.
Torque fault OPEN	Torque fault in direction OPEN	Perform one of the following measures: <ul style="list-style-type: none"> • Issue operation command in direction CLOSE. • Set selector switch to position Local control (LOCAL) and reset fault indication via push button RESET. • Execute reset command via fieldbus.
Phase fault	<ul style="list-style-type: none"> • When connecting to a 3-ph AC system and with internal 24 V DC supply of the electronics: Phase 2 is missing. • When connecting to a 3-ph or 1-ph AC system and with external 24 V DC supply of the electronics: One of the phases L1, L2 or L3 is missing. 	Test/connect phases.
Incorrect phase seq	The phase conductors L1, L2 and L3 are connected in the wrong sequence. Only applicable if connected to a 3-ph AC system.	Correct the sequence of the phase conductors L1, L2 and L3 by exchanging two phases.

Indication on display	Description/cause	Remedy
Mains quality	Due to insufficient mains quality, the controls cannot detect the phase sequence (sequence of phase conductors L1, L2 and L3) within the pre-set time frame provided for monitoring.	<ul style="list-style-type: none"> Check mains voltage. Check parameter Tripping time M0172, extend time frame if required.
Thermal fault	Motor protection tripped	<ul style="list-style-type: none"> Cool down, wait. If the fault indication display persists after cooling down: <ul style="list-style-type: none"> Set selector switch to position Local control (LOCAL) and reset fault indication via push button RESET. Execute reset command via fieldbus. Check fuses.
Fault no reaction	No actuator reaction to operation commands within the set reaction time.	Check movement at actuator.

Table 15: Not ready REMOTE and Function check (collective signal 04)


Indication on display	Description/cause	Remedy
Wrong oper. cmd	Collective signal 13: Possible causes: <ul style="list-style-type: none"> Several operation commands (e.g. OPEN and CLOSE simultaneously, or OPEN and SETPOINT operation simultaneously) A setpoint is present and the positioner is not active For fieldbus: Setpoint exceeds 100.0 % 	<ul style="list-style-type: none"> Check operation commands (send one operation command only). Set parameter Positioner to Function active. Check setpoint. Press push button  Details to display a list of individual indications. For details, refer to <Individual indications> table.
Sel. sw. not REMOTE	Selector switch is not in position REMOTE.	Set selector switch to position REMOTE.
Service active	Operation via service interface (Bluetooth) and service software AUMA ToolSuite.	Exit service software.
Disabled	Actuator is in operation mode Disabled.	Check setting and status of function <Local controls enable>.
EMCY stop active	The EMERGENCY stop switch has been operated. The motor control power supply (contactors or thyristors) is disconnected.	<ul style="list-style-type: none"> Enable EMERGENCY stop switch. Reset EMERGENCY stop state by means of Reset command.
EMCY behav. active	Operation mode EMERGENCY is active (EMERGENCY signal was sent). 0 V are applied at the EMERGENCY input.	<ul style="list-style-type: none"> Detect cause for EMERGENCY signal. Verify failure source. Apply +24 V DC at EMERGENCY input.
I/O interface	The actuator is controlled via the I/O interface (parallel).	Check I/O interface.
Handwheel active	Manual operation is activated.	Start motor operation.
FailState fieldbus	Fieldbus connection available, however no process data transmission by the master.	Verify master configuration
Local STOP	A local STOP is active. Push button STOP of local controls is operated.	Release push button STOP.
Interlock	An interlock is active.	Check interlock signal.
Interlock by-pass	By-pass function is interlocked.	Check states of main and by-pass valve.
PVST active	Partial Valve Stroke Test (PVST) is active.	Wait until PVST function is complete.

Table 16: Individual indications

Indication on display	Description/cause	Remedy
Config. warning (Collective signal 06)		
Wrn Setpoint Source	No setpoint source configured although an operation to a setpoint position is to be performed.	Configure analogue inputs AIN 1 or AIN 2, refer to <Input for setpoint position>
Wrn Dead bands	The inner dead band is larger than the outer deadband (the outer dead band is adapted to the inner dead band).	Check positioner setting.
Wrn Fieldbus config.	The configuration of the fieldbus interface is invalid	Check fieldbus interface configuration.
Torque config. CLOSE	The set tripping torque for direction CLOSE is outside the permissible setting range.	Verify torque switching setting.
Torque config. OPEN	The set tripping torque for direction OPEN is outside the permissible setting range.	Verify torque switching setting.
DIN 1 configuration – DIN 10 configuration	Signal assignment for the indicated digital input (DIN 1 – DIN 10) is incorrect.	Reconfigure digital input.
Configuration EMCY	Configuration of EMERGENCY behaviour is incorrect	Check configuration.
Config. operat. profile	Configuration of operation profile is incorrect.	Check configuration.
FO configuration	FO configuration is incorrect	Check configuration.
Heat.monitor.config.	Configuration of the heater monitoring is incorrect.	Check configuration.
Fail.beh. config.	Configuration of the failure behaviour is incorrect.	Check configuration.
Config. PID controller	Configuration of PID controller is incorrect	Check configuration.
Configuration error (Collective signal 11)		
IE MCM	Available version of the of 'MCM' (Motor Control and Monitoring / A52) electronics sub-assembly does not correspond to the target configuration.	Check hardware equipment/article number MCM.
IE PSO	Available version of the 'PSO' (Power Supply Options / A52.1) electronics sub-assembly does not correspond to the target configuration	Check hardware equipment/article number PSO.
IE config. pos. transm.	Internal error of position transmitter configuration (for actual position recording)	Check hardware equipment/article number position transmitter.
IE parameter config.	Available configuration does not correspond to the target configuration.	Check position transmitter parameters.
Hydraulics fault (Collective signal 12)		
Oil level	Oil level too low	Check oil level.
Oil leakage	Oil leakage occurred	Check hydraulic system.
Motor running time	Permissible running time of the electric motor for hydraulic pump exceeded.	Check hydraulic system.
Pressure rise fault	Pressure rise fault	Check hydraulic system.
Phase fault	<ul style="list-style-type: none"> When connecting to a 3-ph AC system and with internal 24 V DC supply of the electronics: Phase 2 is missing. When connecting to a 3-ph or 1-ph AC system and with external 24 V DC supply of the electronics: One of the phases L1, L2 or L3 is missing. 	Test/connect phases.
Incorrect phase seq	The phase conductors L1, L2 and L3 are connected in the wrong sequence. Only applicable if connected to a 3-ph AC system.	Correct the sequence of the phase conductors L1, L2 and L3 by exchanging two phases.

Indication on display	Description/cause	Remedy
Thermal fault	Motor protection tripped	<ul style="list-style-type: none"> Cool down, wait. If the fault indication display persists after cooling down: <ul style="list-style-type: none"> Set selector switch to position Local control (LOCAL) and reset fault indication via push button RESET. Execute reset command via fieldbus. Check fuses.
Wrong oper. cmd (Collective signal 13)		
Command REMOTE I	An incorrect operation command is available at I/O interface REMOTE I.	Correct operation command.
Command REMOTE II	An incorrect operation command is available at I/O interface REMOTE II.	Correct operation command.
Command fieldbus	An incorrect operation command is available at the fieldbus interface.	Correct operation command.
Setpoint pos. disabled	Operation commands to setpoint positions are not available (function disabled)	Verify availability of function (Activation M0212 parameter)
Internal error (Collective signal 14)		
IE mot. prot. monitor	Motor protection monitoring is defective	Check motor protection monitoring.
IE selector switch	Internal error selector switch defective	Replace selector switch.
IE phase monitoring	Internal error of phase monitoring	Check power supply.
IE 24 V AC	Internal error: The internal 24 V AC voltage supply of the controls has exceeded the power supply limits. The 24 V AC voltage supply is used to control the reversing contactors, to assess the thermostats, to supply the internal actuator heater and, as an option, to generate the 115 V AC supply for the customer.	<ul style="list-style-type: none"> Check power supply (level and wiring). Check power supply unit.
IE output defective	Internal error output defective (switchgear control)	Check switchgear control.
IE position transmitter	Internal error position transmitter (for actual position recording)	Check actuator.
IE logic	Internal error of 'Logic' electronics sub-assembly (A2)	Check logic.
IE fieldbus	Internal error of 'Fieldbus' electronics sub-assembly (A1.8)	Check fieldbus interface.
IE MWG	Internal error of 'MWG' (Magnetic Limit and Torque Transmitter / B6) electronics sub-assembly	Check MWG.
IE LC	Internal error of 'LC' (Local Controls / A9) electronics sub-assembly	Check local controls.
IE Hall 1 calibration – IE Hall 5 calibration	Internal error: Calibration of Hall sensor 1 – 5 of the MWG is incorrect.	Check MWG.
IE MWG calibration	Calibration of MWG is incorrect	Check MWG.
IE version	Internal error, conflict of versions	Check device configuration.
IE EEPROM	Internal error EEPROM	Check device configuration.
IE parameter	Internal error parameter (error during parameter initialisation)	Check device configuration.
IE file access	Internal error file access	Check device configuration.
IE backup	Error when accessing replacement parameters	Check device configuration.
IE registration	Internal error upon process data registration	Check device configuration.
IE startup FB	Internal error upon function block startup	Check device configuration.
IE startup sub-assy	Internal error upon electronics sub-assembly startup	Check device configuration.
IE LC exception	Error in the execution of LC firmware	Check device configuration.

Indication on display	Description/cause	Remedy
IE logic exception	Error in the execution of logic firmware	Check device configuration.
IE MWG Exception	Error in the execution of MWG firmware	Check device configuration.
IE bus exception	Error in the execution of fieldbus interface firmware	Check device configuration.
IE MWG end positions	Error when recording the end positions using the MWG	Check device configuration.
Internal warning (Collective signal 15)		
Wrn heater	Internal warning is active (control unit)	Check heater.
24 V DC customer	The 24 V DC customer auxiliary supply to control the digital inputs has failed.	Check 24 V DC inputs (DIN).
24 V DC internal	The internal 24 V DC power supply of the controls used to provide the electronics components (sub-assemblies within the AC 01.2 controls and in the actuator) has exceeded the power supply limits .	Check internal 24 V DC voltage supply.
Wrn Backup in use	Internal warning: Replacement parameters are used as no valid parameters are available (Remedy: Reboot controls/actuator)	Reboot AUMATIC.
Wrn ref.actual position	Actuator position feedback has not yet been referenced to the end positions.	Operate actuator fully in end positions OPEN and CLOSED.
Wrn range act.pos.	The current signal range of the position feedback is outside the permissible range.	Verify primary reduction gearing settings within the actuator.
Wrn sign.loss act.pos.	Loss of signal of the actuator position feedback	Check position feedback.
Wrn event mark	Wrn event mark (internal system warning)	Check system configuration.
Wrn Tm mark	Wrn Tm mark (internal system warning)	Check system configuration.
Hydraulics warning (Collective signal 17)		
Operat. pressure min	Pressure of hydraulic accumulator lower than the minimum value of the set accumulator pressure.	Check hydraulic system
Pump starts	Permissible number of starts of the hydraulic pump has been exceeded.	Check hydraulic system.
Oper. press. config.	Configuration of the accumulator pressure is incorrect.	Check hydraulic system.
Config. error REMOTE (Collective signal 22)		
IE I/O interface	Available version of 'I/O interface' (A1.0) electronics sub-assembly does not correspond to the target configuration.	<ul style="list-style-type: none"> Check I/O interface M0139 parameter. The setting must correspond to the wiring diagram. Check wiring. Check I/O interface.
IE remote interface	Configuration for function of Remote interface is incorrect.	Check configuration.
IE remote Prm Config	Configuration of Remote interface function is faulty.	Check configuration.

16. Appendix

16.1 Selection overview for output contacts and indication lights (digital outputs DOUT)

Depending on the version, the AC is equipped with up to 6 output contacts (digital outputs).

Table 17:

Signal	Description
Not assigned	–
End position CLOSED	End position CLOSED reached Indication depends on the type of seating and means either <ul style="list-style-type: none"> • limit seating, end position CLOSED reached, or • torque seating, end position CLOSED reached
End position OPEN	End position OPEN reached Indication depends on the type of seating and means either <ul style="list-style-type: none"> • limit seating, end position OPEN reached, or • torque seating, end position OPEN reached
End p. CLOSED, blink	End position CLOSED reached or intermediate position reached (The intermediate position is only indicated if parameter Signal interm. pos. M0167 = OPEN/CLOSED = On.) Signal blinking: Actuator runs in direction CLOSE.
End p. OPEN, blink	End position OPEN reached or intermediate position reached. (The intermediate position is only indicated if parameter Signal interm. pos. M0167 = OPEN/CLOSED = On.) Signal blinking: Actuator runs in direction OPEN
Setpoint pos. reached	The position setpoint is within max. error variable (outer dead band). Is only signalled if Profibus DP master has set the Fieldbus SETPOINT bit (process representation output).
Running CLOSE	Actuator runs in direction CLOSE.
Running OPEN	Actuator runs in direction OPEN.
Selector sw. LOCAL	Selector switch is in position LOCAL.
Selector sw. REMOTE	Selector switch is in position REMOTE.
Selector sw. OFF	Selector switch is in position OFF.
Limit switch CLOSED	Limit switch operated in direction CLOSE
Limit switch OPEN	Limit switch operated in direction OPEN
Torque sw. CLOSED	Torque in direction CLOSE exceeded
Torque sw. OPEN	Torque in direction OPEN exceeded
Failure	Collective signal 10: Indication according to NAMUR recommendation NE 107 Actuator function failure, output signals are invalid.
Function check	Collective signal 08: Indication according to NAMUR recommendation NE 107 The actuator is being worked on; output signals are temporarily invalid.
Out of specification	Collective signal 07: Indication according to NAMUR recommendation NE 107 Difference between setpoint and actual value is too important (exceeding the normal operation conditions).
Maintenance required	Collective signal 09: Indication according to NAMUR recommendation NE 107 Recommendation to perform maintenance.
Fault	Collective signal 03: Contains the result of a disjunction (OR operation) of all faults.
Warning	Collective signal 02: Contains the result of an OR disjunction of all warnings.
Not ready REMOTE	Collective signal 04: Contains the result of a disjunction (OR-operation) of the signals, forming the "Not ready REMOTE" group. The actuator cannot be operated from REMOTE. The actuator can only be operated via the local controls.
Op. pause active	Actuator is in pause time of stepping mode

Signal	Description
Start stepping mode	The actuator is within the set stepping range.
Actuator running	Actuator is running (output drive is moving) Hard wired collective signal consisting of:
Running LOCAL	Output drive rotates due to operation command from LOCAL.
Running REMOTE	Output drive rotates due to operation command from REMOTE.
Handwheel operation	Output drive rotates without electric operation command.
In intermed. position	The actuator is in an intermediate position e.g. neither in end position OPEN nor in end position CLOSED.
Intermed. pos. 1	Intermediate position 1 reached
Intermed. pos. 2	Intermediate position 2 reached
Intermed. pos. 3	Intermediate position 3 reached
Intermed. pos. 4	Intermediate position 4 reached
Intermed. pos. 5	Intermediate position 5 reached
Intermed. pos. 6	Intermediate position 6 reached
Intermed. pos. 7	Intermediate position 7 reached
Intermed. pos. 8	Intermediate position 8 reached
Input DIN 1	A high signal (+24 V DC) is present at digital input 1.
Input DIN 2	A high signal (+24 V DC) is present at digital input 2.
Input DIN 3	A high signal (+24 V DC) is present at digital input 3.
Input DIN 4	A high signal (+24 V DC) is present at digital input 4.
Input DIN 5	A high signal (+24 V DC) is present at digital input 5.
Input DIN 6	A high signal (+24 V DC) is present at digital input 6.
EMCY stop active	Operation mode EMERGENCY stop is active (EMERGENCY stop button has been pressed).
Torque fault CLOSE	Torque fault in direction CLOSE
Torque fault OPEN	Torque fault in direction OPEN
Torque fault	Torque fault in directions CLOSE or OPEN
Thermal fault	Motor protection tripped
Phase fault	One phase missing
Fieldbus DOUT 1	High signal at fieldbus, digital output 1
Fieldbus DOUT 2	High signal at fieldbus, digital output 2
Fieldbus DOUT 3	High signal at fieldbus, digital output 3
Fieldbus DOUT 4	High signal at fieldbus, digital output 4
Fieldbus DOUT 5	High signal at fieldbus, digital output 5
Fieldbus DOUT 6	High signal at fieldbus, digital output 6
Fieldbus DOUT 7	High signal at fieldbus, digital output 7
Fieldbus DOUT 8	High signal at fieldbus, digital output 8
Fieldbus DOUT 9	High signal at fieldbus, digital output 9
Fieldbus DOUT 10	High signal at fieldbus, digital output 10
Fieldbus DOUT 11	High signal at fieldbus, digital output 11
Fieldbus DOUT 12	High signal at fieldbus, digital output 12
FailState fieldbus	No valid communication via fieldbus (despite available connection).
Handwheel active	Manual operation is active (handwheel is engaged); optional signal.
PVST active	Partial Valve Stroke Test (PVST) is active.
PVST error	Partial Valve Stroke Test (PVST) could not be successfully completed.
PVST abort	Partial Valve Stroke Test (PVST) was aborted or could not be started. Remedy: Perform RESET or restart PVST.
Failure (Cfg)	This signal can be configured (parameter Failure (Cfg) M0879) and comprises a combination of the following signals which can also be configured: <ul style="list-style-type: none"> • Fault (Cfg) M0880 • Warnings (Cfg) M0881 • Not ready REMOTE (Cfg) M0882
Interlock REMOTE	Function Interlock is active for operation mode REMOTE.
Interlock LOCAL	Function Interlock is active for operation mode Local.

Signal	Description
Interlock OPEN	Interlock OPEN is active (enable signal for operation commands in direction OPEN available).
Interlock CLOSED	Interlock CLOSED is active (enable signal for operation commands in direction CLOSE available).
Interlock	The operation mode Interlock is active.
By-pass Sync Out	<By-pass function> enable for operation commands of main or by-pass valves is active.
Interlock By-pass	Operation command executed without enable signal By-pass Sync Out.

16.2 Selection overview of binary signals for digital inputs (DIN)

— Option —

Conditions: <Additional inputs> or additional <Parallel interface>

Depending on the version, the AC is equipped with up to 10 digital inputs.

The inputs are designed for binary signals (standard input level: +24 V DC) and can be used, for example, to receive operation commands OPEN, STOP, CLOSE, to control intermediate positions or for the EMERGENCY signal.

Configuration of digital inputs

M ▶ Device configuration M0053
I/O interface M0139
Digital inputs M0116

Table 18:

Signal	Description
Not used	Input not assigned
MODE	Change-over between OPEN - CLOSE control and setpoint control
OPEN	Operation command OPEN
CLOSE	Operation command CLOSE
STOP	Operation command STOP
RESET	Reset fault signal
I/O interface	Change-over between fieldbus interface and parallel interface
OPEN/CLOSE	Operation command OPEN/CLOSE for two-wire control
EMERGENCY	Operation mode for EMERGENCY behaviour
Intermediate pos. 1	Operation command: Run to intermediate position 1.
Intermediate pos. 2	Operation command: Run to intermediate position 2.
Intermediate pos. 3	Operation command: Run to intermediate position 3.
Intermediate pos. 4	Operation command: Run to intermediate position 4.
Intermediate pos. 5	Operation command: Run to intermediate position 5.
Intermediate pos. 6	Operation command: Run to intermediate position 6.
Intermediate pos. 7	Operation command: Run to intermediate position 7.
Intermediate pos. 8	Operation command: Run to intermediate position 8.
Intermediate position 9	Operation command: Run to intermediate position 9.
Intermediate position 10	Operation command: Run to intermediate position 10.
Intermediate position 11	Operation command: Run to intermediate position 11.
Intermediate position 12	Operation command: Run to intermediate position 12.
CW position 1	Clockwise approach of position 1
CCW position 1	Counterclockwise approach of position 1
CW position 2	Clockwise approach of position 2
CCW position 2	Counterclockwise approach of position 2
CW position 3	Clockwise approach of position 3
CCW position 3	Counterclockwise approach of position 3
CW position 4	Clockwise approach of position 4
CCW position 4	Counterclockwise approach of position 4
CW	Clockwise actuator operation

Signal	Description
CCW	Counterclockwise actuator operation
Input DIN 1	Signal for controlling output contact
Input DIN 2	Signal for controlling output contact
Input DIN 3	Signal for controlling output contact
Input DIN 4	Signal for controlling output contact
Enable LOCAL	Enables the selector switch function (LOCAL/OFF) on the local controls
Enable OPEN	Interlock: Enables operation command in direction OPEN
Enable CLOSE	Interlock: Enables operation command in direction CLOSE
Internal PID setpoint 2	Internal PID setpoint
Remote II activation	
Remote II OPEN	
Remote II CLOSE	
Remote II STOP	
Execute PVST	
By-pass Sync In	Enable signal for <By-pass function>
LPV Sync In	
LPV end position CLOSED (SA)	
LPV sel. sw. REM (SA)	
LPV system ok (SA)	
PID setpoint I/O	
PID actual value I/O	

Index

A

Activate functions	86
Actual configuration	89
Actual value - indication on display	19
Actual value source - process controller	54
Actuator operation at the local controls	11
Actuator operation from remote	12
Adaptive behaviour	44
Additional bus inputs	57
Analogue output 1	26
Analogue output 1 adjustment	27
Analogue output 1 signal range	27
Analogue output 2	28
Analogue output 2 adjustment	28
Analogue output 2 signal range	28
Analogue signals	26
Appendix	109
Application functions	40
Auto change-over I/O	58

B

Basic settings	33
Binary input signals	111
Bluetooth	89
Bluetooth diagnostic	95
Bus address	56
Bus failure	58 , 58 , 71 , 71
By-pass function	59

C

Change-over between OPEN - CLOSE control and setpoint control	47
Characteristics	97
Closing fully/opening fully	46
Combination of fieldbus-parallel interface	57
Commission number	9
Commissioning	7
Commissioning (indications on display)	17
Configurable signals	26
Contrast	39
Control	9 , 30
Controller behaviour (process controller)	50
Correction of the direction of rotation	85
Corrective action	102
Cycles	80

D

Data export	88
Data import	88
Date	38
Date format	38
Dead band	45 , 45
Dead time	46
Delay time	64
Delay time <EMERGENCY operation>	68
Device temperatures	84
Diagnostic interface	94
Diagnostics	91
Digital inputs	111 , 111
Digital inputs (diagnostics)	94
Digital outputs	25
Digital outputs (diagnostics)	94
Direct display via ID	13
Direction of rotation	85 , 87
Direction of rotation:	87
Directives	7
Display (indications)	17
Display formats	38
Down time	84

E

EMERGENCY behaviour	64
EMERGENCY operation	64 , 66
EMERGENCY stop	31
Electronic device ID	91
Electronics monitoring power supply	83
Enable functions	86
Enable operation commands	72
End position seating	33
End position tolerance	46
Enforce REMOTE control	70
Error - indication on display	17
Error variable	45
Event report	92

F			L	
Factory setting	87		LEDs (indication lights)	23
Failure - indication on display	23		Language in the display	15
Failure behaviour	62		Limit seating	33
Failure functions	62		Limit setting range	46
Failure operation	62		Limit switching	36
Failure position	63		Local Stop	73
Failure source (EMERGENCY operation)	66		Local actuator operation	11
Failure source (failure operation)	63		Local control	11
Fault - indication on display	21		Local controls	11
Fault signal - configurable	26		Local controls: enable	69
Fieldbus address	56 , 56		Local setting	12
Fieldbus auto enable	71		Local stop: by-pass	68
Firmware update	89		Loss of process setpoint	52
Firmware version	89		Loss of signal	62 , 63
Function check - indication on display	22		Loss of signal (bus)	71
Functions: activate/enable	86		Loss of signal process setpoint value	52
Fuses	102			
G			M	
GSD file	25		MODE	48
H			MWG (diagnostic)	96
Histogram	98 , 99 , 99		Main menu	13
I			Maintenance	7
I/O interface change-over	57		Maintenance required - indication on display	22
Identification	9		Menu navigation	12
Indication light colour	24		Monitoring functions	78
Indication lights	23		Motion detector	82
Indications	17		Motor protection monitoring	79
Indications on display	17		Motor protection. by-pass	67
Input of setpoint position	48		Motor running time position histogram	98
Inspection record	9		Motor running time-temperature (histogram)	99
Interface (diagnostics)	94		Motor running time-torque (histogram)	99
Interlock behaviour	73		Motor starts	80
Interlock:	72		Multiport valve - Indications on display	20
Interlock: by-pass	68			
Intermediate position indication via LEDs	23		N	
Intermediate positions	40		Name plate	9
Internal process setpoint	52		Non-Intrusive	10
Intrusive	10		Not ready REMOTE - indication on display	21
Inverse operation	52		Number format	39 , 39

O

OPEN - CLOSE control (Remote OPEN - CLOSE)	47
Off time	43 , 55
On time	55 , 80
Operating data	91
Operation	7 , 11 , 29
Operation commands - indications on display	19
Operation profile	41
Operation profile: by-pass	68
Operation time monitoring	81
Out of specification - indication on display	22
Output contacts	25
Overload protection	78
Overrun	45

P

PVST	74
Partial Valve Stroke Test	74
Password	14
Password change	15
Password entry	14
Permissible operation time	81
Permissible reaction time	82
Permissible starts/h	81
Phase failure monitoring	84
Phase sequence detection	85
Position transmitter (diagnostic)	96
Positioner	43
Positioner (diagnostic)	97
Positioner - indication on display	20
Potentiometer (diagnostic)	96
Primary fuses	102
Priority REMOTE	70
Process controller	49
Profibus DP address	56
Profibus DP interface	56
Profibus interface: diagnostics	95
Proportional amplification Kp	53
Protective measures	7
Push-to-run operation Remote	30
Push-to-run operation local	29
process setpoint - loss	52

Q

Qualification of staff	7
------------------------	---

R

RWG (diagnostic)	96
Rate time Td	53
Reaction monitoring	82
Reaction time	82
Redundancy	56
Remote actuator operation	12
Reset time Tn	53
Response telegrams	56
Reversing time	62
Running time	80
Running time (motor)	98 , 99 , 99

S

Safety instructions	7
Safety instructions/warnings	7
Selection overview for output contacts and indication lights	109
Selector switch functions	69
Self-retaining Remote	30
Self-retaining local	29
Service	32
Service functions	87
Setpoint - indication on display	20
Setpoint control (Remote SETPOINT):	47
Setpoint position - input	48
Setpoint source - process controller	51
Signal failure (bus)	58
Signal loss	63
Signals	25
Signals (analogue)	26
Signals - configurable	26
Simulation	101
Slave address	56
Standards	7
Start of stepping mode	55
Status menu	13
Status signals	25
Status signals - configurable	26
Stepping mode	54
Stepping mode: by-pass	67
Stop step	55
Switching off for reaction time error	82

T

Target configuration	89
Temperature (motor)	99
Temperature indication	84
Temperature monitoring	83
Temperature unit	39
Thermal monitoring	79
Time	38
ToolSuite	89 , 89
Torque (histogram)	99
Torque - indication on display	19
Torque by-pass	78 , 78
Torque monitoring	78
Torque seating	33
Torque switching	34 , 35
Torque switching: by-pass	67
Torque unit	39
Torque warning	78
Torque-travel characteristic	97
Two-wire control	43
Type and size	9
Type of seating for end positions	33

U

User level	14
------------	----

V

Valve position - indication on display	18
Verification of sub-assemblies	84

W

Warnings - indication on display	21
----------------------------------	----

Parameter index

15 , 15 , 23 , 23	, 94 , 94 , 94 ,
, 23 , 23 , 23 ,	94 , 96 , 96 , 96
23 , 24 , 24 , 24	, 96 , 96 , 96 ,
, 24 , 24 , 25 ,	96 , 96 , 96 , 96
25 , 25 , 25 , 26	, 96 , 96 , 96 ,
, 26 , 26 , 26 ,	96 , 96 , 96 , 97
26 , 27 , 27 , 27	, 97 , 97 , 97 ,
, 27 , 27 , 27 ,	97 , 97 , 97 , 97
27 , 27 , 28 , 28	, 97 , 97 , 97 ,
, 28 , 28 , 28 ,	97 , 97 , 97 , 97
28 , 28 , 28 , 29	, 97 , 98 , 98 ,
, 30 , 30 , 33 ,	98 , 98 , 101 , 102
33 , 33 , 35 , 35	, 102 , 102 , 102 ,
, 35 , 36 , 36 ,	102 , 102 , 102 , 103
36 , 38 , 38 , 39	, 103 , 103 , 103 ,
, 39 , 39 , 39 ,	103 , 103 , 103 , 103
39 , 40 , 40 , 40	, 103 , 103 , 103 ,
, 41 , 41 , 42 ,	103 , 103 , 103 , 103
42 , 42 , 43 , 43	, 103 , 103 , 103 ,
, 44 , 44 , 45 ,	103 , 103 , 103 , 103
45 , 45 , 46 , 46	, 104 , 104 , 104 ,
, 46 , 46 , 46 ,	104 , 104 , 104 , 104
47 , 47 , 47 , 48	, 104 , 104 , 104 ,
, 48 , 49 , 49 ,	104 , 104 , 104 , 105
50 , 51 , 55 , 55	, 105 , 105 , 105 ,
, 55 , 55 , 55 ,	105 , 105 , 105 , 105
55 , 55 , 55 , 56	, 105 , 105 , 105 ,
, 56 , 56 , 56 ,	105 , 105 , 105 , 105
56 , 56 , 56 , 56	, 105 , 111
, 56 , 56 , 56 ,	
60 , 61 , 62 , 62	
, 62 , 63 , 63 ,	
64 , 64 , 65 , 65	
, 66 , 66 , 66 ,	
67 , 67 , 67 , 67	
, 68 , 68 , 68 ,	
69 , 73 , 73 , 73	
, 73 , 75 , 76 ,	
76 , 76 , 76 , 76	
, 77 , 77 , 77 ,	
78 , 78 , 78 , 79	
, 79 , 79 , 79 ,	
80 , 80 , 80 , 81	
, 81 , 81 , 81 ,	
81 , 81 , 82 , 82	
, 82 , 82 , 82 ,	
83 , 83 , 83 , 83	
, 83 , 84 , 84 ,	
84 , 85 , 87 , 88	
, 88 , 88 , 88 ,	
88 , 88 , 89 , 89	
, 89 , 89 , 90 ,	
90 , 90 , 90 , 91	
, 91 , 91 , 92 ,	
92 , 92 , 92 , 92	
, 92 , 92 , 93 ,	
93 , 93 , 93 , 93	
, 93 , 94 , 94 ,	
94 , 94 , 94 , 94	

Europe

AUMA Riester GmbH & Co. KG

Plant Müllheim
DE 79373 Müllheim
 Tel +49 7631 809 - 0
 Fax +49 7631 809 - 1250
 riester@auma.com
 www.auma.com

Plant Ostfildern - Nellingen
DE 73747 Ostfildern
 Tel +49 711 34803 - 0
 Fax +49 711 34803 - 3034
 riester@wof.auma.com

Service-Center Köln
DE 50858 Köln
 Tel +49 2234 2037 - 900
 Fax +49 2234 2037 - 9099
 service@sck.auma.com

Service-Center Magdeburg
DE 39167 Niederndodeleben
 Tel +49 39204 759 - 0
 Fax +49 39204 759 - 9429
 Service@scm.auma.com

Service-Center Bayern
DE 85386 Eching
 Tel +49 81 65 9017- 0
 Fax +49 81 65 9017- 2018
 Riester@scb.auma.com

AUMA Armaturentriebe GmbH
AT 2512 Tribuswinkel
 Tel +43 2252 82540
 Fax +43 2252 8254050
 office@auma.at
 www.auma.at

AUMA (Schweiz) AG
CH 8965 Berikon
 Tel +41 566 400945
 Fax +41 566 400948
 RettichP.ch@auma.com

AUMA Servopohony spol. s.r.o.
CZ 250 01 Brandýs n.L.-St.Boleslav
 Tel +420 326 396 993
 Fax +420 326 303 251
 auma-s@auma.cz
 www.auma.cz

OY AUMATOR AB
FI 02230 Espoo
 Tel +358 9 5840 22
 Fax +358 9 5840 2300
 auma@aumator.fi
 www.aumator.fi

AUMA France S.A.R.L.
FR 95157 Taverny Cedex
 Tel +33 1 39327272
 Fax +33 1 39321755
 info@auma.fr
 www.auma.fr

AUMA ACTUATORS Ltd.
UK Clevedon, North Somerset BS21 6TH
 Tel +44 1275 871141
 Fax +44 1275 875492
 mail@auma.co.uk
 www.auma.co.uk

AUMA ITALIANA S.r.l. a socio unico
IT 20023 Cerro Maggiore (MI)
 Tel +39 0331 51351
 Fax +39 0331 517606
 info@auma.it
 www.auma.it

AUMA BENELUX B.V.
NL 2314 XT Leiden
 Tel +31 71 581 40 40
 Fax +31 71 581 40 49
 office@benelux.auma.com
 www.auma.nl

AUMA Polska Sp. z o.o.
PL 41-219 Sosnowiec
 Tel +48 32 783 52 00
 Fax +48 32 783 52 08
 biuro@auma.com.pl
 www.auma.com.pl

OOO Priwody AUMA
RU 124365 Moscow a/ya 11
 Tel +7 495 221 64 28
 Fax +7 495 221 64 38
 aumarussia@auma.ru
 www.auma.ru

ERICH'S ARMATUR AB
SE 20039 Malmö
 Tel +46 40 311550
 Fax +46 40 945515
 info@erichsarmatur.se
 www.erichsarmatur.se

GRØNBECH & SØNNER A/S
DK 2450 København SV
 Tel +45 33 26 63 00
 Fax +45 33 26 63 21
 GS@g-s.dk
 www.g-s.dk

IBEROPLAN S.A.
ES 28027 Madrid
 Tel +34 91 3717130
 Fax +34 91 7427126
 iberoplan@iberoplan.com

D. G. Bellos & Co. O.E.
GR 13671 Acharnai Athens
 Tel +30 210 2409485
 Fax +30 210 2409486
 info@dgbellos.gr

SIGURD SØRUM AS
NO 1300 Sandvika
 Tel +47 67572600
 Fax +47 67572610
 post@sigum.no

INDUSTRA
PT 2710-297 Sintra
 Tel +351 2 1910 95 00
 Fax +351 2 1910 95 99
 industria@talis-group.com

Auma Endüstri Kontrol Sistemleri Limited
 irketi
TR 06810 Ankara
 Tel +90 312 217 32 88
 Fax +90 312 217 33 88
 Servis@auma.com.tr
 www.megaendustri.com.tr

AUMA Technology utomations Ltd.
UA 02099 Kiyiv
 Tel +38 044 586-53-03
 Fax +38 044 586-53-03
 auma-tech@aumatech.com.ua

Africa

AUMA South Africa (Pty) Ltd.
ZA 1560 Springs
 Tel +27 11 3632880
 Fax +27 11 8185248
 aumasa@mweb.co.za

A.T.E.C.
EG Cairo
 Tel +20 2 23599680 - 23590861
 Fax +20 2 23586621
 atec@intouch.com

CMR Contrôle Maintenance Régulation
TN 1002 Tunis
 Tel +216 71 903 577
 Fax +216 71 903 575
 instrum@cmr.com.tn
 www.cmr-tunisie.net

MANZ INCORPORATED LTD.
NG Port Harcourt
 Tel +234-84-462741
 Fax +234-84-462741
 mail@manzincorporated.com
 www.manzincorporated.com

America

AUMA ACTUATORS INC.
US PA 15317 Canonsburg
 Tel +1 724-743-AUMA (2862)
 Fax +1 724-743-4711
 mailbox@auma-usa.com
 www.auma-usa.com

AUMA Argentina Representative Office
AR 1609 Boulogne
 Tel/Fax +54 232 246 2283
 contacto@aumaargentina.com.ar

AUMA Automação do Brasil Ltda.
BR São Paulo
 Tel +55 11 8114-6463
 bitzco@uol.com.br

AUMA Chile Representative Office
CL 9500414 Buin
 Tel +56 2 821 4108
 Fax +56 2 281 9252
 aumachile@adsl.tie.cl

TROY-ONTOR Inc.
CA L4N 8X1 Barrie Ontario
 Tel +1 705 721-8246
 Fax +1 705 721-5851
 troy-ontor@troy-ontor.ca

Ferrostaal de Colombia Ltda.
CO Bogotá D.C.
 Tel +57 1 401 1300
 Fax +57 1 416 5489
 dorian.hernandez@ferrostaal.com
 www.ferrostaal.com

PROCONTIC Procesos y Control
 Automático
EC Quito
 Tel +593 2 292 0431
 Fax +593 2 292 2343
 info@procontic.com.ec

Corsusa International S.A.C.
PE Miraflores - Lima
 Tel +511444-1200 / 0044 / 2321
 Fax +511444-3664
 corsusa@corsusa.com
 www.corsusa.com

PASSCO Inc.
PR 00936-4153 San Juan
 Tel +18 09 78 77 20 87 85
 Fax +18 09 78 77 31 72 77
 Passco@prtc.net

Suplibarca
VE Maracaibo Estado, Zulia
 Tel +58 261 7 555 667
 Fax +58 261 7 532 259
 suplibarca@intercable.net.ve

Asia

AUMA Actuators (Tianjin) Co., Ltd.
CN 300457 Tianjin
 Tel +86 22 6625 1310
 Fax +86 22 6625 1320
 mailbox@auma-china.com
 www.auma-china.com

AUMA INDIA PRIVATE LIMITED
IN 560 058 Bangalore
 Tel +91 80 2839 4656
 Fax +91 80 2839 2809
 info@auma.co.in
 www.auma.co.in

AUMA JAPAN Co., Ltd.
JP 211-0016 Nakaharaku, Kawasaki-shi Kanagawa
 Tel +81 44 863 8371
 Fax +81 44 863 8372
 mailbox@auma.co.jp
 www.auma.co.jp

AUMA ACTUATORS (Singapore) Pte Ltd.
SG 569551 Singapore
 Tel +65 6 4818750
 Fax +65 6 4818269
 sales@auma.com.sg
 www.auma.com.sg

AUMA Actuators Middle East W.L.L.
AE 15268 Salmabad 704
 Tel +973 17877377
 Fax +973 17877355
 Naveen.Shetty@auma.com

PERFECT CONTROLS Ltd.
HK Tsuen Wan, Kowloon
 Tel +852 2493 7726
 Fax +852 2416 3763
 joeip@perfectcontrols.com.hk

DW Controls Co., Ltd.
KR 153-702 Seoul
 Tel +82 2 2624 3400
 Fax +82 2 2624 3401
 sichoi@actuatorbank.com
 www.actuatorbank.com

Sunny Valves and Intertrade Corp. Ltd.
TH 10120 Yannawa Bangkok
 Tel +66 2 2400656
 Fax +66 2 2401095
 sunnyvalves@inet.co.th
 www.sunnyvalves.co.th/

Top Advance Enterprises Ltd.
TW Jhonghe City Taipei Hsien (235)
 Tel +886 2 2225 1718
 Fax +886 2 8228 1975
 support@auma-taiwan.com.tw
 www.auma-taiwan.com.tw

Australia

BARRON GJM Pty. Ltd.
AU NSW 1570 Artarmon
 Tel +61 294361088
 Fax +61 294393413
 info@barron.com.au
 www.barron.com.au

AUMA Riester GmbH & Co. KG
P.O.Box 1362
D 79373 Muellheim
Tel +49 7631 809 - 0
Fax +49 7631 809 - 1250
riester@auma.com
www.auma.com