



Actuator controls

AUMATIC AC 01.1/ACExC 01.1

Profibus DP-V1

DTM (Device Type Manager)

for FDT (Field Device Tool)



Reference documents:

- Manual (operation and setting) AUMATIC AC 01.1/ACExC 01.1 with Profibus DP.
Can be downloaded from the Internet (www.auma.com) or ordered directly from AUMA (addresses see page 26).

	Page
Table of contents	
1. Introduction	3
1.1. AUMA scope of delivery	4
1.2. Summary of AUMATIC DTM functions	4
1.3. Prerequisites for the device integration with AUMATIC DTM	4
2. Installing AUMATIC DTM software	4
3. Setup of AUMATIC in FDT frame application	4
4. General information regarding the AUMATIC DTM operation.	8
4.1. Starting the AUMATIC DTM	8
4.2. Main window	8
4.3. Selecting the AUMATIC DTM language	9
4.4. AUMATIC DTM views	9
4.5. Printing device data	9
4.6. AUMATIC DTM Online help	9
5. Functions for data communication with AUMATIC DTM	10
5.1. Connecting/disconnecting the communication to the AUMATIC	10
5.2. Reading data from/writing data into the AUMATIC	10
5.3. Parameter setting	11
5.3.1 Offline parameterisation	11
5.3.2 DTM communication behaviour	13
5.3.3 Online parameterisation	14
5.4. Measured value	15
5.5. Special features of the programming	16
5.6. Additional functions	17
5.6.1 Trend	17
5.6.2 About	20
6. Profibus DP-V0 communication channel	21
7. Appendix A: Literature	23
8. Overview on AUMATIC DTM icons	24
Addresses	26

1. Introduction

Process data DP-V0 Extended functions DP-V1

The field devices used in the industrial process automation today have, aside from the compulsory main functions, a variety of more detailed application functions to adapt their performance optimally to the process requirements. In addition to this, most field devices have even more functions and methods to diagnose their own field device status. When using open, internationally standardised fieldbus systems such as Profibus DP-V1, access to these device-specific application and diagnosis functions is made through the same fieldbus cables which are also used for the process data exchange between field device and control system. Beside the cyclic process data exchange via Profibus DP-V0, an additional acyclic communication via Profibus DP-V1 can hereby be established, without additional wiring. It serves for adapting parameters of the application functions or reading out status and diagnostics data during operation.

By means of the optional acyclic Profibus DP-V1 services, the actuator controls AUMATIC offers access to

- User function parameters for adapting to process requirements
- Data within the electronic name plate for detailed device identification
- Operational data for preventive maintenance

Furthermore, the current device status may be communicated for diagnosis purpose.

Access via FDT interface

The device access for all connected field devices is thereby made through a central operation and monitoring station, located e.g. in the control room. A standardised software interface enables uniform integration of various field devices into the operation and monitoring software.

The details of this software interface were laid down and published in the FDT interface specification (FDT = Field Device Tool, refer to www.profibus.com or www.fdt-group.org).

FDT frame application

Typical examples for operation and monitoring software with FDT interface are PACTware (www.pactware.com) or Fieldcare (by Endress&Hauser). These tools are also called FDT frame applications, as they contain the various DTMs for all field devices of a plant.

Device integration via DTM

A DTM (Device Type Manager) is an instrument-specific software component required to integrate a field device of a certain manufacturer into the operation and monitoring software (FDT frame application) or into a control system with FDT interface.

The **AUMATIC DTM** for the actuator controls AUMATIC is available for free download on the Internet, at www.auma.com.

The AUMATIC DTM frees the user from having to worry about the details regarding the Profibus DP-V1 communication, but allows to use the device-specific application and diagnosis functions immediately after having installed and assigned the device address.

The present document describes the handling of the AUMATIC DTM on the basis of the PACTware FDT frame application; the instructions apply accordingly to other FDT applications.

1.1. AUMA scope of delivery

AUMATIC DTM installation package, available on the Internet at www.auma.com, with the following contents:

- Installation file (setup.exe) for AUMATIC DTM
- Manual device integration with AUMATIC DTM (pdf file)

1.2. Summary of AUMATIC DTM functions

The AUMATIC DTM provides the following features:

- Reading and writing of AUMATIC parameters.
- Reading and writing of the electronic name plate for detailed identification of the AUMATIC.
- Reading and clearing the operating data for diagnosis and preventive maintenance.
- Tool tips with short descriptions for each parameter.
- Offline and online operation mode
- Online diagnosis regarding the current AUMATIC status.
- Trend functions with logging and storing features of the current torque, the actual position, the setpoint, as well as the current operation status.
- Includes the GSD file, the documentation of the AUMATIC with Profibus DP, short instructions for AUMATIC DTM, as well as Online Help.
- Profibus DP-V0 communication channel (e.g. for integration into ABB systems).

AUMATIC DTM conforms to FDT specification 1.2 including addendum.

1.3. Prerequisites for the device integration with AUMATIC DTM

Actuator controls AUMATIC:

The following software versions/functions must be installed:

- AUMATIC logic software Z031.922/10-xx or later, refer to AUMATIC display, diagnosis indication D6: LOGIC SW-VERSION.
If the AUMATIC DTM is operated in combination with an AUMATIC equipped with an older logic software version (e.g. Z031.922/05-04 or later, or Z031.922/08-xx), the available functionality is somewhat restricted (no online transfer of status or diagnosis information, no trend function).
- AUMATIC Profibus DP-V1 software Z031.320/02-00 or later, refer to AUMATIC display, diagnosis indication DD:DP1 SW-VERSION (for Profibus DP redundancy additionally DH: DP2 SW-VERSION).
- The Profibus DP-V1 function has to be activated within the AUMATIC, refer to AUMATIC display, menu indication M4009: MAIN MENU > CONFIGURATION > SPECIAL FUNCTIONS > VIEW > DP-V1 SERVICES = FUNCTION ACTIVE.

Computer:

The following programs/hardware must be installed:

- FDT frame application (operation and monitoring software), with FDT specification 1.2 support, e.g. PACTware (www.pactware.com)
- CommDTM (communication DTM) for Profibus DP-V1 interface e.g. PCMCIA board with PROFIdtm DPV1 by Softing AG (www.softing.com).

2. Installing AUMATIC DTM software

1. Exit all running programs.
2. Start setup.exe.
3. Follow the instructions of the setup program.


3. Setup of AUMATIC in FDT frame application

This chapter describes the setup with the example of the FDT frame application PACTware. Please refer to the PACTware Online help for a complete program description.

When using a different FDT frame application, the procedure to be followed is basically the same way as described hereunder.

Starting FDT frame application

1. Start PACTware
2. Display the device catalogue selecting **View > Device catalog**
The device catalogue shows all DTM installed on the computer, sorted by manufacturer.




3. Click **Update device catalog** to display all DTM available within the system.

Adding CommDTM

A CommDTM (communication DTM) is a software component which must be available for each project. The AUMATIC DTM and all other DTMs for other field devices are then assigned to the CommDTM.

4. Click **HOST PC** with the right mouse button and select **Add device**.
The **Device for** window shows the available CommDTMs.




5. Select **CommDTM** (Device Data Base for Softing DP Master) and confirm by clicking **OK**.

Adding the AUMATIC


6. Click CommDTM (here: <0.PROFIdtm>PROFIDTM V1>) using right mouse button.

The following dialogue window opens:




7. Click **Add device** command

The **Device for PROFIdtm DPV1** window shows the available devices:



8. Select **Device** (AUMATIC actuator) and confirm with **OK**.

The dialogue window for entering the station address opens:



9. Enter **Station Address** (Profibus DP device address of the AUMATIC) and click **OK**.


Note The station address entered must be identical to the device address of the AUMATIC connected!

You may request the device address at the AUMATIC local controls display as follows:

MAIN MENU (M0)
SETTINGS (M1)
PROFIBUS DP1 (M1B)
SLAVE ADDRESS (M1B00)

Subsequently updating the device address

1. Click CommDTM (here: <0.PROFIdtm>PROFIDTM V1>) using right mouse button and select **Additional functions**.
The dialogue window indicates:




2. Click **Edit DTM Station Addresses**.
The device address may be modified within the window opening now.

4. General information regarding the AUMATIC DTM operation


4.1. Starting the AUMATIC DTM

When using PACTware, double-click the AUMATIC projected within the project tree to start the AUMATIC DTM.



4.2. Main window

Figure 1



Area mark A The area mark A describes the AUMATIC DTM **Header**. This area shows typical device features and serves the purpose to identify, at a glance, the AUMATIC used. The figure shows the AUMATIC in offline mode.


Area mark B The area mark B describes the **Tree view** of the AUMATIC DTM. The tree structure is used to quickly toggle between the various parameters. Pull the tree structure to an expanded view to display values and units.

Area mark C Area mark C describes the **Parameter main view**, the so-called display. The navigation arrows (mark C) allow to navigate between the individual displays. It is possible to divide a menu with several parameters into several displays to logically group the parameters. If only one display containing all parameters is defined for a menu, the navigation arrows are inactive and shown in grey.

The mark C2 shows the menu names of the currently displayed items.

4.3. Selecting the AUMATIC DTM language

The AUMATIC DTM supports six languages altogether, which can be selected independently of the FDT frame application language setting using the **Language** button:



4.4. AUMATIC DTM views

The three icons below the Language button are used to display the available AUMATIC DTM views,

- a) with or without tree structure
- b) with or without header display
- c) with or without displaying the AUMATIC photo



4.5. Printing device data



Printing device data

For example, the data saved in the device memory may be printed to dispose of all parameter conditions in the event of failure for any possible subsequent troubleshooting required. The selection criteria can be:

- Offline parameter
- Online parameter
- Measured value

Attention

The printing of online parameters may take several minutes and depends on the number of instrument parameters to be read.

4.6. AUMATIC DTM Online help




Selecting online help

Provides detailed information on AUMATIC parameters.

If the menu pointer points to a parameter, the pertaining tool tip is displayed for explanation.

Furthermore, the operation instructions are selected when clicking the parameter names (mark A)



5. Functions for data communication with AUMATIC DTM

5.1. Connecting/disconnecting the communication to the AUMATIC

Before reading data from or writing data into the AUMATIC, you have to establish a connection to the device.

- Click the AUMATIC icon with the right mouse button and select **Connect** or **Disconnect**.


5.2. Reading data from/writing data into the AUMATIC

This function allows reading/writing of AUMATIC parameters from/into the AUMATIC DTM. It is possible to display and/or set the parameters in the offline parameter display. They are stored in the frame application data base.

- Click the AUMATIC icon with the right mouse button and select **Load from device** or **Store to device**.

Note These functions are only available if an online connection to the device is established.

Parameter values must be within the permissible minimum and maximum limits. When transmitting invalid values, the reference “Out of range” is displayed together with the permissible value range for the parameter concerned:



Some parameters of the AUMATIC actuator controls are combined with optional functions and features; changing these parameters will only have an effect if these functions are available in the AUMATIC actuator controls (e.g. parameters of a possibly available redundant Profibus DP or parallel standard interface).

FDT user groups

FDT frame applications distinguish between five different user groups with different access authorisations.

An **observer** of the AUMATIC DTM may only read the AUMATIC actuator controls information.

Offline parameterisation and trend function are not available.

All other user groups have the right to read the information stored within the AUMATIC like the **observer** and write most parameters. Offline parameterisation and the trend function are available.


5.3. Parameter setting

Parameters may be set in online or offline mode.

Online/offline parameterisation

- Click the AUMATIC icon with the right mouse button and select offline or online parameterisation.

Figure 6



Note Online parameterisation is only available if an online connection to the device is established.

5.3.1 Offline parameterisation


In case of absence of communication, the DTM is first started in offline mode.

During offline parameterisation, the parameters displayed in the DTM are not synchronised with those modified simultaneously online within the AUMATIC.

Attention First load the data from the AUMATIC, then specifically modify individual parameters using the AUMATIC DTM. The complete parameter record should only be rewritten to the AUMATIC after this procedure. This is the only way to ensure that the AUMATIC DTM values match the values currently available in the AUMATIC.

The following view allows to display and modify the offline parameters of the device. The offline parameters may be stored in the FDT frame application data base.

Figure 2



Changing parameters

→ Click in the entry field to modify the desired values.

Note

Parameters which cannot be modified are shaded in grey.



Value unchanged (with blue circle)

The displayed value corresponds to the AUMATIC DTM standard value.



Value has been changed, modification has not yet been saved (red asterisk)

To save changes, press return key.

The changes are lost unless you press the return key.



Value has been modified but not yet set (white asterisk)

Does not correspond to the standard value.



Reset all parameters to the standard AUMATIC DTM values

Consequently, all changes within the AUMATIC DTM are lost.

Sending data to the AUMATIC

→ Click **Store to device** function.

Once the data is successfully stored to the device, the blue asterisks are removed; this shows that the displayed value matches the value within the device.



Value has not been stored to AUMATIC

Further information regarding the error can be gathered when clicking this icon.

5.3.2 DTM Communication behaviour

In the “Offline parameterisation” view, the DTM time behaviour during “Online parameterisation” may be influenced.

Communication > parameter

Refresh Time (dynamic)

This parameter is used to determine the time during which the dynamic device parameters are automatically updated.

Dynamic parameters are marked with the  icon.

Refresh Time (static)

This parameter is used to determine the time during which the static device parameters are automatically updated.

Static parameters are marked with the  icon.

A higher value or a longer refresh time leads to a reduced, acyclic Profibus DP-V1 data exchange (this can be particularly useful in order not to completely occupy the available Profibus DP-V1 communication bandwidth when several field devices are connected).


The cycle times set via the “Refresh Time” parameters define the reading cycle times which are not fallen short of. The actual cycle times may be higher; this depends on the Profibus DP baud rate, the number of Profibus DP devices, the configuration of the Profibus DP communication, as well as on the number of any simultaneously available Profibus DP-V1 connections to other field devices.

5.3.3 Online parameterisation

Note This function is only available if an online connection to the device is established.

Opening the menus may take more time than in offline mode because the data has to be loaded from the device. The loading time depends on the number of parameters to be loaded.

Figure 3



Like for the offline parameterisation, the parameters can be written or modified. The difference is that the modified value is stored to the device immediately after entry confirmation. Thus, the displayed values match the device values.



Dynamic value

This data is cyclically loaded from the device and displayed. Typically, this includes measured values, the cycle time depends on the "Refresh Time (dynamic)" parameter.



Static value

This data may also cyclically loaded from the device. These values normally remain unchanged.



Value has not been stored to AUMATIC

Further information regarding the error can be gathered when clicking this icon.

Attention


The parameter data may not be modified directly at the device or using a different tool if the AUMATIC DTM is in the online parameterisation mode. This can lead to an inconsistent status in the DTM. Therefore, go offline first; then the user can modify the parameters before allowing to read again the data in online mode.

5.4. Measured value

Note This function is only available if an online connection to the device is established.

This function opens the AUMATIC DTM Observe view. An overview of the dynamic values of the AUMATIC devices is displayed here (e.g. torque values, setpoint, actual position, and information on the operation status).

Figure 4



The current actuator torque is simultaneously shown in three different units

- Torque E6 as percentage of nominal torque
- Torque E6 as absolute value in Nm
- Torque E6 as absolute value in Lbs.Ft.

Notes Negative values correspond to a torque in direction CLOSE, positive values correspond to a torque in direction OPEN. Only those torque values are displayed in the AUMATIC DTM which exceed a certain actuator-specific basic load (typically approx. 40 – 50 % of the nominal actuator torque).

The actual position E2 and the setpoint E1 (when controlling via a setpoint) are displayed in per mil values.

The status information contains binary data on the current operation status:

Table 1	
Value	Signification
1	Actuator runs in direction OPEN
2	Actuator runs in direction CLOSE
3	Actuator is in end position OPEN
4	Actuator is in end position CLOSED
5	Actuator is at desired setpoint E1

The dynamic data transfer is a cyclic communication using the Profibus DP-V1 services. The cycle time may vary depending on the configuration of the Profibus DP-V0 communication and the workload of the available bandwidth for the Profibus DP-V1 communication.

The cycle time set via the “Refresh Time (dynamic)” parameter defines the reading cycle time which is not fallen short of. The actual cycle time may be higher; this depends on the Profibus DP baud rate, the number of Profibus DP devices, the configuration of the Profibus DP communication, as well as on the number of any simultaneously available Profibus DP-V1 connections to other field devices.

5.5. Special features of the programming

Parameters for setting the tripping torques

The setting of the tripping torques in direction OPEN or direction CLOSE is only available in combination with non-intrusive actuators (parameters Tripping torque OPEN or Tripping torque CLOSE).

Figure 5



The permissible minimum values of both parameters depend on the actuator type.

A typical AUMA actuator of the type range SA 07.1 has a tripping torque of 10 – 30 Nm (see details on the name plate), the minimum permissible tripping torque is in this case 33 %.

Make sure that the permissible minimum values for the tripping torques are not fallen short of; otherwise the writing process is rejected and the parameter is shown with an exclamation mark.

Figure 7

Parameters for setting the torque indication

The Local controls > Torque indication parameter only has an effect for non-Intrusive actuators equipped with the AUMATIC logic software version Z031.922/05 or later.

Figure 6

5.6. Additional functions

The “Additional functions” option allows to access to further AUMATIC DTM functions.

5.6.1 Trend

Note This function is only available if an online connection to the device is established.

This function (Additional functions > Trend) opens the trend view of the dynamic device values. The following data can be logged as trend:

- 1) Torque E6 as percentage of the nominal torque
- 2) Torque E6 as absolute value in Nm
- 3) Torque E6 as absolute value in Lbs.Ft.
- 4) Actual position E2 in per mil
- 5) Setpoint E1 in per mil
- 6) Status information on the operation status as binary value.


Further notes Negative torque values correspond to a torque in direction CLOSE, positive values correspond to a torque in direction OPEN. Only those torque values are displayed in the AUMATIC DTM which exceed a certain actuator-specific basic load (typically approx. 40 – 50 % of the nominal actuator torque).

The status information contains binary data on the current operation status:

Table 2

Value	Signification
1	Actuator runs in direction OPEN
2	Actuator runs in direction CLOSED
3	Actuator is in end position OPEN
4	Actuator is in end position CLOSED
5	Actuator is at desired setpoint E1


Figure 8






Configuring the trend function

Scaling of axes, graph representations, ... etc..



Device specific configuration:

Setting the graph assignment, the automatic file backup, as well as the refresh time of the trend function.



Note regarding the refresh time:

The cycle time set by this parameter defines the reading cycle time for the trend data which is always observed. The actual cycle time might be longer, depending on the Profibus DP baud rate, the number of connected Profibus DP devices, the configuration of the Profibus DP communication, as well as the number of simultaneously available Profibus DP-V1 connections to other field devices.



Save recorded trend data as *.bmp file



Save recorded trend data as *.csv file



Load recorded trend data in *.csv format



Print trend data



This button can be used to shift the respective data series using the mouse from the Y axis to the X axis. Besides the time-dependent presentation, this feature allows a presentation of the X-Y graph of the trend data.



Adapt current view of recorded trend data

Start

Start recording the trend function

Stop

Stop recording the trend function




Activate the screen refresh feature

This button is used to activate or deactivate the refresh feature for the trend graphs on the screen. The trend data can be recorded in the background if the refresh feature is deactivated.

5.6.2 About

This function opens a window indicating important information on the AUMATIC DTM.

Figure 14



6. Profibus DP-V0 communication channel

The AUMATIC DTM supports various configurations for the cyclic data exchange via Profibus DP (e.g. in combination with ABB control systems). Depending on the configuration selected, the number of communication channels varies. You may select the following options:

- 4 byte input, 4 byte output, consistent
- 8 byte input, 4 byte output, consistent
- 12 byte input, 4 byte output, consistent
- 16 byte input, 8 byte output, consistent
- 20 byte input, 8 byte output, consistent
- 6 byte input, 2 byte output, consistent

Use the Channel Module Setup > Channel Setup parameter in the Offline parameterisation to set the communication channel.

All configurations refer to process representation input arrangement 1, see the following figures:

Figure 15



Byte1: Logical signals								Byte 2: Actuator signals								Byte 3: E2 (Actual position)								Byte 4: E2 (Actual position)								
Fault ind.	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0	Warning ind.	Running CLOSE	Running OPEN	Not ready ind.	Setpoint reached	Closed position	Open position	TSC (DSR)	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0	Actual position high byte (positioner)	Actual position low byte (positioner)						
Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0									TSO (DOEL)	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0								
																LSC (WSRF)																
																LSO (WOEL)																
																Local sw. position																
																Remote sw. position																
																Loss of phase																
																Thermal fault																
Byte 5: Configurable byte 1	Byte 6: Physical operation (configurable byte 2)								Byte 7: Options part 1 (configurable byte 3)								Byte 8: Options part 2 (configurable byte 4)															
Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0									Runs from Local	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0								
																Runs from REMOTE																
																Runs via handwheel																
																(Actuator moving)																
																Start stepping mode																
Byte 9: DP1 An1	Byte 10: DP1 An1								Byte 11: E4 (Torque)								Byte 12: E4 (Torque)															
DP1 Analogue input high byte								DP1 Analogue input low byte								Torque high byte								Torque low byte								
Byte 13: Not ready ind.	Byte 14: Fault signals								Byte 15: Warning signals part 1								Byte 16: Warning signals part 2															
External operation	Clear state	Emergency mode	Emergency stop active	... 	Actuator locked	Selector not remote	Wrong command	-	Internal fault	Torque fault (CLOSED)	Torque fault (OPEN)	Loss of phase	Thermal fault	-	Config. fault	Operation time	Starts/run	Internal feedback	Internal warning	I/O1 Anlog In2 loss	I/O1 Anlog In1 loss	-	-	Analog In1 DP1 loss	Analog In2 DP2 loss	-	-	Setpoint E1 loss	Feedback E2 loss	-	Torque E4 loss	
Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0									Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0									
Byte 17: DP1 An2	Byte 18: DP1 An2								Byte 19: Reserved								Byte 20: Reserved															
DP1 Analogue input 2 high byte								DP1 Analogue input 2 low byte								Reserved for future extensions								Reserved for future extensions								
Byte 21: Reserved	Byte 22: Reserved								Byte 23: Additional data								Byte 24: Reserved															
Reserved for future extensions								Reserved for future extensions								In intermed. position																
Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0									-	-	-	Intermed. pos. 8	Intermed. pos. 7	Intermed. pos. 6	Intermed. pos. 5										

Byte 1: Commands								Byte 2: E3 (reserved)								Byte 3: E1 (Setpoint)								Byte 4: E1 (Setpoint)							
Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0																								
Reset				Remote SETPOINT				Remote CLOSED				Remote OPEN				Setpoint high byte								Setpoint low byte							
Byte 5: Reserved								Byte 5: Additional commands								Byte 6: Operation commands for multiport valve function ¹⁾															
Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0																								
Bit 15	Bit 14	Bit 13	Bit 12	Bit 11	Bit 10	Bit 9	Bit 8																								
Channel 2				Channel 1								Local sw. position				Off sw. position				Remote sw. position				Intermed. pos. 8	Intermed. pos. 7	Intermed. pos. 6	Intermed. pos. 5	Intermed. pos. 4	Intermed. pos. 3	Intermed. pos. 2	Intermed. pos. 1

1) The multiport valve function is available as an option (refer to short instructions AUMATIC with multiport valve function)

7. Appendix A: Literature

- FDT Interface Specification; specification for Profibus Device Description and Device Integration, Release 5/2001, Version: 1.2 Order No.2.162, www.profibus.com
- Field Device Tool FDT; Die universelle Feldgeräteintegration [the universal field device integration], Oldenburg Verlag [publisher] ISBN 3-486-27044-3
- FDT Joint Interest Group www.fdt-group.org
- Operation instructions Actuator controls AUMATIC AC 01.1 Profibus DP, www.auma.com

8. Overview on AUMATIC DTM icons

Table 3	
	Static value, display
	Static value: Indicates that this value is a default value.
	Invalid dynamic value: This value has not been read from the device.
	Dynamic value display: Blue and red arrows toggle each time the value is read from the device.
	Modification indication: Indicates that the value has been modified and not yet saved to the device. This icon disappears after saving the value to the device.
	This value is currently being edited and has not yet been confirmed via the Return key.
	Range violation. The entered value conflicts with this requirement.
	Error indicator: Indicates an error that occurred when reading this value from the device. Disappears when the value is read without error.
	Device status error: The device is in error state.
	Device status OK: The device is in OK state.
	Undefined parameter: The value has not yet been read from the device.
	System is working: Indicates that no feedback has been received from the system.
	Calculation indicator: Green turning wheel indicates that the DTM is performing calculations.
	Communication indicator: Yellow turning wheel indicates active communication with the device.
	Indicates a communication error.
	Connection indicator: The DTM is connected to the device.
	Offline indicator: The DTM is not connected to the device.
	Set default values: Sets all persistent parameters to their default value.
	Set all values to invalid. When opening a menu again, all parameters are read from the device.
	Status bar: Provides information on the current state of the DTM.
	Print: Prints the data of the current view.
	Tree view on/off. Activates and deactivates the tree view.
	Tree view on/off. Activates and deactivates the header view.
	Picture view on/off. Enables and disables the presentation of the photo.
	Opens the online help file of the device.
	Opens an online help file providing information on the AUMATIC parameters.

Notes

Europe

AUMA Riester GmbH & Co. KG

Factory Müllheim

DE-79373 Müllheim

Tel +49 7631 809 - 0

Fax +49 7631 809 - 1250

riester@auma.com

www.auma.com

Factory Ostfildern-Nellingen

DE-73747 Ostfildern

Tel +49 711 34803 - 0

Fax +49 711 34803 - 3034

riester@wof.auma.com

Service Centre Cologne

DE-50858 Köln

Tel +49 2234 2037 - 9000

Fax +49 2234 2037 - 9099

Service@sck.auma.com

Service Centre Magdeburg

DE-39167 Niederrdondeleben

Tel +49 39204 759 - 0

Fax +49 39204 759 - 9429

Service@scm.auma.com

Service Centre Bavaria

DE-85386 Eching

Tel +49 81 65 9017- 0

Fax +49 81 65 9017- 2018

Riester@scb.auma.com

AUMA Armaturenantriebe GmbH

AT-2512 Tribuswinkel

Tel +43 2252 82540

Fax +43 2252 8254050

office@auma.at

www.auma.at

AUMA (Schweiz) AG

CH-8965 Berikon

Tel +41 566 400945

Fax +41 566 400948

RettichP.ch@auma.com

AUMA Servopohony spol. s.r.o.

CZ-10200 Praha 10

Tel +420 272 700056 / 704125

Fax +420 272 704125

auma-s@auma.cz

www.auma.cz

OY AUMATOR AB

FI-02270 Espoo

Tel +35 895 84022

Fax +35 895 8402300

auma@aumator.fi

AUMA France S.A.R.L.

FR-95157 Taverny Cédex

Tel +33 1 39327272

Fax +33 1 39321755

stephanie.vatin@auma.fr

www.auma.fr

AUMA ACTUATORS Ltd.

GB- Clevedon North Somerset BS21 6QH

Tel +44 1275 871141

Fax +44 1275 875492

mail@auma.co.uk

www.auma.co.uk

AUMA ITALIANA S.r.l. a socio unico

IT-20023 Cerro Maggiore (MI)

Tel +39 0331 51351

Fax +39 0331 517606

info@auma.it

www.auma.it

AUMA BENELUX B.V.

NL-2314 XT Leiden

Tel +31 71 581 40 40

Fax +31 71 581 40 49

office@benelux.auma.com

www.auma.nl

AUMA Polska Sp. z o.o.

PL-41-310 Dąbrowa Górnica

Tel +48 32 261 56 68

Fax +48 32 261 48 23

R.Ludzien@auma.com.pl

www.auma.com.pl

OOO Priwody AUMA

RU-141400 Moscow region for mail:

124365 Moscow a/ya 11

Tel +7 495 221 64 28

Fax +7 495 221 64 38

aumarussia@auma.ru

www.auma.ru

ERICHSEN ARMATUR AB

SE-20039 Malmö

Tel +46 40 311550

Fax +46 40 945515

info@erichsarmatur.se

www.erichsarmatur.se

GRØNBÆCH & SØNNER A/S

DK-2450 København SV

Tel +45 33 26 63 00

Fax +45 33 26 63 21

GS@g-s.dk

www.g-s.dk

IBEROPLAN S.A.

ES-28027 Madrid

Tel +34 91 3717130

Fax +34 91 7427126

iberoplan@iberoplan.com

D. G. Bellos & Co. O.E.

GR-13671 Acharnai Athens

Tel +30 210 2409485

Fax +30 210 2409486

info@dgbellos.gr

SIGURD SØRUM A. S.

NO-1300 Sandvika

Tel +47 67572600

Fax +47 67572610

post@sigurd-sorum.no

INDUSTRA

PT-2710-297 Sintra

Tel +351 2 1910 95 00

Fax +351 2 1910 95 99

jpalhares@tyco-valves.com

MEGA Endüstri Kontrol Sistemleri Tic. Ltd.

Sti.

TR-06810 Ankara

Tel +90 312 242 18 88 pbx

Fax +90 312 242 18 00

megaendustri@megaendustri.com.tr

CTS Control Limited Liability Company

UA-02099 Kiyiv

Tel +38 044 566-9971, -8427

Fax +38 044 566-9384

v_polyakov@cts.com.ua

Africa

AUMA South Africa (Pty) Ltd.

ZA-1560 Springs

Tel +27 11 3632880

Fax +27 11 8185248

aumasa@mweb.co.za

A.T.E.C.

EG- Cairo

Tel +20 2 3599680 - 3590861

Fax +20 2 3586621

atec@intouch.com

America

AUMA ACTUATORS INC.

US-PA 15317 Canonsburg

Tel +1 724-743-AUMA (2862)

Fax +1 724-743-4711

mailbox@auma-usa.com

www.auma-usa.com

AUMA Chile Representative Office

CL- Buin

Tel +56 2 821 4108

Fax +56 2 821 9252

aumachile@adsl.tie.cl

LOOP S. A.

AR-C1140ABP Buenos Aires

Tel +54 11 4307 2141

Fax +54 11 4307 8612

contacto@loopsa.com.ar

Asvotec Termoindustrial Ltda.

BR-13190-000 Monte Mor/SP.

Tel +55 19 3879 8735

Fax +55 19 3879 8738

atudor.auma@asvotec.com.br

TROY-ONTOR Inc.

CA-L4N 5E9 Barrie Ontario

Tel +1 705 721-8246

Fax +1 705 721-5851

troy-ontor@troy-ontor.ca

MAN Ferrostaal de Colombia Ltda.

CO- Bogotá D.C.

Tel +57 1 401 1300

Fax +57 1 416 5489

dorian.hernandez@manferrostaal.com

www.manferrostaal.com

PROCONTIC Procesos y Control Automático

EC- Quito

Tel +593 2 292 0431

Fax +593 2 292 2343

info@procontic.com.ec

IESS DE MEXICO S. A. de C. V.

MX-C.P. 02900 Mexico D.F.

Tel +52 55 55 561 701

Fax +52 55 53 563 337

informes@iess.com.mx

Corsusa S.A.C.

PE- Miraflores - Lima

Tel +511444-1200 / 0044 / 2321

Fax +511444-3664

corsusa@corsusa.com

www.corsusa.com

PASSCO Inc.

PR-00936-4153 San Juan

Tel +18 09 78 77 20 87 85

Fax +18 09 78 77 31 72 77

Passco@prtc.net

Suplibarca

VE- Maracaibo Estado, Zulia

Tel +58 261 7 555 667

Fax +58 261 7 532 259

suplibarca@intercable.net.ve

Asia

AUMA Actuators (Tianjin) Co., Ltd.

CN-300457 Tianjin

Tel +86 22 6625 1310

Fax +86 22 6625 1320

mailbox@auma-china.com

www.auma-china.com

AUMA (INDIA) PRIVATE LIMITED

IN-560 058 Bangalore

Tel +91 80 2839 4655

Fax +91 80 2839 2809

info@auma.co.in

www.auma.co.in

AUMA JAPAN Co., Ltd.

JP-210-0848 Kawasaki-ku, Kawasaki-shi Kanagawa

Tel +81 44 329 1061

Fax +81 44 366 2472

mailbox@auma.co.jp

AUMA ACTUATORS (Singapore) Pte Ltd.
SG-569551 Singapore
Tel +65 6 4818750
Fax +65 6 4818269
sales@auma.com.sg
www.auma.com.sg

Al Ayman Industrial. Eqpts
AE- Dubai
Tel +971 4 3682720
Fax +971 4 3682721
auma@emirates.net.ae

PERFECT CONTROLS Ltd.
HK- Tsuen Wan, Kowloon
Tel +852 2493 7726
Fax +852 2416 3763
joeip@perfectcontrols.com.hk

DW Controls Co., Ltd.
KR-153-803 Seoul Korea
Tel +82 2 2113 1100
Fax +82 2 2113 1088/1089
sichoi@actuatorbank.com
www.actuatorbank.com

Al-Arfaj Engineering Co WLL
KW-22004 Salmiyah
Tel +965 481-7448
Fax +965 481-7442
info@arfajengg.com
www.arfajengg.com

Petrogulf W.L.L
QA- Doha
Tel +974 4350 151
Fax +974 4350 140
pgulf@qatar.net.qa

Sunny Valves and Intertrade Corp. Ltd.
TH-10120 Yannawa Bangkok
Tel +66 2 2400656
Fax +66 2 2401095
sunnyvalves@inet.co.th
www.sunnyvalves.co.th/

Top Advance Enterprises Ltd.
TW- Jhonghe City Taipei Hsien (235)
Tel +886 2 2225 1718
Fax +886 2 8228 1975
support@auma-taiwan.com.tw
www.auma-taiwan.com.tw

Australia

BARRON GJM Pty. Ltd.
AU-NSW 1570 Artarmon
Tel +61 294361088
Fax +61 294393413
info@barron.com.au
www.barron.com.au

2007-02-21



Solutions for a world in motion

AUMA Riester GmbH & Co. KG

P.O.Box 1362
D-79373 Müllheim
Tel +49 7631 809 - 0
Fax+49 7631 809 - 1250
riester@auma.com
www.auma.com



Certificate Registration No.
12 100104 4289

Y003.881/003/en/1.07