

Spare Parts:



Fig. F: 1.XMP Module



Fig. G: 1.XMP Module within EPAC enclosure




Fig. H: 1.XMP PCB Cards




Fig. I: 1.XMP Transformers




Fig. J: 1.XMP Cable Harness




Fig. K: 1.XMP Mechanical Parts

CATEGORY	PART	DESCRIPTION	ARTICLE NO
PRINTED CIRCUIT BOARDS	1	CPU CARD	K215.213
	2	PS CARD	K215.214
	3	KEY CARD	K215.215
	4	EXTENDER CARD	K215.216
TRANSFORMERS	5	T1-415V PRIMARY	Z213.096
	6	T2-415V PRIMARY	Z213.095
CABLES	7	CONTROL WIRES - X1	Z213.083
	8	SPACE HEATER SUPPLY-X2	Z213.084
	9	SELECTOR SWITCH CONN TO SWITCH CARD-X3	Z213.085
	10	RELAY WIRES-X4	Z213.086
	11	PWR TO CONTACTOR CONNECTOR-X5	Z213.087
	12	F1 CONNECTOR-X6	Z213.088
	13	SWITCH CARD CONNECTOR-X7	Z213.089
	14	SELECTOR SWITCH CONNECTOR TO TERMINALS-X8	Z213.090
	15	TRANSFORMER T1 CONNECTOR-X9	Z213.091
	16	TRANSFORMER T2 CONNECTOR-X10	Z213.092
	17	T2 WIRING -X11	Z213.093
	18	T1 WIRING -X12	Z213.094
MECHANICAL PARTS	19	CAPTIVE SCREWS (HEXAGON BOLT)	Z213.098
	20	TR-MOUNTING PLATE	Z213.078
	21	CONTACTOR MOUNTING PLATE	Z213.079
	22	FRONT PLATE	Z213.080
	23	MODULE MOUNTING PLATE	Z213.081
	24	EMI PROTECTION PLATE	Z213.082
	25	FUSE PLATE	Z212.058
	26	FUSES - 1A	K215.143
	27	FUSES - 250mA	K214.379
	28	FUSE HOLDER	K215.144