

***Updating service not
applicable for printed
copies!***

Handling instructions for VCI bags

Handling instructions for VCI bags

Page 1 of 3

VCI bags have to be procured in three different sizes and shall replace the VCI paper. Place bags into the cage pallet or the small load carrier. When inserting intermediate layers ensure that the bag is not damaged. Should tears exceeding 10 cm occur, the bags have to be rejected. Otherwise, the tears may be sealed with adhesive tape. Prior to leaving for a break or for the day, seal the bag to maintain corrosion protection. For more detailed information, refer to the last page of the instructions. For our parts, only bags with VCI print may be used.



The three different sizes are used for large cage pallets, medium-sized cage pallets and for small load carriers.

Handling instructions for VCI bags

Page 2 of 3



Article number	Dimensions	Use
C001.186	430x320x500	Small load carriers

The VCI bag for medium-sized cage pallets can be identified by the three lines printed at one side.



Article number	Dimensions	Use
C001.185	1230x825x1500	Semi cage pallet



Article number	Dimensions	Use
C001.032	1250x1120x1800	EURO cage pallet

Handling instructions for VCI bags

Page 3 of 3


Correct



Ensure clean and dry packaging of parts!



Wear gloves!



During packaging, temperature of goods to be packaged and ambient temperature must be identical!



Packaging must be tightly sealed!
Seal holes or other damage with adhesive tape!
Prevent ingress of water!



For high bulk density, ensure that VCI is also placed at the centre!



Avoid direct contact of metal with wood, paper or cardboard!
Cover intermediate cardboard layers also with VCI!

Wrong

